Comfort Zone Portable Industrial Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ275

Original source file(s): CZ275.Instruction Manual.01.pdf; 120185.Instruction Manual.01.pdf

Source SHA-256: 1465c26504d5fc4a5d3e60be96b7556c807c9a8b521be9d1c6b1446c1fba9ee9

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase.

This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation.

All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available.

This limited warranty is given in lieu of all other warranties.

Mr.Brands LLC

113 Fillmore St

Bristol,PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev. 07/14/23

Source page 1 - Panel 1 (left to right) (OCR)

O Comfort Zone.

PINDUSTRIAL | Model No. CZ275

fone i 4 AS BEEK A

Wi es

i ath WA AN!))

\ N\A, SE /7/)

\ NWR)

NAS

Portable Industrial Heater

Features:

e Water and Dust resistant to IP24

e Adjustable Thermostat

e High Heat Setting (5000W)

e Portable - Uses NEMA 6-30R Receptacle

e Fan-Forced for Wide Heat Circulation

¢ Safety Overheat Protection

© Convenient Handle with Integral Cord Wrap

e Sturdy Heavy Gauge Steel Body

¢ 240 VA.C., 60Hz. 21A, 17,050 BTU

www.comfortzoneproducts.com Save These Instructions

Source page 1 - Panel 2 (left to right) (OCR)

Comfort Zone.

©) www.comfortzoneproducts.com

INTENDED USE /\WARNING: SHOCK HAZARD

Electric Utlity heaters are designed to meet a variety of heating requirements. Use your heater only in dry environments. This heater is not intended

This product is intended for indoor use only. Use only with electrical wiring that for use in a bathroom, laundry area, or similar locations, or near sinks,

is in good working order and that meets applicable codes and ordinances. This washing machines, swimming pools or other sources of water. Never

heater must be plugged in to a 208-240V AC, 25 Amp. (or larger) circuit. Do not locate heater where it may fall into a bathtub or other water container.

plug anything additional into the same circuit. If you have any questions whether Do not use heater outdoors. Do not use in damp environments such

your wiring is adequate, consult a qualified electrician. Risk of fire, overheating, as flooded basements.

malfunction, property damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the vicinity of \WARNING: HOT SURFACES

your heater/fan. Do not touch body of heater when in use. This heater is hot when in

While using your heater/fan, you should follow the IMPORTANT INSTRUCTIONS use, to avoid burns, do not let bare skin touch hot surfaces.

listed below. As part of those instructions, we have used the word "WARNING" lf provided, use handles when moving this heater.

to indicate the level of hazard: WARNING indicates a hazard which, if not

avoided, could result in injury or death. AXWARNING: FIRE HAZARD ;

Heater has hot and arcing or sparking parts inside. Do not use near

IMPORTANT INSTRUCTIONS combustible materials or flammable gases or sources of heat. DO

When using electrical appliances, basic precautions should always be followed NOT USE in areas where gasoline, paint or flammable materials are

to reduce the risk of fire, electric shock and injury to persons, including the used or stored. Keep combustible materials such as furniture, pillows,

following bedding, papers, clothes and curtains at least 3 feet (0.9 m) from

Read all the instructions before using this heater. the front of the heater and keep them away from the sides and rear.

© This heater is hot when in use. To avoid burns, do not let bare skin touch hot Ensure a minimum of 5.5 Inches (14cm) from both sides and rear of

surfaces. Use provided handle when moving this heater. Keep combustible heater to adjacent walls. Keep rear grille away from walls or drapes

materials, such as furniture, pillows, bedding, papers, clothes and curtains at so as to not block air intake. To prevent a possible fire, do not block

least 3 feet (0.9 meters) from the front of the heater-fan and keep them away air intakes or exhaust in any manner. Do not use on soft surfaces, like

from the sides and rear. Ensure a minimum clearnace of 5.5 inches (14cm) from a bed, where openings may become blocked. Do not insert or allow

both sides and rear of heater to adjacent walls. Keep rear grille away from walls foreign objects to enter any ventilation or exhaust opening as this may

of drapes 60 as to not block air intake. cause an electric shock, fire, or damage the heater.

* Do not use heater unattended. Use of extreme caution is necessary when any

heater is used by or near children, invalids, disabled persons or pets. AXWARNING: ELECTRICAL SHOCK HAZARD

* Do not operate the heater with a damaged power cord or after the heater Do not use with damaged cord or plug. Use with adequate electrical

malfunctions, has been dropped or damaged in any manner. Return heater to system that is up to code .

authorized service facility for examination, electrical or mechanical adjustment

or repair. The supply cord has a NEMA 6-30 plug.

* Do not use heater outdoors. As a safety feature this plug will fit 7a

* Use your heater only in dry environments. This heater is not intended for use in ina 240V grounded receptacle/outlet =<

a bathroom, laundry area, or similar locations, or near sinks, washing machines, (NEMA 6-30R) only one way. os

swimming pools or other sources of water. Never locate heater where it may fall To prevent electric shock, match the NEMA 6-30P "3

into a bathtub or other water container. Do not use in damp environments such blade pattern of the plug. Fully insert fatech Cord \\

i (attached)

as flooded basements. plug. If the plug does not fit contact

* Do not place the heater on a small, unlevel, uneven or any surface which a qualified electrician.

might allow heater to tip or fall.

* For proper operation, heater should be placed on a smooth, non-combustible Do not operate any heater with a damaged cord or plug or after heater

surface. Do not place on rugs, carpet, vinyl flooring or other plastic surfaces. malfunctions, has been dropped or damaged in any manner. Do not

Not for use outdoors or in wet areas. operate heater with a broken heating element or ceramic cone or any

* This heater is not designed as a primary heat source. visual imperfections. For repairs covered under warranty, see warranty

* Always plug heaters directly into a wall outlet/receptacle. Never use with an statement. For all other repairs contact Comfort Zone® Customer

extension cord or relocatable power tap (outlet/power strip). Always unplug Service by telephone or mail for information and assistance.

heater when not in use.

* Do not run power cord under carpeting. Do not cover cord with throw rugs, PET OWNERS NOTE:

runners or similar coverings. Arrange cord away from traffic area where it will not The health of birds and some small pets are extremely sensitive to the

be tripped over. fumes given off during the initial use of many appliances. Although

* To disconnect heater, turn controls off then remove plug from outlet. these fumes are not harmful to humans, it is recommended that this

* Do not insert or allow foreign objects to enter any ventilation or exhaust heater not be used around birds and small pets during its initial use

opening as this may cause an electric shock or fire or damage the heater. until the manufacturing corrosion coatings burn off.

* To prevent a possible fire, do not block air intakes or exhaust in any manner.

Do not use on soft surfaces like a bed, where openings may become blocked.

* Aheater has hot and arcing or sparking parts inside. Do not use it in areas

where gasoline, paint or flammable liquids are used or stored.

* Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock or injury to

persons or property.

* Connect to properly grounded outlets only. Check heater voltage and

amperage on the back of heater to make sure it agrees with the electrical

service supplied,

Source page 1 - Panel 3 (left to right) (OCR)

©) www.comfortzoneproducts.com

USAGE TURNING HEATER OFF: To shut the heater off, turn the

HEATER OPERATION: cpwntteneen neuen | EMOSAT neh! pst tn ONES

Post iol rowing all instructions and recommendations listed in this two minutes. For heaters with the time delay stopping function - even if

manual. the power switch is off - the delay circuit may turn the heater on if the

HEATER LOCATION: Place the heater in the area of the room that is | inner temperature has reached the preset temperature. The delay time

coldest. depends on the ambient temperature. For 68°F ambient temperature,

HEATER CONNECTION: Plug heater directly into 208-240 volt A.C it is about 3-4 minutes. If the ambient temperature keeps being higher

60 Hz, 25A wall outlet, Be sure plug fits tightly in outlet, Aloose _|_‘han 80°F, the delay function can not cool down the heater and the delay

connection may cause overheating and damage to the plug or heater. time may be very long or the delay circuit won't open. Therefore, the

NOTE: To prevent overloading a circuit, do not plug the heater into a user can only disconnect the heater from the power supply by pulling

anee event & gacreun, pig out the plug.

circuit that is servicing other electrical needs.

PARTS OF THE HEATER:

TURNING HEATER ON: To start the heater, turn the heater ON by ‘set

turning the Power Knob (located on the top of the heater) away from the | 1) Thermostat 5) Angle Adjusting Knob

OFF position «0» to the FAN ONLY setting « 4 » or to one of the two 2) Heat Level & Fan Knob -_6) Motor

heat settings: 3) Heating Element 7) Adjusting Foot

-- « Sold » - LOW HEAT (3300W) 4) Steel Frame

-- « Soll » - HIGH HEAT (5000W)

For faster heat up or to increase the heat output, turn the THERMOSTAT FRONT of HEATER BACK of HEATER

CONTROL all the way to the MAX position. The thermostat function 1 2

controls the temperature output. To decrease the heat output, turn the az _tonbes

a ES 7

knob towards the MIN Position. To completely shut off heater, turn the 3 -s 4 (ta

POWER KNOB to the OFF position «0» and unplug the heater. L__| A =

EEN if ff }-6

NOTE: During the heaters initial use, you may experience a slight odor Li ae\ < “oe ie

or smoking. This is the result of the heating element lubrication "burning A a ai Hi) Wao fi me fl

off". This is normal and will go away after a few minutes of use. 4)) ‘

/X -- 7

a a

I-- C=

CONTROL PANEL

- wg

Vi \ Fin ASSEMBLY OF THE HEATER:

{ \ |) bm 1) Clip plastic feet on steel frame as shown.

\ i} \" } 2) Assemble the M8x28 Adjustment knob to steel frame and screw into

ay \N y heater body on both sides of heater.

-_ J o£ 3) Tighten the M8X28 screw adjustment knobs on both sides to keep

MIN MAX heater at the desired angle.

AjustableThermostat Power knob

HEAT SETTING: This heater has a thermostat and two heat settings. Gi BSN ec \ maf

je \ ml

SETTING THERMOSTAT: At first turn the thermostat to MAX and Gm) *) ENE

let the heater operate with full power input. When the room temperature \\ yy) EX \ \

reaches the required value, turn the thermostat to left until it switches Wy UMERN_ (72)

off. The thermostat will then switch on and off automatically to control & SZ \ WZ Wy) } Wi

the room temperature according to the preset value and keep the room i) f WG

temperature constant. DZ

- a f

“- [8

Source page 1 - Panel 4 (left to right) (OCR)

Comfort Zone.

TILT ANGLE ADJUSTMENT: LIMITED WARRANTY

This heater can be tilted to adjust the direction of the air to the desired This unit is guaranteed to the original retail purchaser against

angle. To adjust the tilt angle, loosen the adjustment knob at both sides | defects in quality or workmanship for a period of one year from

of heater and gently press down the front or the back of heater housing. | the date of original purchase. If this unit fails because of a

The heater will be tilted. manufacturing defect within 30 days of purchase, return the unit,

with your receipt, to the retailer. After 30 days, but within the

The heater blows hot air up; to adjust the direction of the air to be blown | warranty period, if the unit was purchased within the continental

out horizontally, gently press the front of heater body down. United States, return it, to Mr. Brands LLC for repair or

replacement. If the unit was purchased outside the continental

United States, return the unit to the place of purchase.

= This warranty does not cover damage caused by misuse, abuse,

~ (overheating or alteration. Repairs made by anyone other than Mr.

, &~ | E Brands LLC are not covered in this warranty. Mr. Brands LLC will

7 not be held liable for any losses due to neglectful operation.

8 Allimplied warranties, including the warranties of merchantability

me) es and of fitness of purpose, if applicable, are hereby limited in

“ae duration to the period of one year from the date of original retail

re y purchase. Some states do not allow limitations on how long an

WA 4, implied warranty lasts, so the above limitations may not apply

~~ é to you. Incidental or consequential damages arising from a

-2 - 2 breach of either express or implied warranties are hereby

disclaimed and excluded. Some states do not allow the exclusion

of limitation of incidental or consequential damages, so this

IMPORTANT SAFETY FEATURES limitation ot exclusion may not apply to you. Upon the expiration

Overheat Protection: The heater is equipped with an automatic over- of this warranty all such liability will terminate. No other warranties

heat protection device located inside the body of the heater. If the heater | _are expressed or implied. This warranty gives you specific legal

grille is obstructed, or if the heater gets too hot for any reason, the rights, and you may also have other rights which vary from state

automatic overheat protection device will turn the heater off. To reset the | to state. No informal dispute settlement mechanisms are available.

heater, simply turn power off and unplug the heater for 10 minutes until it This limited warranty is given in lieu of all other warranties.

cools down and you may plug in and restart the heater. Be sure that the

heater is on a smooth level surface with no obstructions.

This warranty gives you specific legal rights, and you may also

CARE AND MAINTENANCE have other rights which vary from state to state. No informal

CLEANING: CAUTION - Before cleaning the heater be sure to discon-___| dispute settlement mechanisms are available. This limited

nect power cord from power outlet and allow the heater to cool com- warranty is given in lieu of all other warranties.

pletely. Clean the outside surface with a clean damp cloth. Do not use

harsh chemical or abrasive cleaners. DO NOT IMMERSE THE HEATER

IN WATER. Allow heater to dry completely before use. Any other service | MtBrands LLC

should be performed by a authorized service representative. 113 Fillmore St

Bristol,PA 19007

REPAIR: 00 NOT OPERATE THE HEATER WITHOUT THE GRILLE IN. | 877-820-7505

PLACE. DO NOT USE THE HEATER IF IT HAS MALFUNCTIONED OR www.comfortzoneproducts.com

BECOME DAMAGED IN ANY WAY.

STORAGE: Keep original carton for storage of the heater. Coil and tie /

the power cord to avoid damage during storage. Store heater in a cool, WARNING:

dry place, Cancer and Reproductive Harm ~

‘www P6SWarnings.ca.gov

Rev. 07/14/23