Comfort Zone Dual Window Fan with Remote Control

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ310R

Original source file(s): CZ310R.Instruction Manual.01.pdf

Source SHA-256: 02ade0925aa66d32df7f79e0ac6f4404380e16e234a3697ea670e867574328e9

Original PDF pages: 6 | Recovered reading units: 6

Source page 1 - OCR transcription (OCR)

O) Comfort Zone OZ810R Series

America’s Heating and Cooling Choice

4 ES :

ESQwayZe ee Ze

S=s Zz SS Ge

SS aS os | |

eae c= = DSi |

ee « (\ Sy te i)

ee (aa\s = hgggss-| areas

i = WE yry ey

| i Sg WS |

es a , ~=-=q

4 ~< |} i

with Two Removable Covers and

Full Function Remote Control

Features:

¢ Three Fan Functions:

COOL - Brings fresh air in

EXHAUST - Removes stale air from room

CIRCULATE - Operates fans opposing directions creating

air circulation and room ventilation

¢ Push Button «ON» Switch with Speed Settings: LOW, MEDIUM, HIGH

¢ Long Distance Full Function Remote Control

(requires 2 AAA batteries - batteries not included)

¢ Adjustable Accordion Extensions Expand from 23-1/2" to 37"

¢ Rust Resistant Construction

¢ Poly Fan Blades Designed for Maximum Air Movement

* Safety Grilles

© 120V A.C. / 6OHz

* 2 Removable covers to keep out hot air, humidity, bugs:

FABRIC COVER (attaches to front when not in use to keep out hot and humid air)

BUG SCREEN (attaches to back of fan)

www.comfortzoneproducts.com Save These Instructions

Source page 2 - OCR transcription (OCR)

eee READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with INSTRUCTIONS |

electrical wiring that is in good working order and that meets 1

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, wimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we

have used the word "WARNING to indicate the level of havard: | Water Never locate fan where it may fall into a bathtub or other

WARNING indicates a hazard which, if not avoided, could result water receptacle. Do not use in damp environments such as

in injury or death. °

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS: Do not touch fan motor when in use. This motor is hot when in

A use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should | WaRNING: FIRE HAZARD

always be followed to reduce the risk of electric shock, fire, or Fans have arcing or sparking parts inside. Do not use near

injury to persons, including the following precautions: combustible materials or flammable gases or sources of heat. Do

* Read all the instructions before using this fan. not use in areas where gasoline, paint or flammable materials are

* Use this fan only as described in this manual. Any other use not | used or stored. To prevent a possible fire, do not block air intakes

recommended by the manufacturer may cause electrical shock, | or exhaust in any manner. Do not insert or allow foreign objects

fire or injury to persons. to enter any ventilation or exhaust opening as this may cause an

* Do not operate the fan with a damaged power cord or after the electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fanis_| Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface | @AUTION: TO PREVENT ELECTRIC SHOCK,

which might allow fan to tip or fall. this product has a polarized two prong plug (one blade is wider

* For proper operation, fan should be placed on a smooth, than the other) that must be fully inserted in to a matching

non-combustible, level surface. properly grounded outlet. This plug is designed to fit a polarized

* Always unplug fan when not in use, when moving from place outlet only one way. If the plug does not fit fully into the outlet,

to place, when assembling or disassembling parts, and before reverse the plug. If the plug still does not fit, contact a qualified

cleaning. electrician. Do not attempt to defeat this safety feature.

* The use of attachments, not recommended or sold by the

manufacturer, may cause hazards. CAUTION: TO REDUCE THE RISK OF FIRE OR

* Do not use outdoors. ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard Solid-state speed control device.

(for non-window models). DO NOT operate any fan with a damaged cord or plug or after

* Do not operate the fan with blade guards or any safety device fan malfunctions, has been dropped or damaged in any manner.

removed. Do not operate fan with a broken blade, safety cage or any visual

* Avoid the use of extension cords due to risk of fire. If an imperfections. Disconnect power before servicing. For repairs

extension cord must be used, the cord must be minimum covered under warranty, see warranty statement. For all other

14 AWG and rated not less then 1875 watts. repairs contact Comfort Zone® Customer Service by telephone or

* Do not run power cord under carpeting. Do not cover cord with | mail for information and assistance.

throw rugs, runners or the like. Arrange cord away from traffic

area where it will not be tripped over. DO NOT run power cord under carpeting. Do not cover cord

* Do not insert or allow any object to enter any openings on the with throw rugs, runners or the like. Arrange cord away from

fan. Doing so may cause electric shock and/or fire hazard. traffic area where it will not be tripped over. Avoid the use of

Avoid contact with moving parts. extension cords due to risk of fire. If an extension cord must

* This appliance is not intended for use by persons (including be used, the cord must be minimum 14 AWG and rated not

children) with reduced physical, sensory or mental capabilities | less then 1875 watts. Do not use an extension cord unless the

or lack of experience and knowledge, unless they have plug can be completely inserted into its receptacle. Unplug

been given supervision or instruction concerning use of the the fan when not in use. Do not operate fan with its ventilation

appliance by a person responsible for their safety. obstructed.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

CAUTION: TO REDUCE THE RISK OF FIRE AND TO TWO REMOVABLE COVERS

PROPERLY EXHAUST AIR, be sure to duct air outside. Removable Fabric Cover: This fan has a unique fabric

Do not vent exhaust air into spaces within walls or ceilings | | cover included that helps keep out hot air, humidity and bugs

or into attics, crawl spaces, or garages. when the fan is not in use. Simply attach loops of cover to the

hooks around the fan openings (See Fig. 4). This cover can

be used on the inside surface while the fan is installed in your

ASSEMBLY INSTRUCTIONS window for intake or exhaust. Please be sure to remove cover

Simple assembly is required to use this fan ona before youuse the fan. Do not run the fan with cover on, damage table or floor. can result.

Locate slot on the base of fan. Align screw holes of base leg Fig. 4
and fan and attach base leg, be sure base leg is snapped in and
secured in slot (See Fig. 1). Use supplied screw to secure the
base leg to the fan (See Fig. 2). Repeat for the opposite side. *
Note: Base legs should not be installed when secured inside a NY itech
window as described below. Mm -*oheover
. . to Hooks
Fig 1 Fig 2
war"
Slot 4
vo we ners Bug Screen attaches to back of fan: Simply attach
Screw. Ves rm) loops of cover to the hooks around the fan openings (See Fig. 5).
Hole OY, \, 2c---i
WZ as ee | Fig.5
SScs. e --
ee er
5 : Peestcaees =| | ‘fesse sess = =F

Installation for Double Hung Window: PSs ScShess. ge Sereen: - | 382)

It is recommended that window screens be left in place. Legs paemeeeces s| | -pesaasoset 227 2]
should not be installed when mounting in window. PSanesseee es pee desesssse 275
1. Locate Slot behind Control Panel, remember it for future use. Sea z & SS -
2. With fan centered in window unlock Clips to Accordion Panels Se
and spread out to fit securely in window track. Lock Accordion
Panels in place by closing the Clips on the top and bottom of
Accordion Panels (See Fig. 3).
3. Lower window into Slot behind Control Panel mentioned.
Fig 3
|= i (jg Pull Clip Up to Unlock
<i) y DBD
. Y i
RZ |
5 -+ Pull Accordion Panel Out
op See
ada S
ase
aap + Pull Clip Down to Unlock

Source page 4 - OCR transcription (OCR)

6) www.comfortzoneproducts.com

USAGE Turning Fan On and Off: (See Fig. 8)

Fan Operation: Always operate the fan in the upright position

following alll instructions and recommendations listed in this To start the fan, press 3==>/ the «ON/SPEED>» button repeatedly

manual. for the speed settings: 1 - LOW, 2- MEDIUM, 3 - HIGH.

Fan Location: Place the fan in the area of the room that will To stop the fan, press @ the «OFF» button.

provide proper fan cooling. This fan can be placed in a window

to provide additional FRESH air from outside. In this location, the ;

fan can also be used to push inside air to the outside using the Fig. 8 FAN SPEED CONTROL PANEL

EXHAUST position. ;

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall with WORDS

outlet. Be sure plug fits tightly in outlet. A loose connection may | eee i. |

cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a ON/Speed | | OFF

circuit that is servicing other electrical needs. Button UNS qj Button

FAN OPERATION CONTROLS nie

Speed Indicator Lights

This fan comes with the commands of the control/functions

panels and remote control expressed in two ways: WORDS: with SYMBOLS

(Fig. 6) or SYMBOLS (Fig. 7).

; FAN SPEED CONTROL PANEL ON/Speed OFF

Fig. 6 Button Button

B .

LID. EWM

SVS WZ

=i =a) 6 ose |G = Speed Indicator Lights

ess <a SS Gis

ek oe

Sars - “Zaps

<A: SS gl WEF

2 ~<a oneness Fan Functions: (See Fig. 9). This fan has three functions for

ale is maximum comfort. To switch between functions, press function

control button repeatedly.

AIR DIRECTION CONTROL PANEL =5)

==39) COOL - Brings fresh air in.

=H) exrraust - Removes stale air from room.

FAN SPEED CONTROL PANEL ==5) CIRCULATE - Operates fans in opposing directions

Fig. 7 creating air circulation and room ventilation.

od ‘| "| Fig.9 AIR DIRECTION CONTROL PANEL

Nia, 9:

ROVE iy 5 Function Indicator Lights Function Indicator Lights

SWIGED (NG

SS ta Ss -

= = SS =s

ae = = SF

Ee IS

Sy SS

ya FS ‘wdaibase

AIR DIRECTION CONTROL PANEL with WORDS Function Control Button with SYMBOLS

Source page 5 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

Fan Push Buttons and Indicator Lights FULL FUNCTION REMOTE CONTROL

If you have the fan with comands in words, see the . ON/OFF ith

column «Word» in the table below. If you have the fan wonns «- Wer SyupoLs

with comands in symbols, see the column «Symbol».

<- Speed Button -»

- 1-Low,

Symbol Description of 2-Medium,

Function mK HIGH

ON/SPEED | ON switch with N 4

(> $v:=.) button speed settings: Air Direction Button

-> 1-Low, 2-Med, eo

: xhaust

3-High Circulate

OFF Shuts fan off

button Place 2 «AAA» size batteries in the remote control (Batteries are

not included). Point the remote control towards the control panel

1 Low Fan speed is on for the sensor to receive a signal. Use the buttons on the remote

-_> indicator light | LOW y panel.

- WARNING: Do not mix old and new batteries.

2-> _ MEDIUM | Fan speed is on Do not mix standard (Carbon-Zino), alkaline, or rechargeable

indicator light | MEDIUM (Ni-Cd, Ni-MH, etc.) batteries. Used batteries should be disposed

- through local recycling centers.

3 HIGH Fan speed is on

indicator light | HIGH If you have the fan with comands in words, see the

F TT lumn «Word» in the table below. If you have the fan

=$) CooL Brings fresh air in col : y

Sh indicator light with comands in symbols, see the column «Symbol».

Remote Control Push Buttons

EXHAUST Removes stale air a

~<~- h indicator light | from the room Symbol Description of

Function

CIRCULATE | Operates fans in POWER - | Turns fan

= indicator light | opposing directions for I button ON/OFF

- PPO

air circulation and room

ventilation Speed settings:

1-Low,

2-Med,

v= SPEED 3-High

- button Works in the same way

- as a push button on

the fan.

Pushing the button

repeatedly changes the

fan speed.

=$|

> COOL Works in the same way

S as a push button on

the fan.

-

EXHAUST Pushing the button

- - $] repeatedly changes the

air direction.

=S Hj | crcuste

Source page 6 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

CARE AND MAINTENANCE: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a period of

with a clean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit fails

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN - because of a manufacturing defect within 30 days of

WATER. Allow fan to dry completely before use. Periodic grille purchase, return the unit, with your receipt, to the retailer.

cleaning with a vacuum will prevent dust build up. The motor is After 30 days, but within the warranty period, if the unit

sealed andl does not require any interior maintenance, cleaning was purchased within the continental United States, return

or lubrication. it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty

lubrication. does not cover damage caused by misuse, abuse,

. overheating or alteration. Repairs made by anyone other

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN than Mr. Brands LLC are not covered in this warranty.

BLOGME DAMAGED IN ANY WAY. ITHAS MALFUNCTIONED OR | ir. Brands LLC will not be held liable for any losses due to

. neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie | Warranties of merchantability and of fitness of purpose, if

the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of

one year from the date of original retail purchase. Some

---_- 0-oO-o states do not allow limitations on how long an implied

Note: Some models come with a plug where you can replace warranty lasts, so the above limitations may not apply to

a fuse. If your model has this, please read and follow the below you. Incidental or consequential damages arising from a

instructions to replace the fuse. breach of either express or implied warranties are hereby

. disclaimed and excluded. Some states do not allow the

This product employs overload protection (fuse). A blown fuse exclusion of limitation of incidental or consequential

indicates an overload or short-circuit situation. If the fuse blows, damages, so this limitation or exclusion may not apply to

unplug the product from the outlet. Replace the fuse as per the U th ti f this ty all h liabilit

user servicing instructions (follow product marking for proper you. Upon the expiration of this warranty all such liability

fuse rating) and check the product. If the replacement fuse will terminate. No other warranties are expressed or

blows, a short-circuit may be present and the product should implied. This warranty gives you specific legal rights, and

be discarded or returned to an authorized service facility for you may also have other rights which vary from state to

examination and/or repair. state. No informal dispute settlement mechanisms are

Fuse Replacement: available. This limited warranty is given in lieu of all other

" warranties.

1. Grasp plug and remove from the receptacle or other

outlet device. Do not unplug by pulling on cord. This warranty gives you specific legal rights, and you may

2. Open fuse cover by sliding open fuse access cover on also have other rights which vary from state to state.

top of attachment plug towards blades. See Fig. 2 No informal dispute settlement mechanisms are available.

3. Remove fuse carefully. Use a small tool to pry the end This limited warranty is given in lieu of all other warranties.

of the fuse from holder cavity. Be careful not to break

glass window. Manufactured for:

4. Replace fuse. Mr. Brands LLC

WARNING: Risk of fire. Replace fuse only with identical 113 Fillmore St

2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure Bristol, PA 19007

fuse is properly seated within its cavity. 1-877-420-7555

5. Close fuse cover by sliding it back to its original closed www.mrbrands.com

position. www.comfortzoneproducts.com

Fig 4 Fig 2 Fig $ Loss

Slide Cover to Open Cancer and Reproductive Harm

- jf Ny =r pp | je

= Rev. 07/20/28