Comfort Zone Oscillating Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ50

Original source file(s): CZ50, CZ50BK.Instruction Manual.01.pdf; 125101.Instruction Manual.01.pdf; 125111.Instruction Manual.01.pdf

Source SHA-256: 4bd44f18cecece60bad221c80ae8bce70ff5b12848579d3f3c106434fc04ac37

Original PDF pages: 4 | Recovered reading units: 6

Source page 1 (embedded text)

210x295mm 2023.7.27

Source page 1 - OCR transcription (OCR)

210x295mm 2023.7.27

Model #CZ50

Oo) Comfort Zone. #CZ50BK

America’s Heating and Cooling Choice

-_~ C

SS

Se Cag,

eS

. . --

Oscillating ==SS=2

a ee

Heater ===>"

a ----

at

Features: . | on

eWide Oscillation oo Ed

eAdjustable Thermostat

eThree Settings:

High - 1500 watts (5120 BTUs)

Low - 750 watts

Fan Only

Top Mounted Control Panel

ePower Indicator Light

eSafety Overheat Protection

eSafety Tip-Over Switch

eStay Cool Body

eConvenient Carry Handle él)

°120V A.C. / 60Hz. 12.5A Ls

Intertek

Save These Instructions

Source page 2 - OCR transcription (OCR)

INTENDED USE: a . WARNING: SHOCK HAZARD

ws product is intended for indoor residential and office use only, Not Use your heater only in dry environments. This heater is not

or industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes locations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a outdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements.

damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

heat. DO NOT USE in areas where gasoline, paint or

IMPORTANT INSTRUCTIONS flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

¢ Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

¢ This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not insert or allow foreign objects to enter

heater. Keep combustible materials, such as furniture, pillows, any ventilation or exhaust opening as this may cause an

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) electric shock, fire, or damage the heater.

from the front of the heater-fan and keep them away from the sides

and rear. .

¢ Do not use heater unattended. Use of extreme caution is necessary WARNING:

when any heater is used by or near children, invalids, disabled ELECTRICAL SHOCK HAZARD

persons or pets. Do not use with damaged cord or plug. Use with adequate

¢ Do not operate the heater with a damaged power cord or after the electrical system that is up to code.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical The supply cord has a polarized plug. As a safety feature this

or mechanical adjustment or repair. plug will fit in a polarized outlet only one way. To prevent

¢ Do not use heater outdoors. electric shock, match wide blade of plug to wide slot, fully

e Use your heater only in dry environments. This heater is not intended insert plug. If the plug does not fit contact a qualified

for use in a bathroom, laundry area, or similar locations, or near electrician.

sinks, washing machines, swimming pools or other sources of water.

Never locate heater where it may fall into a bathtub or other water Do not operate any heater with a damaged cord or plug or

container. Do not use in damp environments such as flooded after heater malfunctions, has been dropped or damaged in

basements. any manner. Do not operate heater with a broken heating

¢ Do not place the heater on a small, unlevel, uneven or any surface element or ceramic cone or any visual imperfections. For

which might allow heater to tip or fall. repairs covered under warranty, see warranty statement. For all

e For proper operation, heater should be placed on a smooth, other repairs contact Comfort Zone® Customer Service by

non-combustible surface. Do not place on rugs, carpet, vinyl flooring telephone or mail for information and assistance.

or other plastic surfaces. Not for use outdoors or in wet areas.

e This heater is not designed as a primary heat source. .

e Always plug heaters directly into a wall outlet/receptacle. Never use PET OWNERS NOTE: i |

with an extension cord or relocatable power tap (outlet/power strip). e health of birds and some small pets are extremely

Always unplug heater when not in use. sensitive to the fumes given off during the initial use of many

* Do not run power cord under carpeting. Do not cover cord with appliances. Although these fumes are not harmful to humans, it

throw rugs, runners or similar coverings. Arrange cord away from is recommended that this heater not be used around birds and
traffic area where it will not be tripped over. small pets during its initial use until the manufacturing

* To disconnect heater, turn controls off then remove plug from outlet. corrosion coatings burn off.

¢ Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.

¢ To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may become blocked.

e A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.

e Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

Source page 3 - OCR transcription (OCR)

USAGE:

HEATER OPERATION: Always operate the heater in the upright position following all instructions and recommendations listed in this manual.
HEATER LOCATION: Place the heater in the area of the room that is coldest.
HEATER CONNECTION: Plug heater directly into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or heater. NOTE: To prevent overloading a circuit, do not plug the heater into a circuit that is servicing other electrical needs. Make sure heater is at least three (3) feet away from walls, furniture, and other obstacles.
TURNING HEATER ON: To start the heater, turn the On/Off Power Level Control from the OFF position to the LOW or HIGH setting. Then rotate the Thermostat Control clockwise to the HIGH THERMOSTAT position as described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element lubrication “burning off’. This is normal and will go away after a few minutes of use.)
TURNING HEATER OFF: To discontinue use, turn the Power Switch to the OFF position. Always turn the heater OFF before unplugging or plugging in the heater.
HEATER LOCATION: Place the heater in the area of the room that is coldest.
HEATER CONNECTION: Plug heater directly into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or heater. NOTE: To prevent overloading a circuit, do not plug the heater into a circuit that is servicing other electrical needs. Make sure heater is at least three (3) feet away from walls, furniture, and other obstacles.
OSCILLATION CONTROL: You can control the Oscillation feature on the Heater/Fan by moving the Oscillation Control switch located on the control panel to the OSC position or the OFF position.
TO OPERATE FAN ONLY: Turn the On/Off Power Level Control dial to the Fan setting. Turn thermostat fully clockwise so the fan will run continuously. Oscillation will function while in fan mode.
IMPORTANT SAFETY FEATURES
The power indicator light, located above the control panel, lights whenever the heater/fan is plugged in to power. The heater is equipped with an automatic overheat protection device located inside the body of the heater. If the heater grill is obstructed, or if the heater gets too hot

Power Indicator . .
a4 Light for any reason, the automatic overheat protection
e device will turn the heater off. To reset the heater,
© G simply turn power off and unplug the heater for 10
VS) tee minutes until it cools down and you may plug the
Thermostat _--” - gn/Oft heater in and restart the heater. Be sure that the
Control === Level heater is on a smooth level surface with no
--- Control obstructions. The heater is also equipped with a
=== safety tip-over switch to turn power off to the heater
-_-__-_- when the heater tips over. To resume heater functions
---- i i ith ti i
fF simply stand heater upright. With tip over protection,
--- the heater will only operate when placed upright on a
=S=" level surface
ES
« f~--___ Oscillation CARE AND MAINTENANCE
Control CLEANING: CAUTION-Before cleaning the heater be
POWER LEVEL SWITCH: This heater has two heat sure to disconnect power cord and allow the heater to
settings: High and Low. Use the higher setting (1500 cool completely. Clean the outside surface with a
watt) to raise the room temperature quickly. When the clean damp cloth. Do not use harsh chemical or
desired temperature is reached use the Low setting abrasive cleaners. DO NOT IMMERSE THE HEATER
(750 watt). It is usually sufficient to maintain a IN WATER. Allow heater to dry completely before use.
comfortable temperature.

REPAIR: DO NOT OPERATE THE HEATER WITHOUT

SETTING THERMOSTAT: After heater has been turned THE GRILL IN PLACE. DO NOT USE THE HEATER IF
on and the room has reached the desired temperature, IT HAS MALFUNCTIONED OR BECOME DAMAGED
slowly rotate the Thermostat Control IN ANY WAY.
counter-clockwise until the heater shuts off (you should
hear a faint “click”). By leaving the thermostat at this STORAGE: Keep original carton for storage of the
setting it will automatically maintain this temperature. heater. Coil and tie the power cord to avoid damage
To lower temperature, rotate the knob further during storage.
counter-clockwise (towards the LOW position). To
raise the temperature, rotate the Thermostat Control
clockwise (towards the HIGH position).

Source page 4 (embedded text)

07/20/23

Source page 4 - OCR transcription (OCR)

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a
period of one year from the date of original purchase. If this unit fails because of a manufacturing

defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev. 07/20/23