Comfort Zone Compact Ceramic Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ442E

Original source file(s): 120117.Instruction Manual.01_compressed.pdf

Source SHA-256: 9c9f8d92df3ffca99b368b854b43105846265145d707a9dea94d31134f160ace

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

442E Series

10/20/23

Source page 1 - Panel 1 (top left) (OCR)

Reading orientation normalized by 180 degrees.

7 J SMOYS JepsOg YIe|q |

| 6d

suoyonasuj asoyzenes = SILA OSL G ‘WG'Zk “'ZHO9 ““O'V AOI

a1191u| gjpueH AeD JUSIUSAUOZD e

sn fie YOUMS J@AQ-dI | Ajayes e

aI> UOND9}OJg JEAUIOAC Ajayes e

1YBI7q JO}VEDIPU| JOMOd e

Joued JOJJUOD psjunoy| do] e

Buimas Ajud ue e

(MOSZ) MO7

(MOOSL) YSIH

spor aves Abieug

‘SBUINDS JeEOH DOU e

ye1ISOWWSeY| sjqeisnipy e

:soinjeo4

Hulpudsq wered

‘yeay yBiy uo Jayeay aoeds

eg JEM 00S‘ |. B 0} paredwog :9}0N,

eS ee 2 j,deyeey puepuels e Ue} ABJeue sso}

Pe2esc2o %0¢ BHBulsn Hulyeay ajqeyJo}WWOd

Peo ee sapiaoid Bunjas yeoy ones

Beez ee ees A®sauz ay S}s0o Hulyeay Jno;

Pie seonpas pue ABiaua anes sdjay

: i : = Sey ABojouyoe! anes Abseuy

ee ADOTONHOSL

ee 009) &) MWS

. aaI0yy Buljooy pue buljeay s,eouewy

S8W8S AZPyZO ‘ON [Epo ‘QUOT 140 LUO") C)

| (48A09) | a6eg |

Source page 1 - Panel 2 (top right) (OCR)

Page 2 (inside) |

INTENDED USE: - . WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not Use your heater only in dry environments. This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes locations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a outdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements

damage, injury or even death may result if not adhered to. ,

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” io indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could resutt in WAIRNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

heat. DO NOT USE in areas where gasoline, paint or

IMPORTANT INSTRUCTIONS flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be ‘materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

¢ Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

© This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not insert or allow foreign objects to enter

heater. Keep combustible materials, such as furniture, pillows, any ventilation or exhaust opening as this may cause an

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) electric shock, fire, or damage the heater.

from the front of the heater-fan and keep them away from the sides

and rear. .

* Do not use heater unattended. Use of extreme caution is necessary WARNING:

when any heater is used by or near children, invalids, disabled ELECTRICAL SHOCK HAZARD

persons or pets. Do not use with damaged cord or plug. Use with adequate

¢ Do not operate the heater with a damaged power cord or after the electrical system that is up to code.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical The supply cord has a polarized plug. As a safety feature this

or mechanical adjustment or repair. plug will fit in a polarized outlet only one way. To prevent

¢ Do not use heater outdoors. electric shock, match wide blade of plug to wide slot, fully

e Use your heater only in dry environments. This heater is not intended insert plug. If the plug does not fit contact a qualified

for use in a bathroom, laundry area, or similar locations, or near electrician.

sinks, washing machines, swimming pools or other sources of water.

Never locate heater where it may fall into a bathtub or other water Do not operate any heater with a damaged cord or plug or after

container. Do not use in damp environments such as flooded heater malfunctions, has been dropped or damaged in any

basements. manner. Do not operate heater with a broken heating element

¢ Do not place the heater on a small, unlevel, uneven or any surface or ceramic cone or any visual imperfections. For repairs

which might allow heater to tip or fall. covered under warranty, see warranty statement. For all other

e For proper operation, heater should be placed on a smooth, repairs contact Comfort Zone® Customer Service by telephone

non-combustible surface. Do not place on rugs, carpet, vinyl flooring or mail for information and assistance.

or other plastic surfaces. Not for use outdoors or in wet areas.

e This heater is not designed as a primary heat source. .

e Always plug heaters directly into a wall outlet/receptacle. Never use PET OWNERS NOTE: a

with an extension cord or relocatable power tap (outlet/power strip). The health of birds and some small pets are extremely sensitive

Always unplug heater when not in use. to the fumes given off during the initial use of many appliances.

F F Although these fumes are not harmful to humans, it is

e Do not run power cord under carpeting. Do not cover cord with g . aa

throw rugs, runners or similar coverings. Arrange cord away from recommended that this heater not be used around birds and

traffic area where it will not be tripped over. small pets during its initial use until the manufacturing corrosion

¢ To disconnect heater, turn controls off then remove plug from outlet. coatings burn off.

¢ Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.

¢ To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may become blocked.

e A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.

e Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

Pg. 2

Black border shows /

Source page 1 - Panel 3 (bottom left) (OCR)

. . page size and should

Page 3 (inside) rw

USAGE: TO OPERATE FAN ONLY: Turn the On/Off Power

HEATER OPERATION: Always operate the heater in Level Control dial to the Fan setting. Turn thermostat the upright position following all instructions and fully clockwise so the fan will run continuously. recommendations listed in this manual HEATER

LOCATION: Place the heater in the area of the room that IMPORTANT SAFETY FEATURES is coldest. HEATER CONNECTION: Plug heater directly The power indicator light, located near the control into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits panel, lights whenever the heater or fan is turned on. tightly in outlet. A loose connection may cause The heater is equipped with an automatic overheat overheating and damage to the plug or heater. NOTE: protection device located inside the body of the heater. To prevent overloading a circuit, do not plug the heater If the heater grille is obstructed, or if the heater gets into a circuit that is servicing other electrical needs. too hot for any reason, the automatic overheat protection device will turn the heater off. To reset the

POWER INDICATOR: When the unit is turned on, the heater, simply turn power off and unplug the heater for power indicator light will illuminate to tell you the 10 minutes until it cools down and then you may plug

heater is functioning. the heater in and restart. Be sure that the heater is ona
smooth level surface with no obstructions. The heater
TURNING HEATER ON: To start the heater, turn the is also equipped with a safety tip-over switch to turn
Power Control dial from OFF position to FAN, LOW, power off to the heater when the heater tips over. To
HIGH, or ENERGY SAVE setting. Then rotate the resume heater functions simply stand heater upright.
Thermostat Control clockwise to the HIGH
THERMOSTAT position as described below. (During CARE AND MAINTENANCE
the heaters initial use, you may experience a slight WARNING: ALWAYS UNPLUG THE CORD BEFORE
odor or smoking. This is the result of the heating MOVING OR SERVING. DO NOT. IMMERSE
element lubrication “burning off”. This is normal and HEATER/FAN IN WATER!
will go away after a few minutes of use.)

CLEANING: IMPORTANT! DO NOT IMMERSE

CONTROL PANEL HEATER/FAN IN WATER! Clean the Heater/fan grille
Power with the vacuum brush attachment on your vacuum
Indicator cleaner. This will remove lint and dirt from inside the
heater/fan. DO NOT ATTEMPT TO TAKE APART THE

On/Off HEATER/FAN. DO NOT REMOVE THE HEATER/FAN

Thermostat ower GRILLE. Clean the body of the Heater/fan with a soft
Control cloth.
POWER LEVEL SWITCH: This heater has 3 heat CAUTION: Do not use gasoline, benzene, paint
heat Satting that best meets your heating nests The thinner, harsh cleaners, etc. as they will damage the
ENERGY SAVE heat setting provides comfortable heater/fan. NEVER USE ALCOHOL OR SOLVENTS.
heating in most rooms, while saving you money on REPAIR:
energy costs. .

DO NOT OPERATE THE HEATER WITHOUT THE

SETTING THERMOSTAT: After heater has been turned GRILLE IN PLACE. DO NOT USE THE HEATER IF IT
on and the room has reached the desired temperature, HAS MALFUNCTIONED OR BECOME DAMAGED IN
slowly rotate the thermostat knob counter-clockwise ANY WAY.
until the heater shuts off (you should hear a faint ,
“click”). By leaving the thermostat at this setting it will STORAGE: Keep original carton for storage of the
automatically maintain this temperature. To lower the heater. Coil and tie the power cord to avoid damage
temperature, rotate the knob further counter-clockwise during storage.
(towards the LOW position). To raise the temperature,
rotate the thermostat knob clockwise (towards the
HIGH position).
TURNING OFF: Turn the center dial to the OFF
position before unplugging or plugging in the heater.
Heater should be unplugged when not in use.
Pg. 3

Source page 1 - Panel 4 (bottom right) (OCR)

Page size and should
Page 4 (back) not it \

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC
113 Fillmore St
Bristol, PA 19007 1
1-877-420-7555 11.0
www.mrbrands.com
www.comfortzoneproducts.com
L\ sasunes
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov
Rev. 10/20/23
Pg. 4
Yt > |