Comfort Zone 40-inch Digital Tower Fan with Remote Control

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12394

Original source file(s): CZ12394.pdf

Source SHA-256: 99d6a933a3d8e2adbfe6516a6b38bd45861e45384942a67da09fbd4dbbbcfa9c

Original PDF pages: 7 | Recovered reading units: 7

Source page 1 - OCR transcription (OCR)

O Comfort Zone. Owner’s Manual

www.comfortzoneproducts.com Please Save These Instructions

40" Digital Tower Fan

with Remote Control

=

! "s

HII © @

WH

Rave Features:

Tyre * Digital Control Panel for

44 Easy Operation

* Remote Control Function

* 4 Modes Selection,Regular,

Sleep,Breeze,Power Breeze

¢ Up to 15 Hours and Auto

Shut-off Timer

* Wide Angle Oscillation

intertek

CZ12394-EC

Source page 2 - OCR transcription (OCR)

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, | Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with | for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances, If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result | _use, to avoid bums, do not let bare skin touch hot surfaces.

in injury or death.

IMPORTANT INSTRUCTIONS Se ar

Fans have arcing or sparking parts inside. Do not use near

As with all electrical appliances, basic safety precautions should | combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

- block air intakes or exhaust in any manner. Do not insert or allow

* Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

* Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

* Do not operate the fan with a damaged power cord or after the Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

* Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

* Do not place the fan on a small, unlevel, uneven or any surface | other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

+ For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

* Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

toplace, when assembling or disassembling parts, and before to Reduce the Risk of Fire or Electric

* The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

manufacturer, may cause hazards. control device.

+ Do not use outdoors. - DO NOT operate any fan with a damaged cord or plug or after

* Do not use fan in window. Rain may cause electrical hazard fan maifunctions, has been dropped or damaged in any manner.

(for non-window models). Do not operate fan with a broken blade, safety cage or any visual

* Do not operate the fan with blade guards or any safety device | imperfections. Disconnect power before servicing.

removed.

* Avoid the use of extension cords due to risk of fire. If an DO NOT run power cord under carpeting. DO NOT cover cord

extension cord must be used, the cord must be minimum ,

PT AWG ond rated not joes then 1875 watts, with throw rugs, runners or the like. Arrange cord away from

p traffic area where it will not be tripped over. Avoid the use of

* Do not run power cord under carpeting, Do not cover cord wth | etansion cords due 1 sk offre, If an extension cord must

98, runners or fhe like. Arrange cord away from traffic be used, the cord must be minimum 14 AWG and rated not

area where it will not be tripped over.

; less then 1875 watts. Do not use an extension cord unless the

* Do not insert or allow any object to enter any openings onthe | jug can be completely inserted into its receptacle. Unplug

fan. Doing so may cause electric shock and/or fire hazard. the fan when not in use. Do not operate fan with its ventilation

Avoid contact with moving parts. obstructed,

* This appliance is not intended for use by persons (including

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

6) www.comfortzoneproducts.com

Figure 1 OPERATING INSTRUCTIONS (Figure 3)

c KSEX, 1. Plug the cord into a standard 120 Volt AC outlet.

fo CARS 2. To turn the fan ON, press the POWER button (A) located on

<< (TR the control panel or remote control. The fan will start running in

Cc ms, nd we the lowest setting "I"(LOW).

-- vans

4 LEE Figure 3

ig

V3 ~\ Lock Nut f \

(@\-O oan nnn -Neen

at / $ ¢ wn F

E-f- © @-

* 1

Figure 2 if i

SS ')

rom) (\ ® © S) VA y

t /

\ y,

il = aa ~

It SER c aA SB

COLES

nm [PRN A. Power Button

ri ROR T AO © 8. Oscillation

rants, ! C. Speed Button

IT ROSY? E OTB D. Mode Button

TTI E. Timer Button

Hi D7 © F. Speed Setting Indicator Lights

Ht G. Timer Indicator Lights

Hl H. Mode Indicator Lights

y 3. Press the SPEED button (C) to cycle through the 3 speed

= settings in sequence.

(C ‘) The corresponding indicator light will illuminate to confirm the

/) selection

T J.-Low +-Medium #-High

ck Nut 4, To tu OSCILLATION ON and OFF, press the Oscillation (8)

button.

| 5. To set automatic shutoff, press the TIMER button (E). When

set, the fan will run and automatically shut off after the set

| duration of time (1-15 hours) has expired.

1 alien Note: To set the timer for 15 hours, press the timer button until

SS all four lights (1H, 2H, 4H, 8H) are illuminated.

6. To activate SLEEP mode, press the MODE button (0). This

ASSEMBLY function circulates the speed from High, Medium to Low.

NOTE:MAKE SURE YOU REMOVE ALL CONTENTS FROM

THE PACKAGE.PLEASE CHECK PACKAGING MATERIALS FOR

PARTS THAT COULD BE REQUIRED TO REMOTE CONTROL

OPERATE YOUR FAN NOTE: THIS UNIT INCLUDES ONE LITHIUM BATTERY,

1. Align and press together the base halves (figure 1). Cee ee PENIOTE CONTaOL barreuy eetone

2. Remove the lock nut from the fan housing by rotating OPERATION.

counterclockwise (Figure 1,2). 5 : . a

3. Place the base onto the bottom of the fan housing and rotate © operate the fan with the remote control,aim it towards the

tocenure control panel on top of the fan tower. The remote control can

1. Diece the lock nut onto the bottom of the base and rotate operate from a distance up to approximately 16 feet from the fan

Clockwise to tighten (Figura 2) body and at an angle variation of 15-20 degrees.

5. Place fan upright one cy, level surface Avoid exposing the display panel to direct sunlight, as it may

7 : 7 interfere with signal transmission.

Source page 4 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

Replacing the Remote Control Battery (Figure 4)

The cells should be disposed of properly, including keeping them

away from children. Even used cells may cause injury.

1. Locate the battery compartment on the back of the remote

control handset. Press tab and pull out battery.

2. Remove old battery.
battery compartment. Figure 4
3. Place new battery into
battery compartment. CR2025
4, Slide battery FO ih\=
compartment into the G) OPEN
remote control handset. &
NOTES: T puss
1. Remove the battery
from the remote when it
is not in use for an
extended period.
2. Remove the battery
pefore discarding the remote at the end of its useful product life.
3. Do not discard used batteries into household trash
containers. Contact your local government for disposal or
recycling practices in your area.
Note: Some models come with a plug where you can replace
a fuse. If your model has this, please read and follow the below
instructions to replace the fuse.
This product employs overload protection (fuse). A blown fuse
indicates an overload or short-circuit situation. If the fuse blows,
unplug the product from the outlet. Replace the fuse as per the
user servicing instructions (follow product marking for proper
fuse rating) and check the product. If the replacement fuse
blows, a short-circuit may be present and the product should
be discarded or returned to an authorized service facility for
examination and/or repair.
Fuse Replacement:
1. Grasp plug and remove from the receptacle or other
outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on
top of attachment plug towards blades. See Fig. 2
3. Remove fuse carefully. Use a small tool to pry the end
of the fuse from holder cavity. Be careful not to break
glass window.
4, Replace fuse.

WARNING: Risk of fire. Replace fuse only with identical

5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is
properly seated within its cavity.
5. Close fuse cover by sliding it back to its original closed
position.

Fig 1 Fig 2 Fig 3

ey (nee | = |p| | tee

= i | _|<- 4 =

Slide Cover to Open ss

Source page 5 - OCR transcription (OCR)

O Comfort Zone.

www.comfortzoneproducts.com

WARNING: a) Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from

children. Do NOT dispose of batteries in household trash or incinerate.

b) Even used batteries may cause severe injury or death.

c) Call a local poison control center for treatment information.

d) Always use the same size and grade battery as CR2025 for this product.

e) Always us a voltage 3V battery for this product.

f) Non-rechargeable batteries are not to be recharged.

g) Do not force discharge, recharge, disassemble, heat above 104°F or incinerate. Doing so may result in injury due to venting,

leakage or explosion resulting in chemical burns.

h) Ensure the batteries are installed correctly according to polarity (+ and -).

i) Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.

j) Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to

local regulations.

k) Always completely secure the battery compartment.

If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from

children.

¢ INGESTION HAZARD: This product contains a button cell or coin battery.

¢ DEATH or serious injury can occur if ingested.

¢ A swallowed button cell or coin battery can cause Internal

Chemical Burns in as little as 2 hours. =)

KEEP new and used batteries OUT OF REACH of CHILDREN CR2025/3V

* Seek immediate medical attention if a battery is suspected to be

swallowed or inserted inside any part of the body.

Source page 6 - OCR transcription (OCR)

O Comfort Zone

Limited Warranty

This unit is guaranteed to the original retail purchaser

against defects in quality or workmanship for a period of

one year from the date of original purchase. If this unit

fails because of a manufacturing defect within 30 days of

purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied **warranty lasts, so the above limitations may not apply to** you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**

Mr. Brands LLC
1414 Radcliffe St Suit 105
Bristol, PA 19007
1-877-420-7555
www.mrbrands.com
www.comfortzoneproducts.com
Cancer and Reproductive Harm ~

www.P65Warnings.ca.gov
Rev. 07/08/24

Source page 7 - OCR transcription (OCR)

C) Comfort Zone.
America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

[=] uo [a]

a Weel vee

ere

ne acneahyek

paired

ol Rie oy--- os

SCAN HERE