Comfort Zone 12-inch Table Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123707

Original source file(s): 123707&123718.pdf

Source SHA-256: f923b4a0c07d7c01e11b6ad7b707e6f3084bbf9ccb72214d2529886e40af5af8

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

O America’s Heating and Cooling Choice : CZ121 Series

got tgaeeenreattgg, ps

Kai,

-_- _-- --

a en ett

t= EB Z, =

es aN is

ile FF UMNIN eS

CATT

aE

ad

" Table F

12" Table Fan

Features:

e Wide Area Oscillation

© Push Button ON/OFF Switches with

3 Speed Settings

¢ High Performance Fan Blade

© Adjustable Tilt

© Safety Grilles

@ 120V A.C. / 6OHz.

www.comfortzoneproducts.com Save These Instructions

Source page 2 - OCR transcription (OCR)

O www.comfortzoneproducts.com »

Tie podtice oor ded for indoor residential and office use only, READ & SAVE THESE

not for industrial or other commercial applications. Use only with | N STR U CTI ONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

- ' combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface CAUTION: TO PREVENT ELECTRIC SHOCK

which might allow fan to tip or fall. : a

* For proper operation, fan should be placed on a smooth, this product has a polarized two prong plug (one blade is wider

non-combustible, level surface. than the other) that must be fully inserted in to a matching

+ Always unplug fan when not in use, when moving from place properly grounded outlet. This plug is designed to fit a polarized

to place, when assembling or disassembling parts, and before outlet only one way. If the plug does not fit fully into the outlet,

cleaning. reverse the plug. If the plug still does not fit, contact a qualified

« The use of attachments, not recommended or sold by the electrician. Do not attempt to defeat this safety feature

ifactt hi ‘ds.

Or netaee te ee nears WARNING: TO REDUCE THE RISK OF FIRE OR

© NOE USE OUICOOTS. - - ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing. For repairs

14 AWG and rated not less then 1875 watts. covered under warranty, see warranty statement. For all other

* Do not run power cord under carpeting. Do not cover cord with repairs contact Comfort Zone® Customer Service by telephone or

throw rugs, runners or the like. Arrange cord away from traffic mail for information and assistance.

area where it will not be tripped over.

* Do not insert or allow any object to enter any openings on the DO NOT run power cord under carpeting. DO NOT cover cord

fan. Doing so may cause electric shock and/or fire hazard. with throw rugs, runners or the like. Arrange cord away from

Avoid contact with moving parts. traffic area where it will not be tripped over. Avoid the use of

© This appliance is not intended for use by persons (including extension cords due to risk of fire. If an extension cord must

children) with reduced physical, sensory or mental capabilities pe used, the cord rust be minimum 14 AWG and rated not ‘

or lack of experience and knowledge, unless they have less then watts. Do not use an extension cord unless the

been given supervision or instruction concerning use of the plug can be completely inserted into its receptacle. Unplug

appliance by a person responsible for their safety. the fan when not in use. Do not operate fan with its ventilation

* Children should be supervised to ensure they do not play with obstructed.

the appliance.

Source page 3 - OCR transcription (OCR)

6) www.comfortzoneproducts.com -

USAGE: Step 3 Step 4

Fan Operation: Always operate the fan in the upright position r"

following all instructions and recommendations listed in this sen 45 WY.
manual. wy aay & | iy LZ
Fan Location: Place the fan in the area of the room that will ~~ @ P % PB
provide proper fan cooling. AN @) % al
Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall i .S G (as) =
outlet. Be sure plug fits tightly in outlet. A loose connection may r LLY Fe =
cause overheating and damage to the plug or fan. a o <> S$
Note: To prevent overloading a circuit, do not plug the fan into 7 t K SS
ircuit that is servicing other electrical needs Remove the Blade Cap by twisting Z _ SS
a circu 7 it CLOCKWISE while holding the VA, WO
metal shaft tightly. = _
CONTROL PANEL Note: Threads are reversed, Assemble Rear Grile onto Motor
Unscrew = Clockwise. Housing. Rear Grille should fit
Py 7 into alignment pins on fan motor
y =f housing as shown.
3 Note: Wire Handle should be on
} top.
- yp | Stews step 6
a AS
Nid Zi WW | JA
On/Off Speed Control Oscillation Control Knob ! ZZ} A
SAahites |
Turnit : SJ ee
ming Fan On/Off: Place fan on stable level surface. Plug s “44 | x @
fan into properly grounded outlet. To start the fan, press i -
desired speed button: 1-LOW, 2-MED, 3-HIGH. Press 0-OFF I oa Ss " Ss =|
to discontinue use. Unplug fan when not in use. (Cone IS
“lation: oe aati : = SS
Oscillation: To start fan oscillation, press Oscillation Control \ ~~] Remove any protective covering
Knob (located above motor housing) down.To stop oscillation ‘ \\ ‘ cover shaft before fan blade
function pull Oscillation Control Knob up while the fan is in any t \ \\ installation, Place fan blade
oscillation position. ce mi \ =| onto motor shaft. Notice the pin
Thread Locknut onto Motor ‘on motor shaft should fit into
. Housing to lock Rear Grille in slots of fan blade.
Fan Assembly: place. Tighten=Clockwise,

Assembly is required to use this fan.

Step1 Step 2 Step 7 Step 8
SS ire Goes’ P | ,
=> hrough \ te +
Opening - ¥) i,
(tery and Guide _ ° Al A |
in |

Remove two (2) screws from base _ Place power cord wire through Thread blade cap onto threaded With logo upright, attach Front

of fan and save them for Step #2. opening of plastic fan base. With end of the motor shaft. Note: Grille to Rear Grille by snapping

cord opening properly positioned, Threads are reversed at this them together. Be sure all 8 clips

snap plastic fan base onto fan connection. are secure. Do not operate fan

body. Re-assemble screws Tighten=Counter-clockwise without grille in place.

removed in Step #1.

Source page 4 - OCR transcription (OCR)

6) www.comfortzoneproducts.com ~

Care and Maintenance: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a

with a clean damp cloth. Do not use harsh chemical or abrasive ; ‘i

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN period of one year from the date of original purchase.

WATER. Replace front grille before fan use. Allow fan to dry If this unit fails because of a manufacturing defect

completely before use. Periodic grille cleaning with a vacuum will | within 30 days of purchase, return the unit, with your

prevent dust build up. The motor is sealed and does not require receipt, to the retailer. After 30 days, but within the

any interior maintenance, cleaning or lubrication. warranty period, if the unit was purchased within the

Maintenance: The Internal motor bearings are permanently continental United States, return it, to Mr. Brands

lubricated at the factory and do not require any additional LLC for repair or replacement. If the unit was

lubrication. purchased outside the continental United States,

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN return the unit to the place of purchase. This

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | warranty does not cover damage caused by misuse,

BECOME DAMAGED IN ANY WAY. abuse, overheating or alteration. Repairs made by

Storage: Keep original carton for storage of the fan. Coil and tie anyone other than Mr. Brands LLC are not covered in

the power cord to avoid damage during storage. this warranty. Mr. Brands LLC will not be held liable

| for any losses due to neglectful operation. All implied

Note: Some models come with a plug where you can replace a warranties, including the warranties of

fuse. If your model has this, please read and follow the below merchantability and of fitness of purpose, if

instructions to replace the fuse. applicable, are hereby limited in duration to the

This product employs overload protection (fuse). A blown fuse period of one year from the date of original retail

indicates an overload or short-circuit situation. If the fuse blows, purchase. Some states do not allow limitations on

unplug the product from the outlet. Replace the fuse as per Pann

the user servicing instructions (follow product marking for proper | NOW long an implied warranty lasts, so the above

fuse rating) and check the product. If the replacement fuse limitations may not apply to you. Incidental or

blows, a short-circuit may be present and the product should consequential damages arising from a breach of

be discarded or returned to an authorized service facility for either express or implied warranties are hereby

examination and/or repair. disclaimed and excluded. Some states do not allow

Fuse Replacement: the exclusion of limitation of incidental or

1. Grasp plug and remove from the receptacle or other outlet consequential damages, so this limitation or device. Do not unplug by pulling on cord. exclusion may not apply to you. Upon the expiration
2. Open fuse cover by sliding open fuse access cover on top of of this warranty all such liability will terminate. No attachment plug towards blades. See Fig. 2. other warranties are expressed or implied.
3. Remove fuse carefully. Use a small tool to pry the end of the
fuse from holder cavity. Be careful not to break glass This warranty gives you specific legal rights, and you window. may also have other rights which vary from state to
4, Replace fuse. WARNING: Risk of fire. Replace fuse only with state. No informal dispute settlement mechanisms identical 5.0 ane. yee vet use Germ x 10mm). Be sure are available. This limited warranty is given in lieu of use is properly seated within its cavity. all other warranties.
5. Close fuse cover by sliding it back to its original closed
Position. Mr. Brands LLC
Fig 1 Fig 2 Fig 3 1414 Radcliffe St Suit 105
Bristol, PA 19007
a ys 1-877-420-7555
ye sl Sr iS | - 25) | www.mrbrands.com
- _-’ , “ www.comfortzoneproducts.com
‘Slide Cover to Open = support@mrbrands.com
L\ enne:
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov
Rev. 07/19/2023

Source page 5 - OCR transcription (OCR)

() Comfort Zone.
America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your
FREE Extended Warranty!
Oo el
: ee
Te “oO; foo
persia
ol cit Of... ra!

SCAN HERE