Comfort Zone 16-inch Oscillating Stand Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123714

Original source file(s): 123714&123724.pdf

Source SHA-256: 1364dc7038084ef7641dc7a21f476740d3c969605513800792019e9d6acbdac8

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

O) Comfort Zone.

America’s Heating and Cooling Choice CZST161BTE Series

Lm

/ ee)

iT} 1 1

16" Oscillating Stand Fan

Features:

¢ Patented Fast Assembly Quad-Pod® Folding Base

(US Pat. No D643230 and D646501)

e Wide Area Oscillation

© ON/OFF Switch with 3 Speed Settings

© High Performance Blades

e Adjustable Height and Vertical Tilt

® Steel Safety Grilles

© 120V A.C. / 60HZz.

www.comfortzoneproducts.com Save These Instructions

Source page 2 - OCR transcription (OCR)

Comfort Zone.

©) Comtort Zone

INTENDED USE: canta and ot READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with | N STR U CTI (e) N Ss

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word ""WARNING* to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

* Use this fan only as described in this manual. Any other use not | materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: TO PREVENT ELECTRIC SHOCK,

© For proper operation, fan should be placed on a smooth, this product has a polarized two prong plug (one blade is wider

non-combustible, level surface. than the other) that must be fully inserted in toa matching ;

+ Always unplug fan when not in use, when moving from place properly grounded outlet. This plug is designed to fit a polarized

to place, when assembling or disassembling parts, and before outlet only one way. If the plug does not fit fully into the outlet,

cleaning. reverse the plug. If the plug still does not fit, contact a qualified

* The use of attachments, not recommended or sold by the electrician. Do not attempt to defeat this safety feature.

. manufacturer may cause hazards. WARNING: TO REDUCE THE RISK OF FIRE OR

7 ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing. For repairs

14 AWG and rated not less then 1875 watts. covered under warranty, see warranty statement. For all other

* Do not run power cord under carpeting. Do not cover cord with repairs contact Comfort Zone® Customer Service by telephone or

throw rugs, runners or the like. Arrange cord away from traffic mail for information and assistance.

area where it will not be tripped over.

* Do not insert or allow any object to enter any openings on the DO NOT run power cord under carpeting. DO NOT cover cord

fan. Doing so may cause electric shock and/or fire hazard. with throw rugs, runners or the like. Arrange cord away from

Avoid contact with moving parts. traffic area where it will not be tripped over. Avoid the use of

© This appliance is not intended for use by persons (including extension cords due to risk of fire. If an extension cord must

children) with reduced physical, sensory or mental capabilities be used, the cord must be minimum 14 AWG and rated not

or lack of experience and knowledge, unless they have less then 1875 watts. Do not use an extension cord unless the

been given supervision or instruction concerning use of the plug can be completely inserted into its receptacle. Unplug

appliance by a person responsible for their safety. the fan when not in use. Do not operate fan with its ventilation

* Children should be supervised to ensure they do not play with obstructed.

the appliance.

Source page 3 - OCR transcription (OCR)

©) www.comfortzoneproducts.com .

USAGE: Step 4 Step 5

7

Fan Operation: Always operate the fan in the upright position (| | ot <a xv

following all instructions and recommendations listed in this = Sy 7

manual.),

Fan Location: Place the fan in the area of the room that will Thumb a4

provide proper fan cooling. Screw /

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall -- -
outlet. Be sure plug fits tightly in outlet. A loose connection may 3 -
cause overheating and damage to the plug or fan. Remove the Blade Cap by
Note: To prevent overloading a circuit, do not plug the fan into a ‘Assemble fan Control twisting it CLOCKWISE while
Circuit that is servicing other electrical needs. Panel/Motor assembly holding the metal shaft tightly.
co NTRO L PAN E L: onto Chrome Extension Note: Threads are reversed
" and tighten thumb screw. Unscrew = Clockwise.
Oscillation 4 Step 6 Step 7
On/Speed Control 7 3 Z 7 7
n/Spee Na pea mm

**Controls == ‘a wa <oP\ **

on bs ¥ SA% ws

Controls ll = Ve = z

/ 2 E03 s ~ AX
Em Zw Zp & ek Nat“
On/Off Speed Controls -_ Oscillation Control Knob Pin Z Pin, KS
Turning Fan On/Off: Place fan on stable level surface. Assemble Rear Grille Thread Locknut onto
‘onto Motor Housing. Motor Housing to lock
Plug fan into properly grounded outlet. To start the fan, Rear Grille should fit Rear Grille in place.
press desired speed button: 1-LOW, 2-MED, 3-HIGH. into pins on fan motor -
Press 0-OFF to discontinue use. Unplug fan when not in use housing ss shown
Oscillation: To start fan oscillation, press Oscillation Control
Knob (located above motor housing) down. To stop oscillation Step 8 Step 9
function, pull Oscillation Control Knob up while the fan is in any Fy
oscillation position. , Pin Slot Ry
y ‘S
Fan Assembly: A | a \ alg
Simple assembly is required to use this fan. ke ac - , \
Step 1 Step 2 Ww,
4 = yo
» . Remove any protective Thread Blade Cap onto
we ‘ya covering over shaft before threaded end of Motor Shaft.
A Fan Blade Installation. Place Note: Threads are reversed.
OS 4 v * Fan Blade onto Motor Shaft. Tighten = Counter-clockwise.
rw 3 | dain Notice the pin on Motor Shaft im
s . should fit into slots of Fan Le E>
Unfold patented Quad-Pod® Place decorative Plastic Flange Blade. fe ee
base legs. over Extension Pole to cover fom |
the base, Slide pedestal pole 1 K I
Step 3 into base receptacle. Tighten Step 10 Ye ay él
nut to secure in place. Slide Si
flange over base connection. E

Pull f thee

Chrome "1 aor.

Extension in, > ,

Out {] y

| y

. With logo upright, attach

' With collar nut loosened, i P

L pull Chrome Extension Front Grille to Rear Grille by

| out of Fan Pedestal. snapping them together. Be

| sure all 8 clips are secure.

Source page 4 - OCR transcription (OCR)

O www.comfortzoneproducts.com

Care and Maintenance LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

Gisconnect power cord from tne pig. Clean ire rile I against defects in quality or workmanship for a

surface with a clean damp cloth. Do not use harsh chemical ‘i ici

or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY period of one year from the date of original purchase.

WIRES IN WATER. Replace front grille before fan use. Allow f this unit fails because of a manufacturing defect

fan to dry completely before use. Periodic grille cleaning with within 30 days of purchase, return the unit, with your

a vacuum will prevent dust build up. The motor is sealed and receipt, to the retailer. After 30 days, but within the

does not require any interior maintenance, cleaning or warranty period, if the unit was purchased within the

lubrication. continental United States, return it, to Mr. Brands

Maintenance: The Internal motor bearings are permanently LLC for repair or replacement. If the unit was

lubricated at the factory and do not require any additional purchased outside the continental United States,

lubrication. return the unit to the place of purchase. This

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN | Warranty does not cover damage caused by misuse,

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | @buse, overheating or alteration. Repairs made by

BECOME DAMAGED IN ANY WAY. anyone other than Mr. Brands LLC are not covered in

: ; this warranty. Mr. Brands LLC will not be held liable

Storage: Keep original carton for storage of the fan. Coil and tie for any losses due to neglectful operation. All implied

© Power cord to avoid damage during storage. warranties, including the warranties of

a _|_ merchantability and Of fitness Of purpose, if

Note: Some models come with a plug where you can replace a applicable, are hereby limited in duration to the

fuse. If your model has this, please read and follow the below period of one year from the date of original retail

instructions to replace the fuse. purchase. Some states do not allow limitations on

This product employs overload protection (fuse). A blown fuse row long an implied warranty lasts, a ine above

indicates an overload or short-circuit situation. If the fuse blows, imitations may not apply 0 you. neidental or

unplug the product from the outlet. Replace the fuse as per consequential damages arising from a breach of

the user servicing instructions (follow product marking for either express or implied warranties are hereby

proper fuse rating) and check the product. If the replacement disclaimed and excluded. Some states do not allow

tise pows, a Short ciroult may be present and tne product ity the exclusion of limitation of incidental or
should be discarded or returned to an authorized service facili : errr
for examination and/or repair. consequential damages, so this limitation or _
exclusion may not apply to you. Upon the expiration
Fuse Replacement: of this warranty all such liability will terminate. No
1. Grasp plug and remove from the receptacle or other outlet other warranties are expressed or implied.
device. Do not unplug by pulling on cord. This warranty gives you specific legal rights, and you
2. Open fuse cover by sliding open fuse access cover on top of may also have other rights which vary from state to
attachment plug towards blades. See Fig. 2. state. No informal dispute settlement mechanisms
3. Remove fuse carefully. Use a small tool to pry the end of the are available. This limited warranty is given in lieu of
fuse from holder cavity. Be careful not to break glass all other warranties.
window. Mr. Brands LLC
4, Replace fuse. WARNING: Risk of fire. Replace fuse only with 1414 Radcliffe St Suit 105
identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Besure Bristol, PA 19007
fuse is properly seated within its cavity. 1-877-420-7555
5. Close fuse cover by sliding it back to its original closed www.mrbrands.com
Position. www.comfortzoneproducts.com
support@mrbrands.com
Fig 1 Fig 2 Fig 3 PPI
L\ noun
-- rrr lig - |r yp p Cancer and Reproductive Harm -
-_ A | ela www.P65Warnings.ca.gov
Slide Cover to Open Rev. 07/19/2023

Source page 5 - OCR transcription (OCR)

O Comfort Zone.
C) Comfort Zone.
America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your
FREE Extended Warranty!
io uae i [m]
a -h “I
ea tetee
T-] pico JE, oO 4
4 MAA
Oo fc pies re

SCAN HERE

$$?