Comfort Zone 8-inch High Velocity Turbo Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123715

Original source file(s): 123715.pdf

Source SHA-256: ce69759fb865aafcd34699adca1fa260f481f94c069f07baa3849b7243acd225

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

O) Comfort Zone.

America’s Heating and Cooling Choice CZHV8T Series

s= wo

Ze AS

sa | ge

/ UWS

: “NE = -

i

iT 1 1

8" High Velocity Turbo Fan

Features:

e ON/OFF Switch with 3 Speed Settings

e Adjustable Tilt

© Quiet Vibration-Free Performance

¢ Wall Mountable (Select models only)

¢ 120V A.C. / 60Hz

www.comfortzoneproducts.com Save These Instructions

Source page 2 - OCR transcription (OCR)

Comfort Zone.

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, INSTRUCTIONS !

not for industrial or other commercial applications. Use only with

electrical wiring that is in good working order and that meets WARNING: SHOCK HAZARD

applicable codes and ordinances. If you have any questions Use your fan only in dry environments. This fan is not intended

whether your wiring is adequate, consult a qualified electrician. for use in a bathroom, laundry area, or similar locations, or near

sinks, washing machines, swimming pools or other sources of

While using your fan, you should follow the IMPORTANT water. Never locate fan where it may fall into a bathtub or other

INSTRUCTIONS listed below. As part of those instructions, we water receptacle. Do not use in damp environments such as

have used the word "WARNING' to indicate the level of hazard: | flooded basements.

WARNING indicates a hazard which, if not avoided, could result

in injury or death. WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in

IMPORTANT INSTRUCTIONS: use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

As with all electrical appliances, basic safety precautions should Fans have arcing or sparking parts inside. Do not use near

always be followed to reduce the risk of electric shock, fire, or combustible materials or flammable gases or sources of heat. Do

injury to persons, including the following precautions: not use in areas where gasoline, paint or flammable materials are

* Read all the instructions before using this fan. used or stored. To prevent a possible fire, do not block air intakes

* Use this fan only as described in this manual. Any other use not | °F exhaust in any manner. Do not insert or allow foreign objects

recommended by the manufacturer may cause electrical shock, | © enter any ventilation or exhaust opening as this may cause an

fire or injury to persons. electric shock, fire, or damage the fan.

* Do not operate the fan with a damaged power cord or after the WARNING: ELECTRICAL SHOCK HAZARD

fan malfunctions or has been dropped in any manner. De F i

0 not use with damaged cord or plug. Use with adequate

* Use of extreme caution is necessary when any fan is used by or | electrical system that is up to code.

near children, disabled persons or pets and whenever the fan is

left operating unattended. CAUTION: TO PREVENT ELECTRIC SHOCK,

* Do not place the fan on a small, unlevel, uneven or any surface this product has a polarized two prong plug (one blade is wider

which might allow fan to tip or fall. than the other) that must be fully inserted in to a matching

© For proper operation, fan should be placed on a smooth, properly grounded outlet. This plug is designed to fit a polarized

non-combustible, level surface. outlet only one way. If the plug does not fit fully into the outlet,

* Always unplug fan when not in use, when moving from place reverse the plug. If the plug still does not fit, contact a qualified

to place, when assembling or disassembling parts, and before electrician. Do not attempt to defeat this safety feature.

cleaning.

«Th se of attachments, not recommended orsoldby the | GAUTION: TO REDUCE THE RISK OF FIRE OR
manufacturer, may cause hazards. ECTRIC SHOCK, do not use this product with any
solid-state speed control device.

* Do not use outdoors.

* Do not use fan in window. Rain may cause electrical hazard DO NOT operate any fan with a damaged cord or plug or after
(for non-window models). fan malfunctions, has been dropped or damaged in any manner.

* Do not operate the fan with blade guards or any safety device Do not operate fan with a broken blade, safety cage or any visual
removed. imperfections. Disconnect power before servicing. For repairs

* Avoid the use of extension cords due to risk of fire. If an covered under warranty, see warranty statement. For all other
extension cord must be used, the cord must be minimum repairs contact Comfort Zone® Customer Service by telephone or
14 AWG and rated not less then 1875 watts. mail for information and assistance.

* Do not run power cord under carpeting. Do not cover cord with ;
throw rugs, runners or the like. Arrange cord away from traffic DO NOT run power cord under carpeting. Do not cover cord
area where it will not be tripped over. with throw rugs, runners or the like. Arrange cord away from

* Do not insert or allow any object to enter any openings on the | traffic area where it will not be tripped over. Avoid the use of
fan. Doing so may cause electric shock and/or fire hazard. extension cords due to risk of fire. If an extension cord must
Avoid contact with moving parts. be used, the cord must be minimum 14 AWG and rated not

* This appliance is not intended for use by persons (including less then 1875 watts. Do Not use an extension cord unless the
children) with reduced physical, sensory or mental capabilities plug can be completely inserted into its receptacle. Unplug
or lack of experience and knowledge, unless they have the fan when not in use. Do not operate fan with its ventilation
been given supervision or instruction concerning use of the obstructed.
appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with
the appliance.

Source page 3 - OCR transcription (OCR)

‘6)) www.comfortzoneproducts.com |

USAGE: ‘

Fan Operation: Always operate the fan in the upright position fs
following all instructions and recommendations listed in this Vex 2 7
manual. Ava ar ay ay

Fan Location: Place the fan in the area of the room that will Vai LT
provide proper fan cooling. a ne

Z-3\, |

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz ~ »\), \ |

wall outlet. Be sure plug fits tightly in outlet. A loose connection ia * WY) \)

7 ZA)

may cause overheating and damage to the plug or fan. (A p

WW W Z

Note: To prevent overloading a circuit, do not plug the fan into QS

a circuit that is servicing other electrical needs.

Turning Fan On/Off: To start the fan, rotate Control Dial from Fig 1

OFF position to desired fan speed (LOW, MEDIUM or HIGH).

Rotate dial to OFF to discontinue use. Unplug fan when not

- NO

(Select models only) 7, =

This fe ith tional wall iting bracket ked EL EE \) \\

is fan comes with an optional wall mounting bracket (packe NG, y \)))

separately). x! Y iS \ py y

1. Use the wall mounting bracket as a template to mark your Or) WA) ZF}

mounting location before you attach the bracket to the fan. ZONK (. Ss

Note: Fan should be level when mounted and at least one of (WEUNS

the two mounting screw locations should be a wall stud. RNS .

2. Place wall mounting bracket on the bottom of the fan and

attach it to the fan using the three enclosed screws as shown

in Fig. 1.

3. Place appropriate fastener into wall. Fasteners can be Fig 2

purchased at your local hardware store or home center. The 9

fastener head must fit properly into mounting holes located

‘on wall mounting bracket. Please leave about 3/8" of space

between the fastener head and the wall surface for the

fastener to properly slot into the wall mounting bracket holes.

4. Mount fan with attached wall mounting bracket to fasteners on

the wall. Check to be sure that the fan is secure on the wall as

shown in Fig. 2.

Source page 4 - OCR transcription (OCR)

CARE AND MAINTENANCE: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a period of

with a clean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit fails

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN - because of a manufacturing defect within 30 days of

WATER. Allow fan to dry completely before use. Periodic grille purchase, return the unit, with your receipt, to the retailer.

cleaning with a vacuum will prevent dust build up. The motor is After 30 d but within the warrant riod, if the unit sealed and does not require any interior maintenance, cleaning er ays, Sut wi e warranty period, It the ul or lubrication. was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty lubrication. does not cover damage caused by misuse, abuse,

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN. | erneatng or aleration. Repairs mace , anyone baie PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR an Mr. Brands LLC are not covered in this warranty. Mr. BECOME DAMAGED IN ANY WAY. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie warranties of merchantability and of fitness of purpose, if the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied

Note: Some models come with a plug where you can replace warranty lasts, so the above limitations may not apply to a fuse. If your model has this, please read and follow the below you. Incidental or consequential damages arising from a instructions to replace the fuse. breach of either express or implied warranties are hereby

This product employs overload protection (fuse). A blown fuse disclaimed and excluded. Some States do not allow the indicates an overload or short-circuit situation. If the fuse blows, | €Xclusion of limitation of incidental or consequential unplug the product from the outlet. Replace the fuse as per the damages, so this limitation or exclusion may not apply to user servicing instructions (follow product marking for proper you. Upon the expiration of this warranty all such liability fuse rating) and check the product. If the replacement fuse will terminate. No other warranties are expressed or blows, a short-circuit may be present and the product should implied.

be discarded or returned to an authorized service facility for examination and/or repair.

Fuse Replacement: This warranty gives you specific legal rights, and you may

1. Grasp plug and remove from the receptacle or other also have other rights which vary from state to state. No outlet device. Do not unplug by pulling on cord. informal dispute settlement mechanisms are available.

2. Open fuse cover by sliding open fuse access cover on This limited warranty is given in lieu of all other warranties. top of attachment plug towards blades. See Fig. 2

3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break Mr. Brands LLC glass window. 1414 Radcliffe St Suit 105

4. Replace fuse. Bristol, PA 19007

WARNING: Risk of fire. Replace fuse only with identical ier ATS

5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse www.mrbrands.com

. rn i" www.comfortzoneproducts.com

is properly seated within its cavity. support@mrbrands.com

5. Close fuse cover by sliding it back to its original closed

position. /\

.WARNING:

Cancer and Reproductive Harm --

Fig 1 Fig 2 Fig 3 www.P65Warnings.ca.gov

Slide Cover to Open Rev. 08/29/03

-[eril lay - |r ip 1

- i | “ml

Source page 5 - OCR transcription (OCR)

O Comfort Zone.

C) Comfort Zone.

America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

Ons re [m]

pa reas, a

ce Ny le 5

(Oct o ro be

4 =a», Pe

3 Spree TE

rap Cr

ol Rie oy oi

SCAN HERE

$$ _ _-__-__-