Comfort Zone 16-inch Table Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123720

Original source file(s): 123720.pdf

Source SHA-256: e03f682bf375f3e59ebfebdf004fe8e5f1a80742956b2f30a43a2880d6f48cfc

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

O) Comfort Zone. Owner’s Manual

www.comfortzoneproducts.com Please Read & Save These Instructions

W

16” Table Fan

Features:

¢ Wide Area Oscillation

« Push Button

Wy ON/OFF Switches

/ and 3 Speed Settings

YY 7 * High Performance

%, Fan Blade

Oconee zone - * Adjustable Tilt

‘SS * Safety Grilles

my) «Ss * 120V A.C. / 60Hz.

MASS

HH!" WSS

IMMA

' \NS

od

CZ161 Series intertek

Source page 2 - OCR transcription (OCR)

O) Comfort Zone.

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances. If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING" to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result use, to avoid burns, do not let bare skin touch hot surfaces.

in injury or death.

Fire Hazard

IMPORTANT INSTRUCTIONS Fans have arcing or sparking pars inside. Do not use near

As with all electrical appliances, basic safety precautions should combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

; ; - block air intakes or exhaust in any manner. Do not insert or allow

* Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

* Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

* Do not operate the fan with a damaged power cord or after the Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

* Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

* Do not place the fan on a small, unlevel, uneven or any surface | other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

* For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

* Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

to place, when assembling or disassembling parts, and before | ; ;

cleaning. to Reduce the Risk of Fire or Electric

* The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

manufacturer, may cause hazards. control device.

* Do not use outdoors. . . DO NOT operate any fan with a damaged cord or plug or after

* Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

(for non-window models). Do not operate fan with a broken blade, safety cage or any visual

* Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing. For repairs

removed. covered under warranty, see warranty statement. For all other

* Avoid the use of extension cords due to risk of fire. If an repairs contact Comfort Zone® Customer Service by telephone or

extension cord must be used, the cord must be minimum mail for information and assistance.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with | DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

READ & SAVE THESE

Source page 3 - OCR transcription (OCR)

‘6)) www.comfortzoneproducts.com

Usage: | ; - Step 3 Step 4

Fan Operation: Always operate the fan in the upright position - WAZ

following all instructions and recommendations listed in this en ie \\ ie

manual. wwe t vy mf eypes’y LZ

Fan Location: Place the fan in the area of the room that will a; s Z
provide proper fan cooling. + - : ; =
j\ Qe =
Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz 4 Sse! =
wall outlet. Be sure plug fits tightly in outlet. A loose connection = Noel S/S
may cause overheating and damage to the plug or fan. 'Z _. FS % < SS
Note: To prevent overloading a circuit, do not plug the fan into Remove the Blade Cap by GZ zs \ WS
a circuit that is servicing other electrical needs. twisting it CLOCKWISE while LA MS
holding the metal shaft tightly.
Note: Threads are reversed. Assemble Rear Grille onto
Control Panel Oscillation Control Unscrew = Clockwise. Motor Housing. Rear Grille
rT 7 should fit into alignment pins
» =/ on fan motor housing as
= shown. Note: Wire Handle
8 should be on top.
)
”/ - Step 5 Step 6

Wu Z| WW 1 TS

On/Off Speed Control Oscillation Control Knob Sgr g GY ‘
Turning Fan On/Off: Place fan on stable level surface. pe Pp
Plug fan into properly grounded outlet. To start the fan, press & s-| -_ y
desired speed button: 1-LOW, 2-MED, 3-HIGH. Press 0-OFF to om , we) == 4
discontinue use. Unplug fan when not in use. a ~~ : SS |
. a S
aati SSS .
Oscillation: To start fan oscillation, press Oscillation Control \ WN Remove any protective
Knob (located above motor housing) down. 7 \\.] covering over shaft before fan
To stop oscillation function pull Oscillation Control Knob up while | | y \\\ blade installation. Place fan
the fan is in any oscillation position. blade onto motor shaft. Notice
Thread Locknut onto Motor the pin on motor shaft should
Housing to lock Rear Grille in fit into slots of fan blade.
place. Tighten=Clockwise
Fan Assembly: Assembly is required to use this fan.
Step 1 Step 2 Step 7 Step 8
~ Screw Wire Goes 2
< s pening © -
i ee! pdaal 7) 1) [|) sh
~S = N
(ae -_ . i ie
~ il
Remove two (2) screws from Place power cord wire through Thread blade cap onto With logo upright, attach
base of fan and save them for opening of plastic fan base. threaded end of motor Front Grille to Rear Grille by

Step #2 With cord “opening properly shaft. Note: Threads are snapping them together. Be

postions’ ’ tote peste reversed at this connection. sure all 8 clips are secure.

jan base onto fan body. Tighten=Counter-clockwise. Do not operate fan without

Re-assemble screws removed grille in place.

in Step #1. .

Source page 4 - OCR transcription (OCR)

©) www.comfortzoneproduets.com

Care and Maintenance Limited Warranty

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a period of

with a clean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit

cleaners DO Not Meee THE TAN OR wy, WIRES IN fails because of a manufacturing defect within 30 days of

. Replace Tront gril betore fan use. Alow fan fo Cry purchase, return the unit, with your receipt, to the retailer.

completely before use. Periodic grille cleaning with a vacuum will After 30 d but within th t iod, if th t

prevent dust build up. The motor is sealed and does not require ‘er lays, bu wil in the warran y Perio » H the unt

any interior maintenance, cleaning or lubrication. was purchased within the continental United States, return

it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty

lubrication. does not cover damage caused by misuse, abuse,

. overheating or alteration. Repairs made by anyone other

Bee eee eT Ae OUT HEGRE N than Mr. Brands LLC are not covered in this warranty. Mr.

BECOME DAMAGED IN ANY WAY. Brands LLC will not be held liable for any losses due to

neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie | Warranties of merchantability and of fitness of purpose, if

the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of

one year from the date of original retail purchase. Some

states do not allow limitations on how long an implied

warranty lasts, so the above limitations may not apply to

you. Incidental or consequential damages arising from a

This product employs overload protection (fuse). A blown fuse breach of either express or implied warranties are hereby

indicates an overload or short-circut situation. tne fuse blows, disclaimed and excluded. Some states do not allow the

unplug the product from the outlet. Replace the fuse as per the exclusion of limitation of incidental or consequential

user servicing instructions (follow product marking for proper damages, so this limitation or exclusion may not apply to

fuse rating) and check the product. If the replacement fuse ges, ‘ ‘ y not app y

blows, a short-circuit may be present and the product should you. Upon the expiration of this warranty all such liability

be discarded or returned to an authorized service facility for will terminate. No other warranties are expressed or

examination and/or repair. implied.

Fuse Replacement: This warranty gives you specific legal rights, and you may also

1. Grasp plug and remove from the receptacle or other outlet have other rights which vary from state to state. No informal

device. Do not unplug by pulling on cord. dispute settlement mechanisms are available. This limited

2. Open fuse cover by sliding open fuse access cover on top of warranty is given in lieu of all other warranties.

attachment plug towards blades. See Fig. 2.

Mr. Brands LLC

3. Remove fuse carefully. Use a small tool to pry the end of the 1414 Radcliffe St Suit 105

fuse from holder cavity. Be careful not to break glass Bristol, PA 19007

window. 1-877-420-7555

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with www.mrbrands.com

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure www.comfortzoneproducts.com

fuse is properly seated within its cavity. support@mrbrands.com

5. Close fuse cover by sliding it back to its original closed

Position. WARNING:

Cancer and Reproductive Harm -

www.P65Warnings.ca.gov

Fig 1 Fig 2 Fig 3 Rev. 09/04/23

ei hs =the. |= re

_ i ae

Slide Cover to Open am

Source page 5 - OCR transcription (OCR)

() Comfort Zone.

America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

[=] ay dl beter [ml

, aA ae

Se Meshes

T.] pico a. of

PEt tie

ol it Of...5 On

SCAN HERE