Comfort Zone 6-inch Desk Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123773

Original source file(s): 123773.pdf

Source SHA-256: dc6f675d0fbbfe8f4990fe7712c0ea0585dab9ebcda54e5734ca14917a26cdd2

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

©) Comfort Zone Owner’s Manual

www.comfortzoneproducts.com Please Read & Save These Instructions

Li

6” Desk Fan

Features:

* Sliding ON/OFF

ra FES Switch with 2 Speed

AS SWE fipg Ses Settings

LES s%-\ * High Performance

f} M A 6" Blade

{ : = = ose | } * Large Base

. =m é + Adjustable Tilt

re) ny g

og 7 he + Steel Safety Grille

, War *120V AC. / 6OHz.

, Pe Wey

. == a \ \s%

CZ6D Series intrtek

Source page 2 - OCR transcription (OCR)

Comfort Zone.

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances. If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as.

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING" to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result use, to avoid burns, do not let bare skin touch hot surfaces.

in injury or death.

Fire Hazard

IMPORTANT INSTRUCTIONS Fans have arcing or sparking parts inside. Do not use near

As with all electrical appliances, basic safety precautions should combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

block air intakes or exhaust in any manner. Do not insert or allow

+ Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

* Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

* Do not operate the fan with a damaged power cord or after the | Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

« Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

* Do not place the fan on a small, unlevel, uneven or any surface other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

* For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

* Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

to place, when assembling or disassembling parts, and before . : .

cleaning. to Reduce the Risk of Fire or Electric

* The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

manufacturer, may cause hazards. control device.

* Do not use outdoors. ; DO NOT operate any fan with a damaged cord or plug or after

* Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

(for non-window models). Do not operate fan with a broken blade, safety cage or any visual

+ Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing. For repairs

removed. covered under warranty, see warranty statement. For all other

* Avoid the use of extension cords due to risk of fire. If an repairs contact Comfort Zone® Customer Service by telephone or

extension cord must be used, the cord must be minimum mail for information and assistance.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

READ & SAVE THESE

Source page 3 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

Usage: Care and Maintenance

Fan Operation: Always operate the fan in the upright position Cleaning: CAUTION-Before cleaning the fan be sure to

following all instructions and recommendations listed in this disconnect power cord from the plug. Clean the grille surface

manual. with a clean damp cloth. Do not use harsh chemical or abrasive

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN

Fan Location: Place the fan in the area of the room that will WATER. Replace front grille before fan use. Allow fan to dry

provide proper fan cooling. completely before use. Periodic grille cleaning with a vacuum will

prevent dust build up. The motor is sealed and does not require

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz any interior maintenance, cleaning or lubrication.

wall outlet. Be sure plug fits tightly in outlet. A loose connection

may cause overheating and damage to the plug or fan. Maintenance: The Internal motor bearings are permanently

Note: To prevent overloading a circuit, do not plug the fan into lubricated at the factory and do not require any additional

a circuit that is servicing other electrical needs. lubrication.

Turning Fan On/Off: Place fan on stable surface. Plug fan Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

into outlet. To start the fan, slide power switch to desired speed PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR

button: OFF, LOW, HIGH. BECOME DAMAGED IN ANY WAY.

Fan Assembly: Simple assembly is required to use this fan. Storage: Keep original carton for storage of the fan. Coil and tie

the power cord to avoid damage during storage.

Step 1 i

~

4p This product employs overload protection (fuse). A blown fuse

Y CS indicates an overload or short-circuit situation. If the fuse blows,

rhe WS unplug the product from the outlet. Replace the fuse as per the

A ENS user servicing instructions (follow product marking for proper

(\ < fuse rating) and check the product. If the replacement fuse

Ne blows, a short-circuit may be present and the product should

s be discarded or returned to an authorized service facility for

a examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet

device. Do not unplug by pulling on cord.

2. Open fuse cover by sliding open fuse access cover on top of

attachment plug towards blades. See Fig. 2.

3. Remove fuse carefully. Use a small tool to pry the end of the

Place Clip Base on to Fan fuse from holder cavity. Be careful not to break glass

window.

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure

fuse is properly seated within its cavity.

Step 2 i, ite ori

= _ _ 5. Close fuse cover by sliding it back to its original closed

ss q position.

f iv Fig 1 Fig 2 Fig 3

eS

r] rf >| = | ae \~- \ | =

5 Slide Cover to Open

Insert Thumbscrew and Tighten

Source page 4 - OCR transcription (OCR)

Limited Warranty

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date

of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to

the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr.

Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of

purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other

than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation.

All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration

to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty

lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or

implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or

consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will

terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute

settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC.

1414 Radcliffe St Suit 105

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

support@mrbrands.com

L\ tune:

Cancer and Reproductive Harm -

www.P65Warnings.ca.gov

Rev. 08/29/23

Source page 5 - OCR transcription (OCR)

O Comfort Zone.

C) Comfort Zone.

America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

io uo t[m]

par a eae

poe ey ied of

“4 rte Sa

(ech: Saha

ol ie att on

SCAN HERE

<q - eo