Comfort Zone 6-inch Clip Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123774

Original source file(s): 123774&125272.pdf

Source SHA-256: 552e2da8fb6feb3922e877e60e3e7c50e0750940e1308433cc07206576b9e3e0

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

O) Comfort Zone.

America’s Heating and Cooling Choice CZ6C Series

ayy.

tut y e

or "prize

) +o

@, i oe

wa 10

CS 18

b = Osenit AY

ed a

r ww y ‘ap

oe Soe

ite Ae

sgt 14 J “We

|| 1

6" Clip Fan

Features:

® Sliding ON/OFF Switch with 2 Speed Settings

@ High Performance 6" Blade

e Large Strong Clip

e Adjustable Tilt and Swivel

® Steel Safety Grille

© 120V A.C. / 60Hz.

www.comfortzoneproducts.com Save These Instructions

Source page 2 - OCR transcription (OCR)

Comfort Zone.

INTENDED USE: aanaom READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only wih | INSTRUCTIONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, | block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: TO PREVENT ELECTRIC SHOCK,

* For proper operation, fan should be placed on a smooth, this product has a three prong grounded plug that must be

non-combustible, level surface. inserted into a matching properly grounded outlet to reduce the

+ Always unplug fan when not in use, when moving from place risk of electrical shock. Do not attempt to defeat this safety feature.

to place, when assembling or disassembling parts, and before WARNING: TO REDUCE THE RISK OF FIRE OR

* The use of attachments, not recommended or sold by the ELECTRIC SHOCK, do not use this product with any

manufacturer, may cause hazards. solid-state speed control device.

* Do not use outdoors. . DO NOT operate any fan with a damaged cord or plug or after

* Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

(for non-window models). Do not operate fan with a broken blade, safety cage or any visual

* Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing. For repairs

removed. covered under warranty, see warranty statement. For all other

* Avoid the use of extension cords due to risk of fire. If an repairs contact Comfort Zone® Customer Service by telephone or

extension cord must be used, the cord must be minimum mail for information and assistance.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

O www.comfortzoneproducts.com »

USAGE: Care and Maintenance

Fan Operation: Always operate the fan in the upright position Cleaning: CAUTION. Before cleaning the fan be sure to

following alll instructions and recommendations listed in this disconnect power cord from the plug. Clean the grille

manual. surface with a clean damp cloth. Do not use harsh chemical

or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY

Fan Location: Place the fan in the area of the room that will WIRES IN WATER. Replace front grille before fan use. Allow

provide proper fan cooling. fan to dry completely before use. Periodic grille cleaning with

a vacuum will prevent dust build up. The motor is sealed and

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall does not require any interior maintenance, cleaning or

outlet. Be sure plug fits tightly in outlet. A loose connection may lubrication.

cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a Maintenance: The Internal motor bearings are permanently

circuit that is servicing other electrical needs. lubricated at the factory and do not require any additional

lubrication.

Turning Fan On/Off: Clip fan to a stable location. Plug fan into

outlet. To start the fan, slide power switch to desired speed Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

button: OFF, LOW, HIGH. PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Fan Assembly: simple assembly is required to use this, Storage: Keep original carton for storage of the fan. Coil and tie

fan. the power cord to avoid damage during storage.

Step 1 -a 7

2 ” Wi Note: Some models come with a plug where you can replace a

Gy / oy fuse. If your model has this, please read and follow the below

\ AS instructions to replace the fuse.

F \

\ We . This product employs overload protection (fuse). A blown fuse

KXXS indicates an overload or short-circuit situation. If the fuse blows,

unplug the product from the outlet. Replace the fuse as per

the user servicing instructions (follow product marking for

' proper fuse rating) and check the product. If the replacement

fuse blows, a short-circuit may be present and the product

should be discarded or returned to an authorized service facility

for examination and/or repair.

pes i Fuse Replacement:

ec aaa cc

1. Grasp plug and remove from the receptacle or other outlet

device. Do not unplug by pulling on cord.

Place Clip Base on to Fan “

2. Open fuse cover by sliding open fuse access cover on top of

attachment plug towards blades. See Fig. 2.

3. Remove fuse carefully. Use a small tool to pry the end of the

_ fuse from holder cavity. Be careful not to break glass

Step 2 \a Hex Rape window.

BishoeN 4. Replace fuse. WARNING: Risk of fire. Replace fuse only with identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Besure fuse is properly seated within its cavity.

G 5. Close fuse cover by sliding it back to its original closed

iw - position.

aS Ze Fi . .
ig 1 Fig 2 Fig 3

Aa | ig ig ig
Se - |e
al rrr =e Wiel |
Insert Thumbscrew and Tighten -
Slide Cover to Open

Source page 4 - OCR transcription (OCR)

O Comfort Zone.

www.comfortzoneproducts.com

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC
1414 Radcliffe St Suit 105
Bristol, PA 19007
1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

support@mrbrands.com

L\ wowsne

Cancer and Reproductive Harm -

www.P65Warnings.ca.gov

Rev. 08/29/23

Source page 5 - OCR transcription (OCR)

C) Comfort Zone.

” America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

f=) uo i [m]

a -h “I

T-] pico JE, oO 4

4 Mas

pasa

SCAN HERE

$e?