Comfort Zone 20-inch High Velocity Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 125058

Original source file(s): 125058.pdf

Source SHA-256: e37f64538b101669fe3dec90ad2e48cd42527bb39bd1b3bb0e07c6be6d7507b1

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

(x Mi,

Noe,

20" High Velocity Fan

Features:

¢ ON/OFF Switch with Speed Settings

e Adjustable Vertical Tilt

e Maximum Air Movement

e All Metal Construction

e Metal Fan Blades

© 120V A.C. / 60Hz

Source page 2 - OCR transcription (OCR)

Comfort Zone.

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, INSTRUCTIONS !

not for industrial or other commercial applications. Use only with

electrical wiring that is in good working order and that meets WARNING: SHOCK HAZARD

applicable codes and ordinances. If you have any questions Use your fan only in dry environments. This fan is not intended

whether your wiring is adequate, consult a qualified electrician. for use in a bathroom, laundry area, or similar locations, or near

sinks, washing machines, swimming pools or other sources of

While using your fan, you should follow the IMPORTANT water. Never locate fan where it may fall into a bathtub or other

INSTRUCTIONS listed below. As part of those instructions, we water receptacle. Do not use in damp environments such as

have used the word "WARNING to indicate the level of hazard: | figoded basements.

WARNING indicates a hazard which, if not avoided, could result

in injury or death. WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in

IMPORTANT INSTRUCTIONS: use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

As with all electrical appliances, basic safety precautions should Fans have arcing or sparking parts inside. Do not use near

always be followed to reduce the risk of electric shock, fire, or combustible materials or flammable gases or sources of heat. Do

injury to persons, including the following precautions: not use in areas where gasoline, paint or flammable materials are

* Read all the instructions before using this fan. used or stored. To prevent a possible fire, do not block air intakes

* Use this fan only as described in this manual. Any other use not | °F &xhaust in any manner. Do not insert or allow foreign objects

recommended by the manufacturer may cause electrical shock, | ‘0 enter any ventilation or exhaust opening as this may cause an

fire or injury to persons. electric shock, fire, or damage the fan.

. rae not operate the ‘an with a damaged power cord or after the WARNING: ELECTRICAL SHOCK HAZARD

fan matfunctions or has been dropped in any manner. Do not use with damaged cord or plug. Use with adequate

* Use of extreme caution is necessary when any fan is used by or | ¢lectrical system that is up to code.

near children, disabled persons or pets and whenever the fan is

left operating unattended. CAUTION: TO REDUCE THE RISK OF FIRE OR

* Do not place the fan on a small, unlevel, uneven or any surface | ELECTRIC SHOCK, do not use this product with any

which might allow fan to tip or fall. solid-state speed control device.

* For proper operation, fan should be placed on a smooth,

non-combustible, level surface. WARNING: PREVENT ELECTRIC SHOCK

* Always unplug fan when not in use, when moving from place This product has a cord with 3-prong grounding-type plug

to place, when assembling or disassembling parts, and before (A) which fits the 3-slot grounded receptacle (A2). DO NOT

cleaning. remove the grounding prong (A1) if only a 2-slot receptacle (B)

© The use of attachments, not recommended or sold by the is available.

manufacturer, may cause hazards. For connecting 3-prong grounding-type plug to 2-slot

* Do not use outdoors. receptacle, use an ADAPTER (C). The grounding lug (C1)

© Do not use fan in window. Rain may cause electrical hazard extending from the adapter must be connected to a permanent

(for non-window models). ground with the Metal Screw (D) such as a properly grounded

* Do not operate the fan with blade guards or any safety device outlet box (F).

removed. The adapter should not be used if a 3-slot grounded receptacle

* Avoid the use of extension cords due to risk of fire. If an is available.

extension cord must be used, the cord must be minimum DO NOT DEFEAT THE SAFETY PURPOSE OF EITHER

14 AWG and rated not less then 1875 watts. A GROUNDED PRONG OR A GROUNDING LUG.

* Do not run power cord under carpeting. Do not cover cord with

throw rugs, runners or the like. Arrange cord away from traffic (Aj2 (B) © ©)

area where it will not be tripped over. a

* Do not insert or allow any object to enter any openings on the () (H) GS (1)) (1))

fan. Doing so may cause electric shock and/or fire hazard. ® @ AO as Z

Avoid contact with moving parts. pre

* This appliance is not intended for use by persons (including t i) @) (0) } ())

children) with reduced physical, sensory or mental capabilities (At) (C1)

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the Adapter is not included

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

©) www.comfortzoneproducts.com

DO NOT operate any fan with a damaged cord or plug or after .

fan malfunctions, has been dropped or damaged in any manner. USAGE:

Do not operate fan with a broken blade, safety cage or any visual Fan Operation: Always operate the fan in the upright position

imperfections. Disconnect power before servicing. For repairs following alll instructions and recommendations listed in this

covered under warranty, see warranty statement. For all other manual.

repairs contact Comfort Zone® Customer Service by telephone or .

mail for information and assistance. Fan Location: Place the fan in the area of the room that will

provide proper fan cooling.

DO NOT run power cord under carpeting. Do not cover cord with | ;

throw rugs, runners or the like. Arrange cord away from traffic Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz

area where it will not be tripped over. Avoid the use of extension wall outlet. Be sure plug fits tightly in outlet. A loose connection

cords due to risk of fire. If an extension cord must be used, the may cause overheating and damage to the plug or fan.

cord must be minimum 14 AWG and rated not less then 1875 . .

watts. Do not use an extension cord unless the plug can be Note: To prevent overloading a circuit, do not plug the fan into

completely inserted into its receptacle. Unplug the fan when not a circuit that is servicing other electrical needs.

in use. Do not operate fan with its ventilation obstructed.

Turning Fan On: Place fan on stable level surface. Plug fan

. into properly grounded outlet. To start the fan, turn the switch

ASS E M B LY INSTR U CTIONS: from the OFF position to the desired fan speed.

Fan Cradle Assembly: | | Turning Fan Off: To turn the fan off, turn the switch from the

Simple assembly is required to use this fan. current fan speed setting to the off position. Remove plug from

1. Align Cradle Base (packed separately) with support outlet.

brackets attached to fan body sides. Note: you may Adjusting Fan Tilt: To adjust the tilt angle, use supplied

need to flex the parts to make them align properly. knob wrench to loosen the adjustment screw. After adjustment,

2. Insert support bracket into opening of Cradle Base. retighten the adjustment screw. Save knob wrench for future use.

Press spring loaded button down to allow it to insert

into Cradle Base, see Fig 1.

3. Press support bracket into Cradle Base until spring

button protrudes out open hole in Cradle Base,

see Fig. 2.

4. Repeat above process for opposite side of fan.

Fig 1 Fig 2

Support

p ~~ Bracket

Press |

¥ q

Spring A

<-- Button Zae<- Spring

Cradle

<-- Base

Source page 4 - OCR transcription (OCR)

O Comfort Zone

CARE AND MAINTENANCE: LIMITED WARRANTY

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a period of

with a clean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit fails

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN - because of a manufacturing defect within 30 days of

WATER. Allow fan to dry completely before use. Periodic grille purchase, return the unit, with your receipt, to the retailer.

cleaning with a vacuum will prevent dust build up. The motor is After 30 di but within the warrant riod, if the unit

sealed and does not require any interior maintenance, cleaning er 00 days, ut wi }e warranty period, if the ul

or lubrication. was purchased within the continental United States, return

it, to Mr. Brands LLC for repair or replacement. If the unit

Maintenance: The Internal motor bearings are permanently was purchased outside the continental United States,

lubricated at the factory and do not require any additional return the unit to the place of purchase. This warranty

lubrication. does not cover damage caused by misuse, abuse,

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN evereating oF alteration. Repairs mace ie tenranty. Me

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | . oo

BECOME DAMAGED IN ANY WAY. Brands LLC will not be held liable for any losses due to

neglectful operation. All implied warranties, including the

Storage: Keep original carton for storage of the fan. Coil and tie warranties of merchantability and of fitness of purpose, if

the power cord to avoid damage during storage. applicable, are hereby limited in duration to the period of

one year from the date of original retail purchase. Some

states do not allow limitations on how long an implied

Note: Some models come with a plug where you can replace warranty lasts, so the above limitations may not apply to

a fuse. If your model has this, please read and follow the below you. Incidental or consequential damages arising from a

instructions to replace the fuse. breach of either express or implied warranties are hereby

This product employs overload protection (fuse). A blown fuse disclaimed and excluded. Some states do not allow the

indicates an overload or short-circuit situation. If the fuse blows, exclusion of limitation of incidental or consequential

unplug the product from the outlet. Replace the fuse as per the damages, so this limitation or exclusion may not apply to

user servicing instructions (follow product marking for proper you. Upon the expiration of this warranty all such liability

fuse rating) and check the product. If the replacement fuse will terminate. No other warranties are expressed or

blows, a short-circuit may be present and the product should implied.

be discarded or returned to an authorized service facility for

examination and/or repair.

Fuse Replacement: This warranty gives you specific legal rights, and you may

1. Grasp plug and remove from the receptacle or other also have other rights which vary from state to state. No

outlet device. Do not unplug by pulling on cord. informal dispute settlement mechanisms are available.

2. Open fuse cover by sliding open fuse access cover on This limited warranty is given in lieu of all other warranties.

top of attachment plug towards blades. See Fig. 2

3. Remove fuse carefully. Use a small tool to pry the end

of the fuse from holder cavity. Be careful not to break Mr. Brands LLC .

glass window. 1414 Radcliffe St Suit 105

Bristol, PA 19007

4. Replace fuse. 1-877-420-7555

WARNING: Risk of fire. Replace fuse only with identical www.mrbrands.com

5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is www.comfortzoneproducts.com

properly seated within its cavity. support@mrbrands.com

5. Close fuse cover by sliding it back to its original closed

position.

L\ ase

. . . Cancer and Reproductive Harm ~

Fig 1 Fig 2 Fig 3 www.P65Warnings.ca.gov

–

ae

Source page 5 - OCR transcription (OCR)

() Comfort Zone.

America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

[=] a done <[m]

er raed |

pote oa o be

Bear ae cee

forge hata

ol cit Of... r_!

SCAN HERE