# EZ Heat Fan Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32556

Original source file(s): 32556.Instruction Manual.01.pdf

Source SHA-256: a8cc99d892ee09c2adba4b0c5134526fd2a4d9ec957d23327793c45f0825f5a1

Original PDF pages: 1 | Recovered reading units: 1

## Source page 1 (embedded text)

I Page 1 (cover)

**Features:**

• Adjustable Thermostat

• Three Settings:

High - 1500 watts (5120 BTUs)

Low - 750 watts Fan Only

• Front Mounted Control Panel

• On/Off Indicator Light

• Safety Overheat Protection

• Safety Tip-Over Switch

• Stay Cool Body

• Convenient Carry Handle

**• 120VA.C./60Hz. 12.5A**

Page 3 (inside)

**USAGE:**

Black border shows /

page size and should

not print

\

e heater in

HEATER OPERATION: Always operate the h

the upright

position following all instructions

and

recommendations listed in this manual HEATER

LOCATION: Place the heater in the area of the room that

is coldest. HEATER CONNECTION: Plug heater directly

into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits

tightly in outlet. A loose connection may cause

overheating and damage to the plug or heater. NOTE:

To prevent overloading a circuit,do not plug the

heater into a circuit that is servicing other electrical

needs.

TURNING HEATER ON: To start the heater,turn the On/Off Power Level Control from the OFF position to the LOW or HIGH setting. Then rotate the Thermostat Control clockwise to the HIGH THERMOSTAT position as described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element lubrication "burning off". This is normal and will go away after a few minutes of use.)

POWER LEVEL SWITCH: This heater has two heat settings: High and Low. Use the higher setting (1500 watt) to raise the room temperature quickly. When the desired temperature is reached use the Low setting (750 watt). It is usually sufficient to maintain a comfortable temperature.

SETTING THERMOSTAT: After heater has been turned on and the room has reached the desired temperature, slowly rotate the Thermostat Control counter-clockwise until the heater shuts off (you should hear a faint "click"). By leaving the thermostat at this setting it will automatically maintain this temperature. To lower temperature, rotate the knob further counter-clockwise (towards the LOW position). To raise the temperature, rotate the Thermostat Control clockwise (towards the HIGH position).

TURNING OFF: To d iscontinue use, turn the Power Switch to the OFF position. Always turn the heater OFF before unplugging or plugging in the heater Heater should be unplugged when not in use.

TO OPERATE FAN ONLY: Turn the On/Off Power Level Control dial to the Fan setting. Turn thermostat fully clockwise so the fan will run continuously.

## IMPORTANT SAFETY FEATURES

When the unit is turned on, the power indicator light will illuminate to tell you the heater is functioning. The heater is equipped with an automatic overheat protection device located inside the body of the heater. If the heater grille is obstructed, or if the heater gets too hot for any reason, the automatic overheat protection device will turn the heateroff. To reset the heater, simply turn power off and unplug the

heater for 10 minutes until it cools down and you may plug the heater in and restart the heater. Be sure that the heater is on a smooth level surface with no obstructions. The heater is also equipped with a safety tip-over switch to turn power off to the heater when the heater tips over. To resume heater functions simply stand heater upright. With tip over protection, the heater will only operate when placed upright on a level surface.

**CARE AND MAINTENANCE**

**CLEANING: CAUTION-Before cleaning the heater be** sure to disconnect power cord and allow the heater to cool completely. Clean the outside surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE HEATER IN WATER. Allow heater to dry completely before use.

**REPAIR: DO NOT OPERATE THE HEATER WITHOUT THE GRILLE IN PLACE. DO NOT USE THE HEATER**

IF

IT

HAS

**MALFUNCTIONED**

OR

**BECOME**

**DAMAGED IN ANY WAY.**

**STORAGE: Keep original carton for storage of the** heater. Coil and tie the power cord to avoid damage during storage.

Page 2 (inside)

**1f\JTENDED USE:**

This product is intended for indoor residential and office use only, not for industrial or other commercial application. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. This heater must be plugged in to a 120V AC, 15 Amp (or larger) circuit. Do not plug anything additional into the same circuit If you have any questions whether your wiring is adequate, consult a qualified electrician. Risk of fire, overheating, malfunction, property damage, injury or even death may result if not adhered to

Use your heater-fan only with a working smoke detector located in the vicinity of your heater/fan.

While using your heater/fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word "WARNING" to indicate the level of hazard

**WARNING indicates a hazard which, if not avoided, could result in** injury ordeath.

## IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following

• Read all the instructions before using this heater/fan.

• This heater/fan is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use provided handle when moving this heater.Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 meters) from the front of the heater-fan and keep them away from the sides and rear.

• Do not use heater unattended. Use of extreme caution is necessary when any heater is used by ornearchildren, invalids, disabled persons or pets.

• Do not operate the heaterwith a damaged power cord orafter the heater malfunctions, has been dropped or damaged in any manner Return heater to authorized service facility for examination, electrical or mechanical adjustment or repair.

• Do not use heater outdoorS

• Use your heater only in dry environments. This heater is not intended foruse in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water Never locate heater where it may fall into a bathtub or other water container. Do not use in damp environments such as flooded basements.

• Do not place the heater on a small, unlevel, uneven or any surface which might allow heaterto tip or fall.

• Forproper operation, heatershould be placed on a smooth, non-combustible surface. Do not place on rugs, carpet, vinyl flooring or other plastic surfaces. Not for use outdoors or in wet areas.

• This heater is not designed as a primary heat source

• Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip) Always unplug heater when not in use.

• Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or similar coverings. Arrange cord away from traffic area where it will not be tripped over

• To disconnect heater, turn controls off then remove plug from outlet.

• Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or

damage the heater

• To prevent a possible fire, do not block air intakes or exhaust 1n any manner. Do not use on soft surfaces like a bed, where openings may become blocked

• A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored

• Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

**SAVE THESE INSTRUCTIONS**

Page 4 (back)

Block border shows'

page size and should

not print

\

**WARNING: SHOCK HAZARD**

Use your heater only in dry environments. This heater is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate heater where it may fall into a bathtub or other water container. Do not use heater outdoors. Do not use in damp environments such as flooded basements

**WARNING:HOTSURFACES**

Do not touch body of heater when in use. This heater is hot when in use, to avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater

**WARNING: FIRE HAZARD**

Heaterhas hot and arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. DO NOT USE in areas where gasoline, paint or flammable materials are used or stored. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear. To prevent a possible fire, do not block airintakes orexhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, ordamage the heater.

**WARNING:**

**2LECTRlq_AL SHOCK HAZAR_D**

Do not use with damaged cord or plug. Use with adequate

electrical system that is up to code.
The supply cord has a polarized plug. As a safety feature this plug will fit in a polarized outlet only one way. To prevent Ńlectric ńhocŅ,_ n1atch. wide. blade of plug to wide slot,.. ņŇIIň insert plug. If the plug does not fit contact a qualified electrician
Do not operate any heater with a damaged cord or plug or after heater malfunctions, has been dropped or damaged in any manner. Do not operate heater with a broken heating element or ceramic cone or any visual imperfections

**PET OWNERS NOTE:**

The health of birds and some small pets are extremely sensitive to the fumes given off during the initial use of many appliances. Although these fumes are not harmful to humans, it is recommended that this heater not be used around birds and small pets during its initiial use until the manufacturing corrosion coatings burn off.
Rev. 056019
8_50"
11.0"

**OWNER'S MANUAL**

**FAN HEATER**

Model No.: BNS-15K
SKU#.: 32556
Save These Instructions
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov

**Warranty:**

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of

this warranty all such liability will terminate. No other warranties are expressed or implied. This

**warranty gives you specific legal rights, and you may also have other rights which vary from state**

to state. No informal dispute settlement mechanisms are available. This limited warranty is given in

lieu of all other warranties.

**CUSTOMER ASSISTANCE**

**FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555**

**A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH**

**ANY QUESTIONS REGARDING YOUR HEATER.**

Distributed By:

Mr. Brands, LLC.

Made in China

On/Off

Power

Level

Control

Thermostat

Control

On/Off

Indicator

Light