EZ Heat Dual Quartz Fan Radiant Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32557

Original source file(s): 32557.Instruction Manual.01.pdf

Source SHA-256: db62d668ffebe28290f9ab8d1c6cd103ee62a82641697c083087b2919acfddfb

Original PDF pages: 4 | Recovered reading units: 4

Source page 1 - OCR transcription (OCR)

TTMM

OWNER'S MANUAL

DUAL QUARTZ FAN RADIANT HEATER

MODEL NO.: QGW15-607

SKU#:32557

= = <

\” --_

Features:

eAdjustable Thermostat

©Two Settings:

High (1500 watts)

Low (750 watts)

¢Top Mounted Control Panel

ePower Indicator Light o

*Safety Overheat Protection US

*Safety Tip-Over Protection risTeD'

Convenient Stay Cool Carry Handle

*Quiet High Efficiency Fan Assisted Intertek

°120V A.C., 60Hz., 12.5A, 5120 BTUs Save These Instructions

Source page 2 - OCR transcription (OCR)

INTENDED USE: WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not Use your heater only in dry environments, This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes locations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in toa T20V AC, 18 Amp. other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a outdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements

damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

IMPORTANT INSTRUCTIONS heat. DO NOT USE in areas where gasoline, paint or

flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be ‘materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

* Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

* This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not place the heater near a bed because

heater. Keep combustible materials, such as furniture, pillows, objects such as pillows or blankets can fall off the bed and be

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) ignited by the heater. Do not insert or allow foreign objects to

from the front of the heater-fan and keep them away from the sides enter any ventilation or exhaust opening as this may cause an

and rear. electric shock, fire, or damage the heater.

* Do not use heater unattended. Use of extreme caution is necessary

when any heater is used by or near children, invalids, disabled .

persons or pets, WARNING:

* Do not operate the heater with a damaged power cord or after the + ELECTRICAL SHOCK HAZARD

heater malfunctions, has been dropped or damaged in any manner. Do not use with damaged cord or plug. Use with adequate

electrical system that is up to code

* Do not use heater outdoors. The supply cord has a polarized plug. As a safety feature this

« Use your heater only in dry environments. This heater is not intended plug will fit in a polarized outlet only one way. To prevent

for use in a bathroom, laundry area, or similar locations, or near electric shock, match wide blade of plug to wide slot, fully

sinks, washing machines, swimming pools or other sources of water. insert plug. If the plug does not fit contact a qualified

Never locate heater where it may fall into a bathtub or other water electrician.

container. Do not use in damp environments such as flooded

basements. Do not operate any heater with a damaged cord or plug or after

* Do not place the heater on a small, unlevel, uneven or any surface heater malfunctions, has been dropped or damaged in any

which might allow heater to tip or fall. manner. Do not operate heater with a broken heating element

* For proper operation, heater should be placed on a smooth or ceramic cone or any visual imperfections.

non-combustible surface. Do not place on rugs, carpet, vinyl flooring

or other plastic surfaces. Not for use outdoors or in wet areas.

© This heater is not designed as a primary heat source.

* Always plug heaters directly into a wall outlet/receptacle. Never use

with an extension cord or relocatable power tap (outlet/power strip). .

Always unplug heater when not in use. PET OWNERS NOTE: f

* Do not run power cord under carpeting, Do not cover cord with The Reallh of bids and some smal pets ae extremely sensitive

throw rugs, runners or similar coverings. Arrange cord away from {© the fumes given off during the initial use of many appliances,

traffic area where it wil not be tripped over. Although these fumes are not harmful to humans, it is

i ds and

* To disconnect heater, turn controls off then remove plug from outlet, _-«fecommended that this heater not be used around birds ar

© Do not insert or allow foreign objects to enter any ventilation or small pets during its initial use until the manufacturing corrosion

exhaust opening as this may cause an electric shock or fire or C0atings burn off

damage the heater.

* To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

« A heater has hot and arcing or sparking parts inside. Do not use it in

areas where gasoline, paint or flammable liquids are used or stored.

* Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock or

injury to persons or property,

Source page 3 - OCR transcription (OCR)

USAGE: TURNING OFF: Turn the center dial to the OFF

HEATER OPERATION: Always operate the heater in position before unplugging or plugging in the heater.

the upright position following all instructions and Heater should be unplugged when not in use.

recommendations listed in this manual.

HEATER LOCATION: Place the heater in the area of QUARTZ TUBES: Do not use with either quartz tube

the room that is coldest. cracked or broken.

HEATER CONNECTION: Plug heater directly into 120

volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in IMPORTANT SAFETY FEATURES

outlet. A loose connection may cause overheating and The power indicator light, located near the control

damage to the plug or heater. NOTE: To prevent panel, lights whenever the heater is plugged in. The

overloading a circuit, do not plug the heater into a heater is equipped with an automatic overheat circuit that is servicing other electrical needs. protection device located inside the body of the heater. If the heater grill is obstructed, or if the heater

Power Indicator: This heater is equipped with a gets too hot for any reason, the automatic overheat Power Light Indicator. The power light will illuminate protection device will turn the heater off. To reset the when the unit is plugged in to alert you that the unit heater, simply turn power off and unplug the heater has power. for 10 minutes until it cools down and you may plug in and restart the heater. Be sure that the heater is on a

TURNING HEATER ON: To start the heater, turn the smooth level surface with no obstructions. If the Power Control Dial from the OFF position to the LOW heater is tipped over, the automatic tip-over switch or HIGH setting. Then rotate the Thermostat Control will turn off the heating elements until the heater is clockwise to the HIGH THERMOSTAT position as upright.

described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element fabrication protective CARE AND MAINTENANCE coating "burning off". This is normal and will go away CLEANING: CAUTION-Before cleaning the heater be after a few minutes of use.) sure to disconnect power cord and allow the heater to cool completely. Clean the outside surface with a clean damp cloth. To clean the inside of the unit,

CONTROL PANEL: place the heater on its back, unscrew two screws that Power hold front grill in place and swing grill open. Wipe Indicator shiny reflectors with a damp cloth. Do not touch Light quartz tubes as it will reduce their usable life. When complete screw the grill back in place. Do not use harsh chemical or abrasive cleaners. DO NOT thermostat Power IMMERSE THE HEATER IN WATER. Allow heater to Control Control dry completely before use. DO NOT OPERATE THE

HEATER WITHOUT THE GRILL IN PLACE.

REPAIR: DO NOT OPERATE THE HEATER WITHOUT

POWER CONTROL DIAL: This heater has two heat THE GRILL IN PLACE. DO NOT USE THE HEATER IF settings: High and Low. Use the higher setting (1500 IT HAS MALFUNCTIONED OR BECOME DAMAGED watt) to raise the room temperature quickly. When the IN ANY WAY.

desired temperature is reached use the Low setting. It is usually sufficient to maintain a comfortable STORAGE: Keep original carton for storage of the temperature. heater. Coil and tie the power cord to avoid damage during storage.

SETTING THERMOSTAT: After heater has been turned on and the room has reached the desired temperature, slowly rotate the Thermostat Control dial counter-clockwise until the heater shuts off (you should hear a faint “click"). By leaving the thermostat at this setting it will automatically maintain this

temperature. To lower temperature, rotate the knob further counter-clockwise (towards the LOW position). To raise the temperature, rotate the thermostat knob clockwise (towards the HIGH position).

Source page 4 - OCR transcription (OCR)

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this **warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All** implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

Cancer and Reproductive Harm

vv? 6SWarnings.ca gov

Rev. 012017