EZ Heat Oscillating Ceramic Tower Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32558

Original source file(s): 32558.Instruction Manual.01.pdf

Source SHA-256: c66bb2435b3b971c694d6322065d47eb6ab6b0f27435dd4200e0d0d6352c1720

Original PDF pages: 4 | Recovered reading units: 4

Source page 1 - OCR transcription (OCR)

EZ HEAT

OWNER'S MANUAL

OSCILLATING CERAMIC TOWER HEATER

MODEL NO.: FP507-15A

SKU#:32558

Voltage: 120V, 60Hz Power: LOW = 750 Watts HIGH = 1500 Watts Intertek

Source page 2 - OCR transcription (OCR)

FOR HOUSEHOLD USE ONLY - REMEMBER: Portable electric heaters are designed for spot heating or as a supplementary heat source. They are

not intended to be the main source of heat during the normal heating season.

Please read all instructions before using this heater. When using electrical appliances, basic precautions should always be followed to reduce

tisk of fire, electrical shock and injury to persons or property, including the following:

When switching on the appliance for the first time, allow it to run at full power for about two hours to burn off manufacturing residue odour.

Make sure that the room in which the appliance is located is well ventilated during this step. It is normal for the appliance to emit small

cracking sounds when you turn it on for the first time.

1. Read all instructions before using this heater. 23. Make sure that no pieces of polystyrene or other packaging material

2. This heater is hot when in use. To avoid burns, use the handle when have been left between Clements ofthe appiance, It may be necessary

moving the unit. Keep flammable materials like furniture, pillows, to pass Over the appliance with a vacuum cleaner. .

bedding, papers, clothes and curtains at least 3 feet /1 m from the 24. This appliance is not intended for use by persons (including children)

front, top, sides and rear of the heater. Keep the rear grill away from with reduced physical, sensory or mental capabilities, or lack of

walls and drapes so as not to block the air intake. experience and knowledge, unless they have been given supervision

3. EXTREME CAUTION and supervision is necessary when any heater is or instruction regarding use of the appliance by a person responsible

used near children or pets. The heater should not be left operating for their safety. Children should be supervised to ensure that they do

unattended, not play with the appliance.

4, Always unplug the heater when itis not being used. - A A

5. Donot operate any heater with a damaged cord or plug or after the CAUTION:To prevent electric shock, match the wide blade of the plug

heater malfunctions, has been dropped or damaged in any manner. to the wide slot and insert fully.

6. Donot use outdoors.

7. This heater is not intended for use in any area where there is standing

water. Never place the heater where it may fall into a bathtub or other PET OWNERS WARNING:

8 pater containers rd under carpeting. Do not cover the cord wth throw The heath of some smal pets including birds are extremely sensitive tothe

7 7 se fumes produced during the first-time use of many appliances. These fumes

be tioned over Place the cord away from the traffic area soit wilnot are not harmful to humans but we recommended that you do not use your

" " d birds and small pets d f]

9. ? cisconnect the heater, turn controls to OFF, then remove the plug onatoctrng arresion crate tarnok Is inifal use until the

10. This appliance has a polarized plug (one blade is wider than the other).

This plug is intended to fit a polarized outlet only one way. If the plug

does not fit fully in the outlet, reverse the plug. If t still does not fit,

consult a qualified electrician. Do not connect the heater to extension OPERATING INSTRUCTIONS

cords surge protectors timers, direct breakers of an outlet with other -_ Be sure to plug into a 120 60 Hz outlet. The model is

appliances connected to the same outlet. Risk of fire, overheat, i i ; i

malfunction, property damage, injury, or even death may resuft not equipped with a POWER switch and two power settings.

adhered to!

11, Connect to properly polarized outlets only. Controls

12. Do not insert or allow foreign objects to enter any ventilation or __ Power

exhaust opening as this may cause electric shock, fire or damage to indicator Handle --;

the heater. light

13. To prevent possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

be blocked. a

14. Do not use it in areas where gasoline, paint or flammable liquids are Air outlet Air inlet

used or stored.

15. Use this heater only as described in this manual. Any other use is not

recommended by the manufacturer and may cause fire, electric

shock, injury to persons or other damage to property. F

16. This heater must be plugged into a 120V, 15 amp (or more) circuit of its

own. Nothing else can be plugged into the same circuit. If unsure if your , Power 7 Tip

home meets this specification, consult a certified electrician prior to Fig 1 cord \- over

use. Risk of fire, overheat, malfunction, property damage, injury, or switch

even death may result if not adhered to!

17. To prevent overload and blown fuses, be sure that no other appliance is

plugged into the same outlet or into another outlet wired into the same Control Pane!

circuit. SC

18. It is normal for the heater’s plug and cord to feel warm to the touch. A SYMBOL FUNCTION

plug or cord that becomes hot to the touch or becomes distorted in © (Oworr) Power switch - must be tured on for heater to operate

shape may be a result of a worn electrical outlet. Worn outlets or aN) Fan only sett

receptacles should be replaced prior to further use of the heater. $ ‘an only setting

Plugging the heater into a worn outlet may result in overheating of the 4 (Low) Low heat (750 W) --___Press both Low heat (750 W) buttons

power cord or fire. Lc Low heat (750\W) at once to get High heat (1500 W)

19. Ensure the heater is on a stable, secure surface to eliminate the 2 (oH at 50M)

potential of tipping it over. Qosciuare)

20. Always plug heater directly into a wall outlet/receptacle. Never use

with an extension cord or relocatable power tap (outlet/power strip)

Source page 3 - OCR transcription (OCR)

TEMPERATURE SETTING PROTECTION SYSTEMS

There are two Low heat (750 W) power switches. Pressing either one will Overheat Protection

give you Low heat. You need to press both Low heat (750 W) buttons atthe | This heater includes an overheat protection system that shuts the

Same fim to get High heat (1500 W), Unit off when parts of the heater overheat. If this occurs, unplug it,

Osellation Function: 7 , inspect and remove any objects on or adjacent to the heater that

This model is equipped with an oscillation feature. If you want to obtain a high t tt Wait five to ten minutes for the unit t

wider area of heat circulation, press button for oscillation function. es fom, Th lat baok al d ve tO stheno es i e or 0

Power Indicator Light: ool down, Then plug it back in, and resume the normal operation.

This heater is equipped with a power indicator light, which glows whenever Tip-over switch

the heater is plugged in and tured on. This feature is to prevent you from Your heater is equipped with a tip-over switch, which is designed to

being unaware that the heater is operating and maintaining the temperature | automatically shut off unit when tipped over. When retuned to

ofthe room, normal upright position, heat will automatically come on again. This

is a safety feature to avoid possibility of a fire should the unit be

accidentally tipped over.

CLEANING/MAINTENANCE STORAGE

1. Before any cleaning, make sure that: A) The heater is tured OFF 1. Perform the cleaning procedures described in

and cool to the touch. B) Disconnect power supply at source by Cleaning/Maintenance section.

removing plug from power outlet. 2. Regular Cleaning; A) Interior 2. Wipe all parts to dry.

dust can often be removed by using a vacuum cleaner with a crevice | 3, Pack the heater in its original carton and store it in a cool,

tool attachment. B) Do not use cleaning spray-on liquids or other dry place,

chemicals on the unit. C) Use a clean, soft and lightly damp cloth to

gently wipe off the dirt tm the surface of the unt Be sue not to wet von DO Nor aso aN TO OPEN OR REPAIR THE HEATER

the heating element and the switches. Allow the unit to dry YOURSELF. DOIN CAN CAUSE DAMAGE OR PERSONAL

completely before using. INJURY.

CAUTION: DO NOT ALLOW WATER TO RUN INTO THE INTERIOR

OF THE HEATER AS THIS COULD CREATE A FIRE OR ELECTRIC

SHOCK HAZARD.

TROUBLESHOOTING

PROBLEM POSSIBLE CAUSES SOLUTIONS

1. Heater will not power on. 1. Heater isnot plugged into a 120 V polarized | 1, Ensure units in OFF positon, Plugin unit and attempt to turn on again, Do not attempt

cutlevreceptace. Thermal fuse has permanently | to fix heater yourself. Contact customer service for repair information, Please check your

cisabled the unit's fuse due to extreme heat. electrical box to confirm the breaker has not been blown. This may occur the units

Breakerffuse has been tripped. sharing a receptacle wit another high power consuming appliance. Ensure units in OFF

position. Plug in unit and attempt to turn on again. Attempt to plug unit into another

independent receptacte inthe house,

2. The heaters creating a burning smell. 2. drop of cilfellon the heating coll during the | 2. Ensure room in which heaters situated is well vntlated. Remove any material

manufacturing process twill quickly evaporate | preventing ar intake into the heater.

and should not occur again,

3. The heateris overheating, 3. Something may be blocking the ar intake. 3. Keep flammable materials lke furniture, pillows, bedding, papers, clothes and curtain at

least 3 feet / 0.9 m from the font, top, sides and rear ofthe heater. Keep the rea gill away

from walls and drapes so as not to block the air intake, I overeating occurs the Overheat

Protection system will shutoff the heater. Unplug it, inspect and remove any objets on or

adjacent tothe heater that may cause high temperatures. Wait five to ten minutes forthe

Unt to cool down. Then plug it back in, and resume the normal operation.

Source page 4 - OCR transcription (OCR)

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or

workmanship for a period of one year from the date of original purchase. If this

unit fails because of a manufacturing defect within 30 days of purchase, return the

unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this **warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and** of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this **warranty all such liability will terminate. No other warranties are expressed or** implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555
A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

L\warwne:

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov