EZ Heat Infrared Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32559

Original source file(s): 32559.Instruction Manual.01.pdf

Source SHA-256: f24a4da9954101f299c61dd17ccf5ea48e1cee30b2ef1ea47fbc725397e51da3

Original PDF pages: 8 | Recovered reading units: 11

Source page 1 (embedded text)

OWNER'S MANUAL

INFRARED HEATER

Model No.: MT1198N

Item No.:32559

120V~ 60Hz 1500W

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental United States,** return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

Source page 2 - OCR transcription (OCR)

TABLE OF CONTENTS

Package Contents. ..... 00... cece cece cee ee eee nett et ene eet teen 3

Safety Information 0. 02002

Frequently Asked Questions ..... 0.6... cece ccc eee ect eee Bb

Preparation 0.0.0... ccc eee eee eee eB

Troubleshooting 0.0.0... ccc cc eee n eee B

(Die -cl6 po poooon obo bobo den bobo bop Dooooo ooo ooo oonoooopopoboooooooodooooned

Remote Control. ..... ccc ccc ccc rere eee tens rs ctsrerecetasreeescsseceseresеerars ID

Operating Instructions .... 2.2.0.2 6 2. i cece eee eee eee WI

Care and Maintenance ..... 6.6. ccc een e eet e eee ence eee 1B

2 15

Source page 3 - OCR transcription (OCR)

PACKAGE CONTENTS

A

ff -----

LS (Be °)

(ag / ° ‘J

| D = = =

SECO 4 S_ = pS

es S055

IN -- =) ---4

\

Se I

L\ \ \ \ a WC) ia

(A)

(I

Oo

© BF

WV

PART DESCRIPTION QUANTITY

[a [rennecone Sd

Control Panel (pre assembled to Infrared Heater (A)]

| oo | Air Intake (pre assembled to Infrared Heater (A]]

Temperature Sensor (pre assembled to Infrared Heater (A]}

14 3

Source page 4 (embedded text)

Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, tum off the heater and seek medical attention. To avoid excessive room temperatures which can cause hyperthermia: DO NOT leave product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.

Source page 5 (embedded text)

Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or re-chargeable (NiCad, ni-mh, etc) batteries. Non-rechargeable batteries are not to be recharged. Batteries are to be inserted with the correct polarity. Exhausted batter-ies are to be removed from the product.

Remote control range: 6 meters.

6.28 lbs.

Source page 6 - OCR transcription (OCR)

FREQUENTLY ASKED QUESTIONS OPERATING INSTRUCTIONS

Please review these frequently asked questions on the next few pages prior to using your heater. 1. Turn the heater on or off by pressing the Power

Q. My heater emits a strange odor when | first open the box and when I turn the heater on for the first button on the control panel (C} or by pressing 1

time. Why is this happening? the Power button on the remote control (B).

A. This is normal. This heater is treated with a special heat safe/resistant coating. This odor will sometimes Once the Power is off, heating elements will

be present when the box is opened. When the coating is exposed to heat, it produces this particular odor stop working first. The fan will continue working

during the first few hours of operation. This will dissipate after the break-in period. If you are sensitive to for up to 90 seconds to dispense residual heat Cc >

odors, you may want to pre-burn the unit in a garage with the door open until the initial odor dissipates. inside the heater. This is a normal function. O)

Q. If my heater runs on its max wattage setting, how many BTUs is that?

A. This heater is intended to be used as supplemental heat in areas most needed. It may take several

minutes to several hours to heat your area, depending on various factors. The below chart provides BTU

translations for different wattages. 2. Select a heat setting by pressing the HEAT

button on either the control panel (C) or the 2

WATTAGE BTUS remote control (B) to toggle between the three

Power for heat-up mode is 1,500 W; heat-down

. - is ,1000 W. ECO mode is an Economic Energy

Saving Function. When ECO mode is chosen,

the heater will operate to maintain a constant

- warm 68°F

Note: The ECO LED light will only illuminate HIGH Low ECO

a0 I plug th wee dt it how li ill it take to heat > when the ECO function is active and the > >

. Once | plug the unit in and turn it on, how long will it take to heat my room? ambient room temperature falls below re O O 7

A. The heating process in the heater begins immediately upon powering on and setting the desired 68°F / 20°C.

temperature above the ambient temperature. A noticeable change in the ambient temperature of the

room will vary due to variables such as the location of the heater (in the home), floor plan and size of the 3. Set the temperature by pressing the arrows on

room, how well the room is insulated, how many doors/windows, how much bare concrete [acts as a heat the control panel (C] or the remote control (B) 3

sink with any type of heating), the opening and closing of an exterior door, long hallways, high ceilings, etc. :

Customers with smaller rooms experience quick heat changes. Rooms with larger and open floor plans You can set the temperature on the heater

can expect up to 24 hours to completely heat up. anywhere between 50°F and 90°F or between

10°C and 32°C. Once you have chosen the

Q. I do not have a grounded outlet. Can | use adapters, a 2-prong power strip? desired temperature, the heater will remain

A. NO! If you do not have a grounded outlet, contact a certified electrician for advice. This high wattage a until ihe naan increases to ine <> <s @

heater requires a dedicated outlet to allow it to operate appropriately, especially during the HIGH setting emperature on the digit’ elsplay. ine neater

will cycle on and off to maintain the desired

modes. room temperature. A v

Q. My Heater has an ECO setting? How does this setting work? To view the ambient temperature press the

ambient temperature button on the control _

A. The ECO mode on your heater is a program that attempts to keep the temperature strictly at a “warm” panel. c o4-66-- se S05

68° F (20°C). This also helps with efficiency, as it is programmed to 1] Increase the power to the unit's Note: Press and hold the ambient temperature

maximum wattage if the temperature drops below 64.4°F (18°C) 2) Gradually reduce the wattage used . butt th trol LCl f ae 4d OR

as it approaches 66.2°F (19°C) and 3] Stop heating when 68° F (20°C) is achieved. This is considered an utton on the control pane? \W) for 9 seconds m,.icmes....+349

Economical function, since in the ECO setting, the heater is almost never running at the maximum watts. to switch the digital display indicator on the ie 1o ae

heater between Fahrenheit and Celsius.

On the remote, short press the ambient

temperature button to engage Ambient

Temperature, long press for 3 seconds to

engage Child Lock. cn

6 11

Source page 7 - OCR transcription (OCR)

REMOTE CONTROL FREQUENTLY ASKED QUESTIONS

Q. The temperature on my heater does not match the temperature display on my wall, or external thermostat. Why?

A. This is completely normal. The temperature display on your heater may vary from the temperature O display on another thermostat (like the one mounted to your wall or a purchased external thermostat). This is because the temperature sensor on the heater reads the temperature directly around the heater. a With the heater near the cold floor (and heat rising], any readings on elevated or external thermostats <> [| . will differ in readings on the heater. The best way to operate your heater is to set the unit on High and dial 6 (5 Cs 2 up to a temperature that feels comfortable to you. Then, leave it at that temperature, regardless of the | = | mismatch. The heater will cycle off when the set temperature is met or exceeded slightly.

6 - ~ eS i a Q. Can | use more than one heater at a time? Can I use the heater and another appliance at the same | va © time?

A. Yes, but make sure they are not plugged into the same circuit. Each heater requires its own minimum 15-amp circuit with no other items plugged into that circuit or outlet. This is because heaters are considered appliances and draw out high amperage. If you are unsure your circuit meets these requirements, verify with a certified electrician.

A WARNING: Risk of fire, damage to property, or injury may result if requirements are not met.

Q. Why does my heater’s fan continue to run after the set temperature is reached or the power is turned off?

/n A. This is normal. The heater’s fan will continue to run even after the heater automatically cycles down. The fan continues to run so that every last bit of heat is blown out of the heat chamber while allowing the

PART NAME DESCRIPTION unit to continue filtering your air. Once the internal box/components cool completely, the fan should then

shut off on its own. In this case, allow a few minutes after the heat cycles off (with power on). The fan will

Temp Up Button Increases the set temperature value shut off faster when the power is turned off.

Heater Mode Button Toggles between Hi / Low/ Eco Modes Q. My heater’s display shows my ambient temperature to be in the 20s when | know it is warmer than

that. Why?

Temp Down Button Decreases the set temperature value A. The heater’s display is defaulted to read the temperature as Fahrenheit. If your heater is definitely

Powers the heater on or off heating but shows it is in the 20s you probably have the setting to read your temperature in Celsius rather

than Fahrenheit.

. Shows ambient temp/hold to engage or disengage safety lock

5 Ambient/Lock Button function Q. My heater’s power cord gets warm. My cord is showing signs of heat or melting at the outlet. Is this

normal?

Los | Timer Button Engages the on/off timer .

A. Awarm power cord is normal. These power cords are rated safe for up to 105°C/ 221°F by the UL, CSA, or ETL. The exception is, if you detect heat, smoke, or signs of melting at the contact point of the wall outlet, it may be due to loose or worn wall contacts (or arcing). Please stop using the heater immediately, contact warranty support for a replacement power cord, and have a certified electrician replace the wall outlet as soon as possible.

10 7

Source page 8 (embedded text)

extension

Source page 8 - OCR transcription (OCR)

PREPARATION CONTROL PANEL

Place the heater on a firm, level surface and plug into a grounded 120 V, 60 Hz power outlet. Only operate

heater in upright position. u Z 9

Insert two AAA batteries into the remote control before using (batteries not included).

Ka tt

Please note that infrared heaters do not heat like a traditional space heater. You should not expect infrared 16 va @) -, c

heaters to blow hot air like a traditional space heater. Infrared heaters heat objects not air. Infrared heaters | ~) (| A

are intended to supplement an already heated, insulated room. Square footage specifications assume a ib | (|

singl i - i °

gle enclosed room not an entire home. Infrared heaters do not heat through walls, floors, and are 14 High Low Eco Yom OF 0) 5

not intended to replace a main heat source. Infrared heat can take at least 24 hours to warm a room but

operate much more efficiently to maintain the desired temperature. Infrared heaters will not work well in ®

uninsulated unheated spaces like screened in porches, RV's, garages, unheated basements, etc. CI Cc) -_| - CI | |

TROUBLESHOOTING

an@QOr ~ 8! 0

PROBLEM POSSIBLE CAUSE CORRECTIVE ACTION b $ $ $ 4 4 6

The heater does 1. The power cord is not plugged in. 1. Plug the power cord into an

not turn on. electrical outlet.

2. The electricity at the main fuse boxis | 2. Check the electricity at the main PART NAME DESCRIPTION

not working. fuse box.

3. The battery in the remote control is 3. Replace the batteries in the remote Timer Indicator Light Indicates when the timer function is active

dead. control.

4. The thermostat on the heater is set 4. Increase the thermostat Digital Display Readout of the set room temperature or timer value

lower than the room temperature. temperature on the heater for a Celsius Indicator Light Indicates that the temperature is being displayed in Celsius

higher heat setting.

Fahrenheit Indicator Light | Indicates that the temperature is being displayed in Fahrenheit

Heater shutoff 1. The heater has overheated. 1. Unplug the heater from the wall,

unexpectedly wait a few seconds then plug the Power Indicator Light Indicates when the unit is receiving power from the wall outlet

power cord back in. ;

Power Switch Button Powers the heater ON or OFF

2. Insufficient power to the unit 2. Make sure the unit is plugged into

a dedicated outlet, with no extension Ambient Temp. Button Indicates ambient temp / hold to toggle between °C/°F

cords or surge protectors.

3. The air intake vent is clogged. the back of the unit. See page 13. | 9 | Temp-Up Button Increases the set temperature

4. Move the unit at least 3ft from the

4. Insufficient air flow to the heater. wall. Timer Button Engages the on / off timer function

The heater 1. Temperature sensor not functioning 1. Please contact technical support. Heater Mode Button Toggles between Hi / Low/ Eco Modes

displays an error properly.

code “E2” Safety Lock Button Hold to Lock / Unlock heater’s control panel

Energy Saving Indicator Indicates when energy-saving mode is on

High Heat indicator Indicates when High Heat mode is on

Low Heat Indicator Indicates when Low Heat mode is on

8 9