EZ Heat Deluxe Utility Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32561

Original source file(s): 32561.Instruction Manual.01.pdf

Source SHA-256: 1a6e97bacb1868cc9c29eff3a99fde4135a81ebab8084c07e8254764d8682cdb

Original PDF pages: 1 | Recovered reading units: 4

Source page 1 - Panel 1 (top left) (OCR)

TM This product is intended ONLY for indoor household or office use. It is NOT intended for industrial or commercial use.

L | PLEASE READ AND SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of lire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.

2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. If provided, use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9m) from the front

' of the heater and keep them away from the sides and rear.

OWNER s MANUAL 3. Extreme caution is necessary when any heater is used by or near children, pets or invalids

DELUXE UTILITY H EATER and whenever the heater is left operating and unattended.

4. Always unplug heater by removing the plug end from the outlet when not in use.

Model No.: BL-K21 -D Never unplug by pulling on the cord as this can damage the power cord.

5. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner . Return heater to authorized service facility for

SKU#: 32561 examination, electrical or mechanical adjustment, or repair.

6. Do not use outdoors.

7. Use your heater only in dry environments. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into bathtub or other water container. Do not use near sinks, swimming pools, or other damp areas such as flooded basements, garages, etc. or anyplace where the heater could come in contact with water.

8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.

9. To disconnect heater, first turn controls to off, then remove plug from outlet.

10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may

cause an electric shock or fire, or damage the heater.

} 11. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on
14 soft surfaces, like a bed, where openings may become blocked.
yey 12. Aheater has hot and arcing or sparking parts inside. Do not use it in the areas where gasoline,

i paint, or flammable liquids are used or stored.

13. Use this heater only as described in this manual. Any other use not recommended by the

ve manufacturer may cause fire, electric shock, or injury to persons.

aa 14. Always plug heater directly into a wall outlet/receptacle. Never use with an extensi6n cord or

relocatable power tap (outlet/power strip).

15. This heater draws 12.5 amps during operation. To prevent overloading a circuit, do not plug
the heater into a circuit that already has other appliances working.

16. It is normal for the plug to feel warm to the touch; however, a loose fit between the AC outlet
(receptacle) and plug may cause overheating and distortion of the plug. Contact a qualified

: " electrician to replace loose or worn outlet.

PRE-OPERATING INSTRUCTIONS

1. Carefully remove your heater from box. (Please SAVE the Box for off season storage.

2. Attach the handle using the screws provided.

3. Make sure the heater is switched OFF before plugging the heater into the outlet. Connect to

(4 lj properly grounded outlets only.
US Note: The power cord has a polarized plug (with one blade wider than the other) that will only fit in a
inichait polarized outlet one way. If it does not insert easily try reversing the plug. If it still does not fit contact
120V~ 60Hz 1500W Intertek your electrician to replace your outlet. DO NOT defeat the safety purpose of the polarized plug.

4. Place heater only on a firm level surface, free from obstructions and at least 3 ft. away from

any wall or other objects such as curtains, plants, etc.

5. Avoid overloading your circuit by not using other high wattage appliances in the same outlet.

2

Source page 1 - Panel 2 (top right) (OCR)

_- Control panel (at the top)
Control panel Remote control
Air outlet POWER
“@ BS” ae
® MODE TEMP FLAME
YOoOSLO
Fl AN ©

ame f n\ K power switch (behind) () © 2) © >)

(A \ SWING TIMER

Base Sa, y

Installation:

1. Connect the 2 pieces of basplates into one

After you connect the heater to the wall receptacle, turn on the power switch, the display

screen shows the ambient temperature, the product will be on standby.

La=W © To turn on or turn off the heater, press the "POWER" button on the control panel or remote.

(33) To set the heat mode, press the "MODE" button on the control panel or remote.

To set the temperature, press the "TEMP" button on the control panel or remote.

after the temperature number flashes for 3 seconds without operation, it will become

the set temperature.

2. Screw off the base nut at the bottom of the product ,put the base at the bottom To «mn on or turn off the flame function, press the "FLAME" button on the control

of the product, then use the base nut to fastern the base and the product. panel or remote.

To oscillate or stop oscillating, press the "SWING" button on the control panel

V7 <r a. (IAS © or remote.

(vw iva To set the ti he "TIMER" b h | panel

R=stC ss mate Gams) o set the timer, press the utton on the control panel or

Nap a, Nap ae, remote. Then press S) to change the number from 0 to 12 hour.

a a

aa ae Long press the temperature and timer button for three seconds at the same time, to

lock the heater so that chilid will not operate wrongly.

Long press the temperature and timer button for another three seconds to unlock the

heater.

The remote controller works with battery CR2025.

3 4

Source page 1 - Panel 3 (bottom left) (OCR)

ALWAYS OBSERVE THESE SAFETY PRECAUTIONS WHEN OPERATING YOUR SAFETY FURNACE

CAUTION NEVER Place drapes, clothing or towels over furnace to dry. ;

Use this heater only as described in this manual. Any other use not recommended by the NEVER Use in the Deuce, of explosive cy flammable Melos such as gas or paint. -

manufacturer may cause FIRE, ELECTRIC SHOCK or injury to persons. NEVER Plug another electrical appliance into the same circuit. Blown fuses, tripped circuits and

fire hazards may result.

NEVER Use water or liquids to clean your furnace.

NEVER Let bare skin touch hot surfaces as this may cause burns.

NEVER Leave furnace unattended.

NEVER Leave furnace when children or pets are present.

NEVER Locate furnace where it may fall into a bath tub or other water containers.

CLEANING AND STORAGE NEVER Operate furnace with a damaged cord, plug or after the furnace malfunctions, or has

Dust, dirt, pet fur, etc can all diminish your heaters performance and can lead to unwanted odors. been dropped or damaged in any manner.

For best performance clean your heater frequently, at least once per season. ALWAYS TURN NEVER Run cord under carpeting or cover with throw rugs or runners.

OFF AND UNPLUG THE HEATER BEFORE CLEANING. NEVER Insert or allow foreign objects to enter any ventilation or exhaust openings, as this may

* Turn Heater OFF, unplug it and wait for the heater to become cool. cause an electrical shock, fire or damage.

+ Useadry cloth to clean only external surfaces of the heater. ALWAYS Read all instructions before operating.

a eocuuln with] Som Oru hima [be lus ed tec anOuveredrea: ALWAYS Locate your furnace away from furniture or loose hanging drapes.

* Wrap and tie the cord to protect it from damage. ALWAYS Keep the rear grill away from walls or drapes so as not to block the air intake.

* Repack the heater in its original carton and store it in dry place. ALWAYS Unplug furnace when not in use

NEVER attempt to open or service the heater yourself. Doing so may cause damage or ALWAYS Use furnace on a flat dry Saran

personal injury. ALWAYS Use on 110-120 volt 6(0Hz AC power supply.

ALWAYS Route the cord so it will not be walked on tripped over or pinched by furniture.

ALWAYS Keep electrical cords, drapes and other furnishings away from your furnace.

ALWAYS Keep your furnace clean and the filter free of dust.

ALWAYS Use indoors only.

INSTRUCTIONS FOR POWER

This heater is for use on 120 volts only. The cord has a plug as shown at (A) in the following

figure. An adapter as shown at (C) is available for connecting three blade grounding-type plugs Warranty:

to two-slot receptacles. The green grounding lug extending from the adapter must be connected i. y. . . . . .

to a permanent ground such as a properly grounded outlet box. The adapter should not be used This unit is guaranteed to the original retail purchaser against defects in quality or

if a three-slot grounded receptacle is available. workmanship for a period of one year from the date of original purchase. If this unit fails

because of a manufacturing defect within 30 days of purchase, return the unit, with your

receipt, to the retailer. After 30 days, but within the warranty period, if the unit was

purchased within the continental United States, return it, to Mr. Brands LLC for repair or

replacement. If the unit was purchased outside the continental United States, return the

WARNING: Before servicing this heater be sure to unplug heater from wall outlet. Do not only unit to the place of purchase. This warranty does not cover damage caused by misuse,

turn off heater from the main “ON/OFF” switch, be sure to unplug this heater. abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are

not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to

neglectful operation. All implied warranties, including the warranties of merchantability and

of fitness of purpose, if applicable, are hereby limited in duration to the period of one year

from the date of original retail purchase. Some states do not allow limitations on how long

an implied warranty lasts, so the above limitations may not apply to you. Incidental or

consequential damages arising from a breach of either express or implied warranties are

hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of

incidental or consequential damages, so this limitation or exclusion may not apply to you.

Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

5 6

145x210mm(20230:

Source page 1 - Panel 4 (bottom right) (OCR)

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

‘Cancer and Reproductive Harm --

we P6SWarnings.cagov

7