EZ Heat Electric Fireplace Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32563

Original source file(s): 32563.Instruction Manual.01.pdf

Source SHA-256: 2c0ed1e5402b8ce814436110bf0ae9c0b3dc87bc5aa46ba94921addf4fb7bef2

Original PDF pages: 6 | Recovered reading units: 7

Source page 1 (embedded text)

145*210mm

12

OWNER'S MANUAL

ELECTRIC FIREPLACE HEATER

Model No.: MT1288

Item No.: 32563

120V~ 60Hz 1500W

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental United States,** return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

Source page 2 (embedded text)

11

Source page 2 - OCR transcription (OCR)

TABLE OF CONTENTS

Package ContentS..... 0... cece ccc eee een eee n ett e ten ee eet eneeae eo

Safety Information 0.0.0.0... eee eee &

Frequently Asked Questions ..... 2.0.0... e cece cece ere eee e renee ee B

Preparation 0.00... ccc cece eee cere eee tenet entree enteneeenee D

Troubleshooting 00... 0... eee eee e ete B

Control Panel... 2.2.2.6 2 eee eee eee B

Operating Instructions ..... 0... cece cece eter eee eee n tenner tenn GD

Care and Maintenance ..... 0... cece cece eee teeter eee e tee eee eee 10

2 11

Source page 3 - OCR transcription (OCR)

CARE AND MAINTENANCE PACKAGE CONTENTS

AA WARNING: Before performing any maintenance task, turn off the power, unplug the unit, and allow it to cool completely.

A

1. To keep the heater clean, clean the outer shell with a soft, damp cloth. Use a mild detergent if = SO necessary. After cleaning, dry the unit with a soft cloth. ZOO QS ee

ee -- - Vee

CAUTION: DO NOT let liquid enter the heater. ese a } SS

ae]

2. DO NOT use alcohol, gasoline, abrasive powders, furniture polish, or rough brushes to clean the C | - = heater. This may cause damage or deterioration to the surface of the heater. ---- 7 oa -

. . oi -)

3. DO NOT immerse the heater in water. f S, -)

4. Wait until the unit is completely dry before use. / i -

5. Store the heater in a cool, dry location when not in use. To prevent dust and dirt build-up, use the | c= cc original packaging to repack the unit. =

AA WARNING: Do not use the heater without all assembly in place. --- ee

= cc

» (ess

(4 ---

LoS 67 -*S a

ng TT IT ST

| W I \

Hl \ II | \|

I | lif \|

| 1) \ {i Flies \

ay de bat =p es

PART DESCRIPTION QUANTITY

| 8 | Control Panel (preassembled to Infrared Heater (AJ)

Heat Output Vent (preassembled to Infrared Heater (A]}

Po fumes CC

Temperature Sensor (preassembled to Infrared Heater (A])

10 3

Source page 4 (embedded text)

3

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

•

SAVE THESE INSTRUCTIONS

This heater must be plugged into a 120 V, 15 amp (or more) circuit of its own. Do not plug anything else into the same circuit. If unsure if your home meets this specification, consult a certified electrician prior to use. Risk of fire, overheating, malfunction, property damage, injury, or even death may result if not adhered to!

Connect to a properly outlet only. Do not connect the heater to extension cords, surge protectors, timers, direct breakers, or an outlet with other appliances connected to the same outlet. Risk of fire, overheating, malfunction, property damage, injury, or even death may result if not adhered to!

This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles (certain models) or wheels to move this heater.

Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 ft. (0.9 m) from the front of the heater and keep them away from the sides and rear of the heater.

Extreme caution is necessary when any heater is used by or near children, invalids, pets, or when the heater is left operating unattended.

Always unplug the heater when not in use.

Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped, or damaged in any manner. Contact the manufacturer for resolution options.

Do not use outdoors. Exposure to outdoor elements such as rain, snow, sun, wind, or extreme temperatures may cause the heater to become a safety hazard.

This heater is not intended for use in bathrooms, laundry areas, and similar indoor locations, nor any locations that use GFCI outlets.

Never place the heater where it may fall into a bathtub or other water receptacles.

Do not run the cord under carpet. Do not cover the cord with throw rugs, runners, or similar coverings. Arrange the cord away from traffic areas and where it will not be tripped over.

The heater must be plugged into a wall outlet that is a dedicated circuit with a minimum 15 amp rating on that individual circuit.

To disconnect the heater, first turn the power button to the OFF position and then remove the plug from the wall outlet.

Do not allow foreign objects to enter or block any ventilation or exhaust opening as this may cause electric shock, fire, or damage the heater.

Allow at least 3 ft. of unobstructed space to the front and rear of the heater to allow for maximum heat, air, and ventilation flow.

A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored, nor use flammable solvents to clean the heater. Keep the heater dry at all times.

Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

Do not use abrasive solvents to clean the heater as it may cause damage to the finish or casing.

To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where opening may become blocked.

Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or

relocatable power tap (outlet/power strip).

Hyperthermia can result in death. Symptoms of hyperthermia include high body temperature, headache, nausea, vomiting, tiredness, dizziness, fainting, and rapid pulse. If you begin to experience symptoms related to hyperthermia, tum off the heater and seek medical attention.

To avoid excessive room temperatures which can cause hyperthermia: DO NOT leave product running unattended in a confined space around infants, or individuals with reduced physical, sensory, or mental capabilities.

Source page 5 - OCR transcription (OCR)

TROUBLESHOOTING A SAFETY INFORMATION

Overheat Safety Feat

PROBLEM POSSIBLE CAUSE CORRECTIVE ACTION verneat satety Feature

This heater is equipped with an overheat safety feature. When the internal components of the heater

The heater 1. The power cord is not plugged in. | 1. Plug the power cord into an electrical reach a certain temperature that could cause overheating or possible fire, the heater will automatically

does not turn outlet. shut off.

on. 2. The electricity at the main fuse 2. Check the electricity at the main fuse

box is not working. box. 4d WARNING: TO PREVENT ELECTRICAL SHOCK,

MATCH THE WIDE BLADE OF THE PLUG TO THE
WIDE SLOT OF THE RECEPTACLE AND FULLY
INSERT. ()

The flame 1. There is no light for the flame 1. Change the light bulb.

effect does not)

turn on (1)

There is no 1. The thermostat on the heater 1. Increase the thermostat temperature

heat from the is set lower than the room on the heater to a higher heat setting.

unit temperature.

2. The switch for heat is not on. 2. Turn the low and/or high heat switch to

the on position along with the flame and

fan effect switch. A WARNING: It is normal for the power cord to feel warm to the touch. However, a loose fit between

the outlet and the plug may cause overheating of the plug. If this occurs, try inserting the plug into a

CONTROL PANEL different outlet. Contact a qualified electrician to inspect the original outlet for damage.

ee SS See Specifications

Voltage Rating 120 V (60 Hz)

° ? se Power Consumption 1,000 W/1,500 W

Unit Size 16.60 in. (W) x 10.70 in. (D) x 22.24 in. (H)

ee a0)

e* pated On, Unit Weight 9.57 lbs.

Oe: iio A Ao

eo // \\o \%\

FI \¥ fi { \¥

*|| (ee | I}

e iN /® A |i

x \ y

re yy \ A

“2 O

PART NAME DESCRIPTION

Power Indicator Light Indicates when unit is recieving power.

2 Mode Select Knob Powers the unit ON / OFF and toggles power between high,

low, and flame only modes.

Thermostat Knob Increases or decreases desired temperature

8 5

Source page 6 - OCR transcription (OCR)

FREQUENTLY ASKED QUESTIONS FREQUENTLY ASKED QUESTIONS

Please review these frequently asked questions on the next few pages prior to using your heater. A WARNING: Risk of fire, damage to property, or injury may result if requirements are not met.

a. My heater emits a strange odor when | first open the box and when | turn the heater on for the first Q. Why does my heater’s fan continue to run after the set temperature is reached or the power is turned

time. Why is this happening? off?

A. This is normal. This heater is treated with a special heat safe/resistant coating. This odor will A. This is normal. The heater’s fan will continue to run even after the heater automatically cycles down.

sometimes be present when the box is opened. When the coating is exposed to heat, it produces this . . : .

. . . . ee 5 The fan continues to run so that every last bit of heat is blown out of the heat chamber while allowing

particular odor during the first few hours of operation. This will dissipate after the break-in period. If . aye . .

aa ae . . the unit to continue filtering your air. Once the internal box/components cool completely, the fan should

you are sensitive to odors, you may want to pre-burn the unit in a garage with the door open until the . . . i

arn on then shut off on its own. In this case, allow a few minutes after the heat cycles off (with power on]. The

initial odor dissipates. .

fan will shut off faster when the power is turned off.

5 . . 9

Q. If my heater runs on its max wattage setting, how many BTUs is that? Q. My heater’s power cord gets warm. My cord is showing signs of heat or melting at the outlet. Is

A. This heater is intended to be used as supplemental heat in areas most needed. It may take several this normal?

minutes fo severat hours to heal your area, depending on various factors. The below chart provides BTU A. A warm power cord is normal. These power cords are rated safe for up to 105°C/ 221°F by the UL,

ges. CSA, or ETL. The exception is, if you detect heat, smoke, or signs of melting at the contact point of

the wall outlet, it may be due to loose or worn wall contacts [or arcing]. Please stop using the heater

WATTAGE BTUS . rm on

immediately, contact warranty support for a replacement power cord, and have a certified electrician

1.500 5.118 replace the wall outlet as soon as possible.

1,000 3,412

PREPARATION

Q. Can the heating elements be replaced? Se ee ee eee

A. Replacement heating elements can be obtained from the manufacturer. All parts may be purchased Place the heater on a firm, level surface and plug into a grounded 120 V, 60 Hz power outlet. Only

through the manufacturer if your product is out of warranty. If you feel that the elements are definitely operate heater in upright position.

feulty right out of the box, contact Customer Support. A representative can then direct you to the next Please note that infrared heaters do not heat like a traditional space heater. You should not expect

step. infrared heaters to blow hot air like a traditional space heater. Infrared heaters heat objects not air.

Q. Once | plug the unit in and turn it on, how long will it take to heat my room? Infrared heaters are intended to supplement an already heated, insulated room. Square footage

specifications assume a single enclosed room not an entire home. Infrared heaters do not heat through

A. The heating process in the heater begins immediately upon powering on and setting the desired walls, floors, and are not intended to replace a main heat source. Infrared heat can take at least 24

temperature above the ambient temperature. A noticeable change in the ambient temperature of the hours to warm a room but operate much more efficiently to maintain the desired temperature. Infrared

room will vary due to variables such as the location of the heater [in the home), floor plan and size of heaters will not work well in uninsulated unheated spaces like screened in porches, RV's, garages,

the room, how well the room is insulated, how many doors/windows, how much bare concrete [acts as unheated basements, etc.

a heat sink with any type of heating), the opening and closing of an exterior door, long hallways, high

ceilings, etc. Customers with smaller rooms experience quick heat changes. Rooms with larger and

open floor plans can expect up to 24 hours to completely heat up.] |

Q. Can | use more than one heater at a time? Can | use the heater and another appliance at the same To assemble the unit feet align the foot to the --

time? mounting bracket and press up firmly until se- <- > -

A. Yes, but make sure they are not plugged into the same circuit. Each heater requires its own minimum cured with a “CLICK” sound. For permanent tS

15-amp circuit with no other items plugged into that circuit or outlet. This is because heaters are attachment you can secure the leg by adding

considered appliances and draw out high amperage. If you are unsure your circuit meets these a screw into the pre-drilled hole (1 per leg). NH]] :

requirements, verify with a certified electrician. {hy | \ j

\ on

Hil | } il \

at '\

as | i

a i \

"\

\

\

6 7