EZ Heat Electric Radiant Dish Heater

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32565

Original source file(s): 32565.Instruction Manual.01.pdf

Source SHA-256: 2a652bb862fbb0995f928c40593fa1dbc2d73b5685aea4e854dd563174e91359

Original PDF pages: 1 | Recovered reading units: 1

Source page 1 (embedded text)

Features:

• Dual Heat Settings: 1000 watts/700 watts

• Wide Oscillation

• Adjustable Tilt to Direct Heat

• Flocked Metal Safety Grille Stays Cool to the Touch

• Safety Temperature Cutoff Switch

• Safety Tip-Over Cutoff Switch

• Convenient Carry Handle

• 120V A.C., 60Hz., 8.33A, 3412 BTUs

USAGE:

HEATER OPERATION: Always operate the h eater in the upright position following all instructions and commendations listed in this manual. HEATER LOCATION: Place the heater in the area of the room that is coldest. HEATER CONNECTION: Plug heater directly into 120 Volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or heater. NOTE: The heater draws 8.33 amps during operation. To prevent overloading a circuit, do not plug the heater into a circuit that is servicing other electrical needs TURNING HEATER ON: To start the heater, turn the POWER SWITCH (left knob) from the off position to the LOW (700 Watt) or HIGH (1000 WATT) position. (During the heaters initial use, you may experience a slight odor orsmoking. This is the result of the heating element lubrication "burning off". This is normal and will go away aftera few minutes of use.)

Power

Switch

OPERATION SWITCH: This heater has two heat settings

LOW (700 Watts) and HIGH (1000 Watts). Use the HIGH setting to raise the room temperature quickly. When the desired temperature is reached use the LOW setting to maintain

temperature. It is usually sufficient to maintain a comfortable temperature

TILT FEATURE: Your heatercan tilt for adjusting the direction of heat. To adjust the angle, loosen tilt adjustment knob and move angle of the heater to desired position Tghten tilt adjustment knob to hold heater in position. Do not force the heater in either direction beyond its guides

TURNING OFF: Turn the selector switch to the OFF position before unplugging or plugging in the heater. Heater should be unplugged when not in use

OSCILLATION CONTROL: You can control the Oscillation feature on the Heater by rotating the Oscillation Control (OSC) switch located on the control panel of the heater

USERS NOTE:

The coils in the center of
the dish are very hot
It is normal that not all coils
are glowing during use
The non-glowing elements
are functioning properly
and generating heat

Page 1

IMPORTANT SAFETY FEATURES

The heater is equipped with an automatic overheat protection device and an automatic tip-over sensor located under the base of the heater. If the heater grille is obstructed, the automatic overheat device will turn the heater off. If the heater is tipped over, the automatic tip-over switch will turn off the heater. If either safety sensor is activated, make sure the heater is on a level surface and clear of all obstacles. Unplug the heater and allow it to cool down before restarting. After cooling down and obstacles have been removed

CARE AND MAINTENANCE

CLEANING: CAUTION-Before cleaning the heaterbe

sure to disconnect power cord and allow the heater to cool completely. This heater should be cleaned at least once a year to maintain proper performance. Clean the outside surface with a clean damp cloth. Do not use harsh chemical orabrasive cleaners. DO NOT IMMERSE THE HEATER IN WATER. Allow heater to dry completely before use

REPAIR: DO NOT OPERATE THE HEATER WITHOUT THE GRILLE IN PLACE. DO NOT USE THE HEATER IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANYWAY.

STORAGE: Keep original carton for storage of the

heater. Coil and tie the power cord to avoid damage

during storage

Page 3

INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial application. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. This heater must be plugged in to a 120V AC, 15 Amp (or larger) circuit Do not plug anything additional into the same circuit If you have any questions whether yourwiring is adequate, consult a qualified electrician. Risk of fire, overheating, malfunction, property damage, injury or even death may result if not adhered to

Use your heater-fan only with a working smoke detector located in the vicinity of your heater/fan

While using your heater/fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word "WARNING" to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in

injury or death

IMPORTANT INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following

• Read all the instructions before using this heater/fan

• This heater/fan is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use provided handle when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 meters) from the front of the heater-fan and keep them away from the sides and rear.

• Do not use heater unattended. Use of extreme caution is necessary when any heater is used by or near children, invalids, disabled persons or pets.

• Do not operate the heater with a damaged power cord or after the heater malfunctions, has been dropped or damaged in any manner Return heater to authorized service facility for examination, electrical or mechanical adjustment or repair

• Do not use heater outdoors

• Use yourheateronly in dry environments. This heater is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate heater where it may fall into a bathtub or other water container. Do not use in damp environments such as flooded basements

• Do not place the heateron a small, unlevel, uneven or any surface which might allow heater to tip orfall

• For proper operation, heater should be placed on a smooth, non-combustible surface. Do not place on rugs, carpet, vinyl flooring or other plastic surfaces. Not for use outdoors or in wet areas

• This heater is not designed as a primary heat source.

• Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord orrelocatable powertap (outlet/powerstrip) Always unplug heater when not in use

• Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or similar coverings. Arrange cord away from traffic area where it will not be tripped over

• To disconnect heater, turn controls off then remove plug from outlet

• Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater

• To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may become blocked

• A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored

• Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

SAVE THESE INSTRUCTIONS

Page 2

WARNING: SHOCK HAZARD

Use your heater only in dry environments. This heater is not intended foruse in a bathroom, laundry area, or similar locations, or nea_r sinks, w.ashing mach.ines, swimming pools_ o.r other sources of water. Never locate heater where it may fall into a bathtub or other water container. Do not use heater outdoors. Do not use in damp environments such as flooded basements

WARNING: HOT SURFACES

Do not touch body of heater when in use. This heater is hot when in use, to avoid burns, do not let bare skin touch hot

surfaces. If provided, use handles when moving this heater.

WARNING: FIRE HAZARD

Heater has hot and arcing orsparking parts inside. Do not use nearcombustible materials orflammable gases orsources of heat.

DO NOT USE in areas where gasoline, paint or flammable materials are used or stored. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9 m) Irom the front of the heater and keep them away from the sides and rear. To prevent a possible fire, do not block airintakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked. Do not place the heater near a bed because objects such as pillows or blankets can fall off the bed and be ignited by the heater. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the heater.

WARNING:

ELECTRICAL SHOCK HAZARD

Do not use with damaged cord orplug. Use with adequate electrical system that is up to code

The supply cord has a polarized plug. As a safety feature this plug will fit in a polarized outlet only one way. To prevent electric shock, match wide blade of plug to wide slot, fully insert plug. If the plug does not fit contact a qualified electrician

Do not operate any heater with a damaged cord or plug or after heater malfunctions, has been dropped or damaged in any manner. Do not operate heater with a broken heating element or ceramic cone or any visual imperfections

PET OWNERS NOTE:

The health of birds and some small pets are extremely sensitive to the fumes given off during the initial use of many appliances Although these fumes are not harmful to humans, it is recommended that this heater not be used around birds and small pets during its initial use until the manufacturing corrosion coatings burn off

OWNER'S MANUAL

Electric Radiant Dish Heater

Model No.: BFGD-8C

SKU#.: 32565

Save These Instructions

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental United States,** return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China