EZ Chill Twin Window Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01282

Original source file(s): 01282&83232_compressed.pdf

Source SHA-256: 2b0d6e578a62e5b02e4df9ec43726046899e9ceb7c07a97650165981951648a0

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

(EzcHIL)

= = " a

Features:

* Manually Reversible:

FRESH AIR OPERATION (draw in fresh air from the outside)

EXHAUST AIR OPERATION (pulls inside air out of the room)

- Rotating Dial with 2 Speed Settings

¢ Carry Handle

« Adjustable Accordion Extensions

- Rust Resistant Construction

« Poly Fan Blades Designed for Maximum Air Movement

° Safety Grilles

*120V A.C. / 60Hz.

BFC-9 Intertek

Source page 2 - OCR transcription (OCR)

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances. If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING" to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result use, to avoid burs, do not let bare skin touch hot surfaces.

in injury or death.

IMPORTANTINSTRUCTIONS - | SUZSRINER rive ave

Fans have arcing or sparking parts inside. Do not use near

As with all electrical appliances, basic safety precautions should combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

block air intakes or exhaust in any manner. Do not insert or allow

+ Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

+ Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

+ Do not operate the fan with a damaged power cord or after the | Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

+ Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

+ Do not place the fan on a small, unlevel, uneven or any surface other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

+ For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

+ Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

to place when assembling or disassembling parts, and before to Reduce the Risk of Fire or Electric

9.

« The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

control device.

manufacturer, may cause hazards.

+ Do not use outdoors. . DO NOT operate any fan with a damaged cord or plug or after

+ Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

(for non.window models). Do not operate fan with a broken blade, safety cage or any visual

+ Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing.

removed.

+ Avoid the use of extension cords due to risk of fire. If an DO NOT run power cord under carpeting. DO NOT cover cord

extension cord must be used, the cord must be minimum with throw rugs, runners or the like. Arrange cord away from

14 AWG and rated not less then 1875 watts. traffic area where it will not be tripped over. Avoid the use of

+ Do not run power cord under carpeting. Do not cover cord with extension cords due to risk of fire. If an extension cord must

throw rugs, runners or the like. Arrange cord away from traffic be used, the cord must be minimum 14 AWG and rated not

area where it will not be tripped over. less then 1875 watts. Do not use an extension cord unless the

= Do not insert or allow any object to enter any openings on the plug can be completely inserted into its receptacle. Unplug

fan. Doing so may cause electric shock and/or fire hazard. the fan when not in use. Do not operate fan with its ventilation

Avoid contact with moving parts. obstructed.

* This appliance is not intended for use by persons (including

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

READ & SAVE THESE

INSTRUCTIONS

Source page 3 - OCR transcription (OCR)

Usage: | ; ; Fan Functions:

Fan Operation: Always operate the fan in the upright position FRESH AIR Operation draws fresh air in from the outside.

following all instructions and recommendations listed in this EXHAUST AIR Operation pulls inside air out of the room.

Fan Location: Place the fan in the area of the room that will Instructions for Floor or Table Use:

provide proper fan cooling. This fan can be placed in a window Simple assembly is required to use this fan on a table or floor.

to provide additional FRESH air from outside. In this location, Locate 4 slots on the base of fan (See Fig. 1). Push fan leg into

the fan can also be used to push inside air to the outside using slot to lock in place. Repeat this action on the other leg.

the EXHAUST position.

. . Fig. 1

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz

wall outlet. Be sure plug fits tightly in outlet. A loose connection] - z ==]

may cause overheating and damage to the plug or fan. | rs --+- == .

Note: To prevent overloading a circuit, do not plug the fan into | = ~<

a circuit that is servicing other electrical needs. | | =

AM

Turning Fan On/Off: To start the fan, rotate Control Dial x \e

from 0 position to desired fan speed (I or II). Rotate dial to 0 to , ys 3

discontinue use. Unplug fan when not in use. oe @

¥

Control ri \ ‘a

Dial - a 2

= Py OF

<= ‘Ss

Installation For Double Hung Window:

+ If space allows, screens can be left in place.

+ Legs should not be installed when mounting in window.

+ Your fan comes fully assembled and is ready for window

installation.

* This fan has been designed for a double hung window with minimum openings of 23-1/2" wide x 11-1/8" high.

+ Prior to installation, be sure the side panels are in the retracted position.

1. Open window at least 12".

2. Identify the front and back sides of the fan.

For Fresh Air Operation (draw in fresh air from the outside), position the fan so the front side faces you. See silkscreen indicator under control dial "This Side - Fresh Air In".

For Exhaust Air Operation (pulls inside air out of the room), position the fan so the back side faces you. See silkscreen Fig. 2 indicator under control dial "This Side - Exhaust Out".

3. Place one hand under the fan and grasp the recessed handle around the Control Dial with your other hand. With power cord TopWindow Sash Top Window F: aligned in its slot and coming inside the house, position the ‘op Window Fan bottom (lower edge) of the fan over the sill cap of the window while still holding the recessed handle. Use your free hand = 4 to lower the window sash down, making firm contact with TT : the top of the fan (See Fig. 2). Secure window sash in down - position tight against the fan top. Note: It is the customers - -- | responsibility to be sure the fan is secure in the window E> A= 5

4, Pull out each side panel until the space on the sides of the fan == == A= =. | are fully blocked, making sure that the power cord is hanging) SS SF SESS inside the room. The side panels can be retracted back into ~ a the fan by pushing them inwards. Side Panel Side Parfel

PXCZNUTONE Fan will not stop a child from falling out of the window. Keep children away from open windows.

Source page 4 (embedded text)

support@mrbrands.com

Source page 4 - OCR transcription (OCR)

Care and Maintenance Warranty:

Cleaning: CAUTION-Before cleaning the fan be sure to

disconnect power cord from the plug. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Allow fan to dry completely before use. Periodic cleaning with a vacuum will prevent dust build up. The motor is sealed and does not require any interior maintenance, cleaning or lubrication.

Maintenance: The Internal motor bearings are permanently

lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.

This unit is guaranteed to the original retail purchaser

against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer.

After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLG are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded.

Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

2. Open fuse cover by sliding open fuse access cover on top of CUSTOMER ASSISTANCE:

attachment plug towards blades. See Fig. 2. FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

3. Remove fuse carefully. Use a small ool to pry the end ofthe | CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

fuse from holder cavity. Be careful not to break glass window. Made in China

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with Distributed by:

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure oe eres tds com

fuse is properly seated within its cavity. www nrbrands.com

5. Close fuse cover by sliding it back to its original closed /\

position. WARNING:

Cancer and Reproductive Harm -

www.P65Warnings.ca.gov

Rev. 04/11/23

Fig1 Fig 2 Fig 3

= S| ol - ae =

Slide Cover to Open _