EZ Chill 20-inch Box Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01284

Original source file(s): 01284(pdfgear.com).pdf

Source SHA-256: 1656284a4a9ac69b5d1ea49c621ab83f39b4459163eb871ea0018857b92d4e0c

Original PDF pages: 4 | Recovered reading units: 4

Source page 1 - OCR transcription (OCR)

E Z(HL L 01284/83224

SL ag a ae a

ie

% a =e

yj 3 Ra

if % S ‘ \

Fite Z S: \

[Ae ~ al

i} iv \\

Dees eUltninnyle f--

NES free |

VANES 2g t))

\ Seen 33° y,

NESSES 2 Ze y

\ . a. 4

a =-27ZF

Features:

¢ Rotary Switch with

3-Speed Settings

1-Low, 2-Med and

3-High

¢ Convenient Carry Handle

¢ Lightweight

¢ Maximum Air Movement

¢« Aerodynamic Shaped Fan Blades

¢ Safety Grilles

¢ Easy No Tool Assembly él)

* 120V A.C. / 6OHz nad

BFT-20A Intertek

Source page 2 - OCR transcription (OCR)

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances. If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING" to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result use, to avoid burns, do not let bare skin touch hot surfaces.

in injury or death.

Fire Hazard

IMPORTANT INSTRUCTIONS Fans have arcing or sparking parts inside. Do not use near

As with all electrical appliances, basic safety precautions should | combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

; ; a block air intakes or exhaust in any manner. Do not insert or allow

+ Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

+ Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

+ Do not operate the fan with a damaged power cord or after the Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

+ Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

+ Do not place the fan on a small, unlevel, uneven or any surface other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

+ For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

+ Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

to place, when assembling or disassembling parts, and before a 7 .

cleaning. to Reduce the Risk of Fire or Electric

+ The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

manufacturer, may cause hazards. control device.

* Do not use outdoors. . . DO NOT operate any fan with a damaged cord or plug or after

+ Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

{for non-window models). Do not operate fan with a broken blade, safety cage or any visual

+ Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing. For repairs

removed. covered under warranty, see warranty statement.

+ Avoid the use of extension cords due to risk of fire. If an

extension cord must be used, the cord must be minimum DO NOT run power cord under carpeting. DO NOT cover cord

+ Do not run power cord under carpeting. Do not cover cord with with throw rugs, runners or the like. Arrange cord away from

throw rugs, runners or the like. Arrange cord away from traffic traffic area where it will not be tripped over. Avoid the use of

area where it will not be tripped over. extension cords due to risk of fire. If an extension cord must

. . . be used, the cord must be minimum 14 AWG and rated not

* Do not insert or allow any object to enter any openings on the less then 1875 watts. Do not use an extension cord unless the

fan. Doing So may cause electric shock and/or fire hazard. plug can be completely inserted into its receptacle. Unplug

Avoid contact with moving parts. the fan wh i Do not te fan with its ventiat

. 4 . , ie fan when not in use. Do not operate fan with its ventilation

+ This appliance is not intended for use by persons (including obstructed.

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have Usage:

been given supervision or instruction concerning use of the Fan Operation: Always operate the fan in the upright position

appliance by a person responsible for their safety. following all instructions and recommendations listed in this

+ Children should be supervised to ensure they do not play with manual.

the appliance.

READ & SAVE THESE Fan Location: Place the fan in the area of the room that will

provide proper fan cooling.

INSTRUCTIONS Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz

Source page 3 (embedded text)

support@mrbrands.com

Source page 3 - OCR transcription (OCR)

wall outlet. Be sure plug fits tightly in outlet. A loose connection 4. Replace fuse. WARNING: Risk of fire. Replace fuse only with

may cause overheating and damage to the plug or fan. identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse

Note: To prevent overloading a circuit, do not plug the fan into is properly seated within its cavity.

a circuit that is servicing other electrical needs. 5. Close fuse cover by sliding it back to its original closed

Turning Fan On/Off: To start the fan, tum rotary dial on Position. ; ;

Control Panel to desired speed setting. Fig 1 Fig 2 Fig 3

0 - Off Ax

1-Low Control Panel - |p iy =

2 - Medium \ } fe | - | <- al

3 - High - 4

Rotate ON/OFF dial to OFF to discontinue use. Unplug fan when Slide Covertolpey)

not in use.

. Warranty:

Assembly Instructions: Turn the feet clock/unclock This unit is guaranteed to the original retail purchaser

according to arrow to the right place. against defects in quality or workmanship for a period of

one year from the date of original purchase. If this unit

_. fails because of a manufacturing defect within 30 days of

purchase, return the unit, with your receipt, to the retailer.

After 30 days, but within the warranty period, if the unit

. Stabilizing Feet was purchased within the continental United States,

Care and Maintenance return it, to Mr. Brands LLC for repair or replacement. If

Cleaning: CAUTION-Before cleaning the fan be sure to the unit was purchased outside the continental United

disconnect power cord from the plug. Clean the grille surface States, return the unit to the place of purchase. This

with a clean damp cloth. Do not use harsh chemical or abrasive warranty does not cover damage caused by misuse,

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN abuse, overheating or alteration. Repairs made by anyone

WATER. Replace front grille before fan use. Allow fan to dry other than Mr. Brands LLC are not covered in this

completely before use. Periodic grille cleaning with a vacuum will warranty. Mr. Brands LLC will not be held liable for any

prevent dust build up. The motor is sealed and does not require losses due to neglectful operation. All implied warranties,

any interior maintenance, cleaning or lubrication. including the warranties of merchantability and of fitness

of purpose, if applicable, are hereby limited in duration to

Maintenance: The Internal motor bearings are permanently the period of one year from the date of original retail

lubricated at the factory and do not require any additional purchase. Some states do not allow limitations on how

lubrication. long an implied warranty lasts, so the above limitations

may not apply to you. Incidental or consequential

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN damages arising from a breach of either express or

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR implied warranties are hereby disclaimed and excluded.

BECOME DAMAGED IN ANY WAY. Some states do not allow the exclusion of limitation of

incidental or consequential damages, so this limitation or

Storage: Keep original carton for storage of the fan. Coil and tie | exclusion may not apply to you. Upon the expiration of

the power cord to avoid damage during storage. this warranty all such liability will terminate. No other

warranties are expressed or implied. This warranty gives

Note: Some models come with a plug where you can replace a you specific legal rights, and you may also have other

fuse. If your model has this, please read and follow the below rights which vary from state to state. No informal dispute

instructions to replace the fuse. settlement mechanisms are available. This limited

warranty is given in lieu of all other warranties.

This product employs overload protection (fuse). A blown fuse

indicates an overload or short-circuit situation. If the fuse blows, CUSTOMER ASSISTANCE:

unplug the product from the outlet. Replace the fuse as per FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

the user servicing instructions (follow product marking for A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

proper fuse rating) and check the product. If the replacement ANY QUESTIONS REGARDING YOUR FAN.

fuse blows, a short-circuit may be present and the product Made in China

should be discarded or returned to an authorized service facility pistibuted by:

for examination and/or repair. support@mrbrands.com

Fuse Replacement: LA

1. Grasp plug and remove from the receptacle or other outlet WARNING:

device. Do not unplug by pulling on cord. Cancer and Reproductive Harm --

2. Open fuse cover by sliding open fuse access cover on top of www.P65Warnings.ca.gov

attachment plug towards blades. See Fig. 2. Rev. 10/31/23

3. Remove fuse carefully. Use a small tool to pry the end of the

e- from holder cavity. Be careful not to break glass window

OCR review notes

No OCR text recovered from source page 4