EZ Chill 20-inch Box Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01284

Original source file(s): 01284.Instruction Manual.01.pdf

Source SHA-256: 92e824b464289b5e1992d33b0d26eb597b2994a3d8799b1c912b6c4653b5c6c3

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

01284

CUSTOMER ASSISTANCE:

FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR

FAN.

Made in China

Distributed by:

Mr. Brands LLC

286.00 mm

210.00 mm

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given

in lieu of all other warranties.

Source page 1 - Panel 1 (top left) (OCR)

- 286.0

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE:

FOR IMMEDIATE CUSTOMER SERVICE, CALL:1-877-420-7555.

ACUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR

FAN.

Made in China

Distributed by:

Mr. Brands LLC

L\ none

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Source page 1 - Panel 2 (top right) (OCR)

Omm as

|

EZ CHILL 01284

| UIs idaaat a 77 eee RY eaten

| u i |

4 { ins AU nt

i Wi sstttnas | LNG \ ;

REE, 0) UT

+ iy l q |

rT

20" Box Fan

Features:

¢ Rotary Switch with 3-Speed Settings

1-Low, 2-Med and 3-High

© Convenient Carry Handle

e Lightweight

e Maximum Air Movement

e Aerodynamic Shaped Fan Blades

¢ Safety Grilles

e Easy no tool assembly

¢ 120V A.C. / 60HZz.

Save These Instructions

Source page 1 - Panel 3 (bottom left) (OCR)

INTENDED USE: scant anaom READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with INSTR UCTI (e) N Ss

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING* to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

¢ Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

* Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

= near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface .

(a) which might allow fan to tip or fall. CAUTION: To Prevent Electric Shock, this product has a

© For proper operation, fan should be placed on a smooth, polarized two prong plug (one blade is wider than the other) that

(a) non-combustible, level surface. must be fully inserted in to a matching properly grounded outlet.

* Always unplug fan when not in use, when moving from place This plug is designed to fit a polarized outlet only one way. If the

. to place, when assembling or disassembling parts, and before plug does not fit fully into the outlet, reverse the plug. If the plug

(a) cleaning. still does not fit, contact a qualified electrician. Do not attempt to

* The use of attachments, not recommended or sold by the defeat this safety feature

. ae pranlactures may cause hazards. WARNING: TO REDUCE THE RISK OF FIRE OR

WN - . . ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic with throw rugs, runners or the like, Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving Parts. . less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed,

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 1 - Panel 4 (bottom right) (OCR)

USAGE: Care and Maintenance:

Cleaning: CAUTION-Before cleaning the fan be sure to

Fan Operation: Always operate the fan in the upright position disconnect power cord from the plug. Clean the grille

following all instructions and recommendations listed in this surface with a clean damp cloth. Do not use harsh chemical

manual. or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY

WIRES IN WATER. Allow fan to dry completely before use.

Fan Location: Place the fan in the area of the room that will Periodic grille cleaning with a vacuum will prevent dust build

provide proper fan cooling. up. The motor is sealed and does not require any interior

maintenance, cleaning or lubrication.

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall Maintenance: The Internal motor bearings are permanently

outlet. Be sure plug fits tightly in outlet. A loose connection may lubricated at the factory and do not require any additional

cause overheating and damage to the plug or fan. lubrication.

Note: To prevent overloading a circuit, do not plug the fan into a

circuit that is servicing other electrical needs. Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR

Turning Fan On: To start the fan, turn rotary dial on Control BECOME DAMAGED IN ANY WAY.

Panel to desired speed setting.

p 9 Storage: Keep original carton for storage of the fan. Coil and tie

Control Panel the power cord to avoid damage during storage.

Ver 0- Off

kad a 1-Low

2 - Medium Note: Some models come with a plug where you can replace a

3 speeds 3 - High fuse. If your model has this, please read and follow the below

So! instructions to replace the fuse.

Rotate ON/OFF dial to OFF to discontinue use. Unplug fan when | This product employs overload protection (fuse). A blown fuse

not in use. indicates an overload or short-circuit situation. If the fuse blows,

unplug the product from the outlet. Replace the fuse as per

ASSEMBLY INSTRUCTIONS: the user servicing instructions (follow product marking for

Simple assembly is required to use this fan on a table or floor. Proper fuse rating) and check the product. If the replacement

i" a fuse blows, a short-circuit may be present and the product

Plastic feet are provided for required stability, and must be . , . a

installed to insure safe operation. Insert each into one of the two should be discarded or returned to an authorized service facility

slots located on the bottom side of the metal fan housing, Snap | f°" &xamination and/or repair.

legs to fan cradle. Short side of base leg should face the front of F Repl ts

the fan, long side should face the back of the fan. use heplacement:

1. Grasp plug and remove from the receptacle or other outlet

device. Do not unplug by pulling on cord.

ess ici

= = 2. Open fuse cover by sliding open fuse access cover on top of

ea - SS attachment plug towards blades. See Fig. 2.

3 - 3. Remove fuse carefully. Use a small tool to pry the end of the

y ee fuse from holder cavity. Be careful not to break glass window.

AN 9 4. Replace fuse. WARNING: Risk of fire. Replace fuse only with

identical 2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm).

Stabilizing Feet Besure fuse is properly seated within its cavity.

5. Close fuse cover by sliding it back to its original closed

position.

Fig 1 Fig 2 Fig 3

rr - |r

=I i | ba od

Slide Cover to Open