EZ Chill 12-inch Table Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01286

Original source file(s): 01286.Instruction Manual.01.pdf

Source SHA-256: 1e46ce946d746aa0792d77970320e3194ca89be6bb5691c9095c5e18a156c328

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 (embedded text)

Save These Instructions

Features:

• Wide Area Oscillation

• Push Button ON/OFF Switches with

3 Speed Settings

• High Performance Fan Blade

• Adjustable Tilt

• Safety Grilles

• 120V A.C. / 60Hz.

01286

12" Table Fan

Source page 2 (embedded text)

22

INTENDED USE:

not for industrial or other commercial applications. Use only with

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we

have used the word "WARNING" to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result

in injury or death.

IMPORTANT INSTRUCTIONS

As with all electrical appliances, basic safety precautions should

injury to persons, including the following precautions:

· Read all the instructions before using this fan.

· Use this fan only as described in this manual. Any other use not

recommended by the manufacturer may cause electrical shock,

· Do not operate the fan with a damaged power cord or after the

fan malfunctions or has been dropped in any manner.

· Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is left operating unattended.

· Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.

· For proper operation, fan should be placed on a smooth, non-combustible, level surface.

· Always unplug fan when not in use, when moving from place to place, when assembling or disassembling parts, and before **cleaning.**

· The use of attachments, not recommended or sold by the manufacturer, may cause hazards.

· Do not use outdoors.

· Do not use fan in window. Rain may cause electrical hazard (for non-window models).

· Do not operate the fan with blade guards or any safety device removed.

extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts.

· Do not run power cord under carpeting. Do not cover cord with area where it will not be tripped over.

· Do not insert or allow any object to enter any openings on the Avoid contact with moving parts.

· This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

· Children should be supervised to ensure they do not play with the appliance.

READ & SAVE THESE INSTRUCTIONS

WARNING: SHOCK HAZARD

Use your fan only in dry environments. This fan is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. Do not use in damp environments such as

WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

Fans have arcing or sparking parts inside. Do not use near block air intakes or exhaust in any manner. Do not insert or allow

foreign objects to enter any ventilation or exhaust opening as this

WARNING: ELECTRICAL SHOCK HAZARD

Do not use with damaged cord or plug. Use with adequate electrical system that is up to code.

CAUTION: TO PREVENT ELECTRIC SHOCK,

this product has a polarized two prong plug (one blade is wider than the other) that must be fully inserted in to a matching electrician. Do not attempt to defeat this safety feature

WARNING: TO REDUCE THE RISK OF FIRE OR

ELECTRIC SHOCK, do not use this product with any solid-state speed control device.

DO NOT operate any fan with a damaged cord or plug or after fan malfunctions, has been dropped or damaged in any manner. Do not operate fan with a broken blade, safety cage or any visual imperfections. Disconnect power before servicing.

DO NOT run power cord under carpeting. DO NOT cover cord with throw rugs, runners or the like. Arrange cord away from be used, the cord must be minimum 14 AWG and rated not less then 1875 watts. Do not use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not in use. Do not operate fan with its ventilation obstructed.

Source page 3 (embedded text)

33

USAGE:

Fan Operation: Always operate the fan in the upright position following all instructions and recommendations listed in this manual.

Fan Location: Place the fan in the area of the room that will provide proper fan cooling.

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

CONTROL PANEL

Turning Fan On/Off: Place fan on stable level surface. Plug fan into properly grounded outlet. To start the fan, press desired speed button: 1-LOW, 2 -MED, 3 -HIGH. Press 0 -OFF to discontinue use. Unplug fan when not in use.

Oscillation: To start fan oscillation, press Oscillation Control Knob (located above motor housing) down.To stop oscillation function pull Oscillation Control Knob up while the fan is in any

oscillation position.

Fan Assembly:

Assembly is required to use this fan.

On/Off Speed Control

Oscillation Control Knob

Step 1

Step 2

Screw

Screw

Wire Goes

Through

Opening

and Guide

Remove two (2) screws from base of fan and save them for Step #2.

Place power cord wire through opening of plastic fan base. With cord opening properly positioned, snap plastic fan base onto fan body. Re-assemble screws removed in Step #1.

Remove the Blade Cap by twisting it CLOCKWISE while holding the metal shaft tightly.

Note: Threads are reversed.

Unscrew = Clockwise.

L

o

o

s

e

n

Step 3

Assemble Rear Grille onto Motor into alignment pins on fan motor housing as shown.

Note: Wire Handle should be on top.

Step 4

Alignment Pins

Thread Locknut onto Motor Housing to lock Rear Grille in

place. Tighten=Clockwise.

T

i

g

h

t

e

n

Step 5

Remove any protective covering over shaft before fan blade **installation. Place fan blade** onto motor shaft. Notice the pin slots of fan blade.

Step 6

T

i

g

h

t

e

n

Step 7

Step 8

Thread blade cap onto threaded end of the motor shaft. Note: Threads are reversed at this connection.

Tighten=Counter-clockwise

With logo upright, attach Front Grille to Rear Grille by snapping them together. Be sure all 8 clips are secure. Do not operate fan without grille in place.

Source page 4 (embedded text)

44

Care and Maintenance:

Cleaning: CAUTION -Before cleaning the fan be sure to disconnect power cord from the plug. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN

WATER. Replace front grille before fan use. Allow fan to dry completely before use. Periodic grille cleaning with a vacuum will prevent dust build up. The motor is sealed and does not require any interior maintenance, cleaning or lubrication.

Maintenance: The Internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

Note: Some models come with a plug where you can replace a fuse. If your model has this, please read and follow the below instructions to replace the fuse.

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades. See Fig. 2.
3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window. identical 2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is properly seated within its cavity.
5. Close fuse cover by sliding it back to its original closed position.

Fig 1

Slide Cover to Open

Fig 2

Fig 3

CUSTOMER ASSISTANCE:
FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555. A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR FAN.

Made in China

Distributed by:

Mr. Brands LLC

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse,** abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this **warranty. Mr. Brands LLC will not be held liable for any** losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**