EZ Chill 16-inch Oscillating Stand Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01289

Original source file(s): 01289.Instruction Manual.01.pdf

Source SHA-256: 5754e5034f10b16df9dd50c9375adc65883dd01fac8c4abf6847c2eea7eb600d

Original PDF pages: 3 | Recovered reading units: 6

Source page 1 (embedded text)

1

145.00 mm

210.00 mm

2:1(5

6 0$18$/

16" STAND FAN

,7(0 12 xxxxx 01289

Source page 2 (embedded text)

2

3

rotating it counterclockwise.

Tighten the blade cap (2) by turning it counterclockwise.

on the nut. Do not fully tighten at this stage.

OPERATING THE FAN.

counterclockwise

Source page 3 (embedded text)

4

5

Be sure not to allow water or other liquid into the motor.

Distributed by,

Mr. Brands LLC

1-877-420-7555

Made in China

Source page 3 - OCR transcription (OCR)

OPERATION INSTRUCTIONS Distributed by,

« Place your fan on a level and dry surface. Mr. Brands LLC

e Plug the power cord into a standard 120V AC, 60HZ outlet. Please make sure the 1-877-420-7555

Selector (Speed Control) is in the OFF position. Select the desired speed setting. . .

There are 4 settings - 0 (off), 1 (low), 2 (medium) and 3 (high). Made in China

« The fan can be set to oscillate by pushing Oscillating Knob downwards. To stop the

oscillating feature, pull-up the Oscillation Knob.

e To adjust the tilt angle of fan head upward or downward by simply moving the guard

up or down.

Caution: The fan should always be switched off when making this adjustment.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by

pulling on cord

2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards

blades. (see fig.1)

3. Remove fuse carefully. Remove the fuse by prying it out carefully. (see fig.2)

4. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse.

5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug. (see

fig.3).

6. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that

should not be removed. Discard product if the attachment plug is damaged.

- e-_

Fig. 1 Fig. 2 Fig. 3

Tips: Do not overexert when replacing the fuse or damage may occur. If it’s hard to close

the access cover, make sure the fuse is fully inserted.

1. Be sure to unplug from the electrical supply source before cleaning.

2.Plastic parts should be cleaned with mild soap and damp cloth or sponge.

Thoroughly remove soap film with clean water.

3. Be sure not to allow water or other liquid into the motor.

4 5