EZ Chill 8-inch High Velocity Turbo Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01300

Original source file(s): 01300.pdf

Source SHA-256: 0f50146b9cc1b783acb5050b9d63a5301df9ba9dd400f43b12d9d280caa80825

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

EZ CHILL oc

SS

Bs)

iT | 1 H

8" High Velocity Turbo Fan

Features:

e ON/OFF Switch with 3 Speed Settings

e Adjustable Tilt

¢ Quiet Vibration-Free Performance

e Wall Mountable (Select models only)

e 120V A.C. / 60Hz

BFT-8A @.

Source page 2 - OCR transcription (OCR)

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, INSTRUCTIONS !

not for industrial or other commercial applications. Use only with

electrical wiring that is in good working order and that meets WARNING: SHOCK HAZARD

applicable codes and ordinances. If you have any questions Use your fan only in dry environments. This fan is not intended

whether your wiring is adequate, consult a qualified electrician. for use in a bathroom, laundry area, or similar locations, or near

sinks, washing machines, swimming pools or other sources of

While using your fan, you should follow the IMPORTANT water. Never locate fan where it may fall into a bathtub or other

INSTRUCTIONS listed below. As part of those instructions, we water receptacle. Do not use in damp environments such as

have used the word "WARNING* to indicate the level of hazard: flooded basements.

WARNING indicates a hazard which, if not avoided, could result

in injury or death. WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in

IMPORTANT INSTRUCTIONS: use, to avoid burns, do not let bare skin touch hot surfaces,

WARNING: FIRE HAZARD

As with all electrical appliances, basic safety precautions should Fans have arcing or sparking parts inside. Do not use near

always be followed to reduce the risk of electric shock, fire, or combustible materials or flammable gases or sources of heat. Do

injury to persons, including the following precautions: not use in areas where gasoline, paint or flammable materials are

© Read all the instructions before using this fan. used or stored. To prevent a possible fire, do not block air intakes

* Use this fan only as described in this manual. Any other use not | °F exhaust in any manner. Do not insert or allow foreign objects

recommended by the manufacturer may cause electrical shock, | t0 enter any ventilation or exhaust opening as this may cause an

fire or injury to persons. electric shock, fire, or damage the fan.

* Do not operate the fan with a damaged power cord or after the WARNING: ELECTRICAL SHOCK HAZARD

fan malfunctions or has been dropped in any manner. Do not use with damaged cord or plug. Use with adequate

* Use of extreme caution is necessary when any fan is used by or | electrical system that is up to code.

near children, disabled persons or pets and whenever the fan is

left operating unattended. CAUTION: TO PREVENT ELECTRIC SHOCK,

* Do not place the fan on a small, unlevel, uneven or any surface this product has a polarized two prong plug (one blade is wider

which might allow fan to tip or fall. than the other) that must be fully inserted in to a matching

« For proper operation, fan should be placed on a smooth, properly grounded outlet. This plug is designed to fit a polarized

non-combustible, level surface. outlet only one way. If the plug does not fit fully into the outlet,

* Always unplug fan when not in use, when moving from place reverse the plug. If the plug still does not fit, contact a qualified

to place, when assembling or disassembling parts, and before electrician. Do not attempt to defeat this safety feature.

cleaning.

* The use of attachments, not recommended or sold by the CAUTION: TO REDUCE THE RISK OF FIRE OR

manufacturer, may cause hazards. ELECTRIC SHOCK, do not use this product with any

solid-state speed control device.

* Do not use outdoors.

* Do not use fan in window. Rain may cause electrical hazard DO NOT operate any fan with a damaged cord or plug or after

(for non-window models). fan malfunctions, has been dropped or damaged in any manner.

* Do not operate the fan with blade guards or any safety device Do not operate fan with a broken blade, safety cage or any visual

removed. imperfections. Disconnect power before servicing.

Avoid the use of extension cords due to risk of fire. If an

extension cord must be used, the cord must be minimum DO NOT run power cord under carpeting. Do not cover cord

14 AWG and rated not less then 1875 watts. with throw rugs, runners or the like. Arrange cord away from

* Do not run power cord under carpeting. Do not cover cord with | traffic area where it will not be tripped over. Avoid the use of

throw rugs, runners or the like. Arrange cord away from traffic extension cords due to risk of fire. If an extension cord must

area where it will not be tripped over. be used, the cord must be minimum 14 AWG and rated not

* Do not insert or allow any object to enter any openings on the _|_ess then 1875 watts. Do not use an extension cord unless the

fan. Doing so may cause electric shock and/or fire hazard. plug can be completely inserted into its receptacle. Unplug

Avoid contact with moving parts. the fan when not in use. Do not operate fan with its ventilation

* This appliance is not intended for use by persons (including obstructed.

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

USAGE:

a

Fan Operation: Always operate the fan in the upright position ~~ / Ft st

following all instructions and recommendations listed in this fares

manual. Ay i~¥ iy

Fan Location: Place the fan in the area of the room that will KLIS

provide proper fan cooling. -- |

2,

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz ~ \\\)),\ |

wall outlet. Be sure plug fits tightly in outlet. A loose connection (Zh ~eZ)

may cause overheating and damage to the plug or fan. K(i -

(WZ

Note: To prevent overloading a circuit, do not plug the fan into SSS,

a circuit that is servicing other electrical needs.

Turning Fan On/Off: To start the fan, rotate Control Dial from Fig 1

OFF position to desired fan speed (LOW, MEDIUM or HIGH).

Rotate dial to OFF to discontinue use. Unplug fan when not

in use.

(Select models only) ; iA -N

LW,

This fan comes with an optional wall mounting bracket HE IN

(assembled at bottom of the fan). | Es } y) i

1. Use the wall mounting bracket as a template to mark your ® in [Of y

mounting location before you attach the bracket to the fan. ZX (i LS

Note: Fan should be level when mounted and at least one of (we WH

the two mounting screw locations should be a wall stud. AWS

2. Place wall mounting bracket on the bottom of the fan and

attach it to the fan using the three enclosed screws as shown

in Fig. 1.

3. Place appropriate fastener into wall. Fasteners can be Fig 2

purchased at your local hardware store or home center. The

fastener head must fit properly into mounting holes located

‘on wall mounting bracket. Please leave about 3/8" of space

between the fastener head and the wall surface for the

fastener to properly slot into the wall mounting bracket holes.

4. Mount fan with attached wall mounting bracket to fasteners on

the wall. Check to be sure that the fan is secure on the wall as

shown in Fig. 2.

Source page 4 (embedded text)

support@mrbrands.com

www.mrbrands.com

Source page 4 - OCR transcription (OCR)

CARE AND MAINTENANCE: Warranty:

. . This unit is guaranteed to the original retail purchaser

Cleaning: CAUTION-Before cleaning the fan be sure to against defects in quality or workmanship for a period of

disconnect Power cord from the plug. Clean the grille surface one year from the date of original purchase. If this unit

with a clean dame fot. Do not ee harsh rem Veal or abrasive fails because of a manufacturing defect within 30 days of

WATER. Allow fan to dry completely before use. Periodic grille purchase, return the unit, with your receipt, to the retailer.

cleaning with a vacuum will prevent dust build up. The motor is After 30 days, but within the warranty Period, if the unit

sealed and does not require any interior maintenance, cleaning was purchased within the continental United States,

or lubrication. return it, to Mr. Brands LLC for repair or replacement. If

the unit was purchased outside the continental United

Maintenance: The Internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY. including the warranties of merchantability and of fitness

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

Note: Some models come with a plug where you can replace a fuse. If your model has this, please read and follow the instructions to replace the fuse.

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.

2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades. See Fig. 2

3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.

4. Replace fuse.

WARNING: Risk of fire. Replace fuse only with identical A

, WARNING:

5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is

Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded.

Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE:

a FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR FAN.

Mr. Brands LLG

support@mrbrands.com

www.mrbrands.com

, WARNING:

Cancer and Reproductive Harm -

properly seated within its cavity. ‘www.P65Warnings.ca.gov

5. Close fuse cover by sliding it back to its original closed Rev. 04/11/23

position.

Fig 1 Fig 2 Fig 3

Slide Cover to Open

== | == Bhp = jgu

ee