EZ Chill 9-inch High Velocity Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01308

Original source file(s): 01308.pdf

Source SHA-256: 4dcaf0c317a1da81d36d803adb132d97d09b8f4e6559783c8b4cead13263489e

Original PDF pages: 4 | Recovered reading units: 4

Source page 1 - OCR transcription (OCR)

E2Z-CHILL 01908

SUGRETy,

St

(ND

== Zz

<< = - =

\ Sess Ss

SZ ym PSS

| COPE CON SS

m

9" HIGH VELOCITY FAN

Features:

* ON/OFF Switch with

Speed Settings

¢ Adjustable Tilt

* Quiet Vibration Free

Performance

* All Metal Construction

¢ Metal Fan Blades

* Safety Grilles

+ 120V A.C. / 60Hz. él)

FDB-9 intertek

Source page 2 - OCR transcription (OCR)

INTENDED USE: sam READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with | INSTRUCTIONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING' to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

* Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, | block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: TO PREVENT ELECTRIC SHOCK,

* For proper operation, fan should be placed on a smooth, this product has a polarized two prong plug (one blade is wider

non-combustible, level surface. than the other) that must be fully inserted intoa matching ;

* Always unplug fan when not in use, when moving from place properly grounded outlet. This plug is designed to fit a polarized

to place, when assembling or disassembling parts, and before | Sutlet only one way. If the plug does not ft fully into the outlet,

cleaning. reverse the plug. If the plug still does not fit, contact a qualified

« The use of attachments, not recommended or sold by the electrician. Do not attempt to defeat this safety feature

« manufaoturen may cause hazarcs WARNING: TO REDUCE THE RISK OF FIRE OR

° ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with | DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic. with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

prea by a person responsible for their cafe. USAGE:

* Children should be supervised to ensure they do not play with

the appliance. Fan Operation: Always operate the fan in the upright position

following all instructions and recommendations listed in this

manual.

Source page 3 (embedded text)

support@mrbrands.com

Source page 3 - OCR transcription (OCR)

Fan Location: Place the fan in the area of the room that will identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Besure

provide proper fan cooling. fuse is properly seated within its cavity.

. . 7 5. Close fuse cover by sliding it back to its original closed

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall position.

outlet. Be sure plug fits tightly in outlet. A loose connection may

cause overheating and damage to the plug or fan. Fig 1 Fig 2 Fig 3

Note: To prevent overloading a circuit, do not plug the fan into

a circuit that is servicing other electrical needs. - ile a = =| Lane -

Turning Fan On: To start the fan, turn the switch from the OFF = wo |-|~ _ '

position to the desired fan speed. Slide Coverte Open ss

Turning Fan Off: To turn the fan off, turn the switch from the Warranty:

current fan speed setting to the off position. Remove plug from This unit is guaranteed to the original retail purchaser

outlet. against defects in quality or workmanship for a period of

--- one year from the date of original purchase. If this unit

fails because of a manufacturing defect within 30 days of

CARE AN D MAI NTENANCE: purchase, return the unit, with your receipt, to the retailer.

After 30 days, but within the warranty period, if the unit

Cleaning: CAUTION-Before cleaning the fan be sure to was purchased within the continental United States,

disconnect power cord from the plug. Unscrew and remove return it, to Mr. Brands LLC for repair or replacement. If

front rite on Clean the rile and fan blade Surface with a the unit was purchased outside the continental United

clean damp cloth. Do not use harsh chemical or abrasive States, return the unit to the place of purchase. This

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN

WATER. Replace front grille before fan use. Allow fan to dry we erheating or attention tatane Poe ty cayone

completely before use. Periodic grille cleaning with a vacuum other than Mr. Brands LLC are not covered in this

will prevent dust build up. The motor does not require any . " .

interior maintenance, cleaning or lubrication. warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties,

Maintenance: The Internal motor bearings are permanently including the warranties of merchantability and of fitness

lubricated at the factory and do not require any additional of purpose, if applicable, are hereby limited in duration to

lubrication. the period of one year from the date of original retail

purchase. Some states do not allow limitations on how

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN long an implied warranty lasts, so the above limitations

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR may not apply to you. Incidental or consequential

BECOME DAMAGED IN ANY WAY. damages arising from a breach of either express or

STORAGE: Keep original package for storage of the fan. Coil implied warranties are hereby disclaimed and excluded.

and tie the power cord to avoid damage during storage. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or

Note: Some models come with a plug where you can replace a exclusion may not apply to you. Upon the expiration of

fuse. If your model has this, please read and follow the below this warranty all such liability will terminate. No other

instructions to replace the fuse. warranties are expressed or implied. This warranty gives

Tis post ong ovat poate fenton ue | OUSPERME el as ado may asa

indicates an overload or short-circuit situation. If the fuse blows, . . Sia

unplug the product from the outlet. Replace the fuse as per settlement mechanisms are available. This limited

the user servicing instructions (follow product marking for warranty is given in lieu of all other warranties.

proper fuse rating) and check the product. If the replacement

fuse blows, a short-circuit may be present and the product

should be discarded or returned to an authorized service facility CUSTOMER ASSISTANCE:

for examination and/or repair. FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

. ANY QUESTIONS REGARDING YOUR FAN.

Fuse Replacement: Mave in China

1. Grasp plug and remove from the receptacle or other outlet Distributed by:

device. Do not unplug by pulling on cord. Mipport@mrbrands.com

2. Open fuse cover by sliding open fuse access cover on top of

attachment plug towards blades. See Fig. 2. L\ nunc:

3. Remove fuse carefully. Use a small tool to pry the end of the Cancer and Reproductive Harm --

fuse from holder cavity. Be careful not to break glass window. www.P65Warnings.ca.gov

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with Rev. 03/11/23

OCR review notes

No OCR text recovered from source page 4