EZ Chill 14-inch High Velocity Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01310

Original source file(s): 01310.pdf

Source SHA-256: 09317a3a05c8b8fa85506e8de92539453dfb18228298d20a1350e16153573fb9

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

EZ CHILL oso

14" High Velocity Fan

Features:

¢ ON/OFF Switch with Speed Settings

e Adjustable Vertical Tilt

¢ Quiet Vibration Free Performance

e All Metal Construction

e Metal Fan Blades

¢ Safety Grilles

e 120V A.C. / 60Hz.

@.

Source page 2 - OCR transcription (OCR)

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, | INSTRUCTIONS!

not for industrial or other commercial applications. Use only with

electrical wiring that is in good working order and that meets WARNING: SHOCK HAZARD

applicable codes and ordinances. If you have any questions Use your fan only in dry environments. This fan is not intended

whether your wiring is adequate, consult a qualified electrician. for use in a bathroom, laundry area, or similar locations, or near

7 . sinks, washing machines, swimming pools or other sources of

While using your fan, you should follow the IMPORTANT water. Never locate fan where it may fall into a bathtub or other

INSTRUCTIONS listed below. As part of those instructions, we water receptacle. Do not use in damp environments such as

have used the word "WARNING" to indicate the level of hazard: flooded basements.

WARNING indicates a hazard which, if not avoided, could result

in injury or death. WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in

IMPORTANT INSTR UCTIONS use, to avoid burns, do not let bare skin touch hot surfaces.

, . . | . WARNING: FIRE HAZARD

As with all electrical appliances, basic safety precautions should Fans have arcing or sparking parts inside. Do not use near

always be followed to reduce the risk of electric shock, fire, or combustible materials or flammable gases or sources of heat. Do

injury to persons, including the following precautions: not use in areas where gasoline, paint or flammable materials are

used or stored. To prevent a possible fire, do not block air intakes

* Read all the instructions before using this fan. or exhaust in any manner. Do not insert or allow foreign objects

* Use this fan only as described in this manual. Any other use not | to enter any ventilation or exhaust opening as this may cause an

recommended by the manufacturer may cause electrical shock, | electric shock, fire, or damage the fan.

fire or injury to persons.

+ Do not operate the fan with a damaged power cord orafterthe | WARNING: ELECTRICAL SHOCK HAZARD

fan malfunctions or has been dropped in any manner. Do not use with damaged cord or plug. Use with adequate

* Use of extreme caution is necessary when any fan is used by or | ¢l€Ctrical system that is up to code.

near children, disabled persons or pets and whenever the fan is CAUTION: TO REDUCE THE RISK OF FIRE OR

left operating unattended. ELECTRIC SHOCK, do not use this product with any

* Do not place the fan on a small, unlevel, uneven or any surface solid-state speed control device.

which might allow fan to tip or fall.

* For proper operation, fan should be placed on a smooth, WARNING: PREVENT ELECTRIC SHOCK

non-combustible, level surface. This product has a cord with 3-prong grounding-type plug

* Always unplug fan when not in use, when moving from place (A) which fits the 3-slot grounded receptacle (A2). DO NOT

to place, when assembling or disassembling parts, and before remove the grounding prong (A1) if only a 2-slot receptacle (B)

cleaning. is available.

* The use of attachments, not recommended or sold by the For connecting 3-prong grounding-type plug to 2-slot

manufacturer, may cause hazards. receptacle, use an ADAPTER (C). The grounding lug (C1)

* Do not use outdoors. extending from the adapter must be connected to a permanent

* Do not use fan in window. Rain may cause electrical hazard ground with the Metal Screw (D) such as a properly grounded

(for non-window models). outlet box (E).

* Do not operate the fan with blade guards or any safety device The adapter should not be used if a 3-slot grounded receptacle

removed. is available.

* Avoid the use of extension cords due to risk of fire. If an DO NOT DEFEAT THE SAFETY PURPOSE OF EITHER

extension cord must be used, the cord must be minimum A GROUNDED PRONG OR A GROUNDING LUG.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with (2 (8) (3)

throw rugs, runners or the like. Arrange cord away from traffic ()

area where it will not be tripped over. (A) () (11)

* Do not insert or allow any object to enter any openings on the (1)) (1))

fan. Doing so may cause electric shock and/or fire hazard. 8 @ peo --} w

Avoid contact with moving parts. | @I]@} oO 4) @)

* This appliance is not intended for use by persons (including (At) (1)

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have ‘Adapter is not included

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

DO NOT operate any fan with a damaged cord or plug or after

fan malfunctions, has been dropped or damaged in any manner. CARE AND MAINTENANCE

Do not operate fan with a broken blade, safety cage or any visual | Cleaning: CAUTION-Before cleaning the fan be sure to

imperfections. Disconnect power before servicing. disconnect power cord from the plug. Unscrew and remove

front grille only. Clean the grille and fan blade surface with a

DO NOT run power cord under carpeting. Do not cover cord with | clean damp cloth. Do not use harsh chemical or abrasive

throw rugs, runners or the like. Arrange cord away from traffic cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN

area where it will not be tripped over. Avoid the use of extension WATER. Replace front grille before fan use. Allow fan to dry

cords due to risk of fire. If an extension cord must be used, completely before use. Periodic grille cleaning with a vacuum

the cord must be minimum 14 AWG and rated not less than 1875 will prevent dust build up. The motor does not require any

watts. Do not use an extension cord unless the plug can be interior maintenance, cleaning or lubrication.

completely inserted into its receptacle. Unplug the fan when not

in use. Do not operate fan with its ventilation obstructed. Maintenance: The Internal motor bearings are permanently

lubricated at the factory and do not require any additional

USAG E lubrication.

. - ; Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN

Fan Operation: Always operate the fan in the upright position PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR

folowing all instructions and recommendations listed in this BECOME DAMAGED IN ANY WAY.

manual.

. , STORAGE: Keep original package for storage of the fan. Coil and

Fan Location: Place the fan in the area of the room that will tie the power cord to avoid damage during storage.

provide proper fan cooling.

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall .

f a Note: Some models come with a plug where you can replace a

outlet. Be sure plug fits tightly in outlet. A loose connection may ©

: fuse. If your model has this, please read and follow the below

cause overheating and damage to the plug or fan. y

instructions to replace the fuse.

Note: To prevent overloading a circuit, do not plug the fan into a This product employs overload protection (fuse). A blown fuse

circuit that is servicing other electrical needs. " Se vat

indicates an overload or short-circuit situation. If the fuse blows,

Turning Fan On: To start the fan, turn the switch from the OFF unplug the product from the outlet. Replace the fuse as per

position to the desired fan speed. the user servicing instructions (follow product marking for

proper fuse rating) and check the product. If the replacement

Turning Fan Off: To turn the fan off, turn the switch from the fuse blows, a short-circuit may be present and the product

current fan speed setting to the off position. Remove plug from should be discarded or returned to an authorized service facility

outlet. for examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other

outlet device. Do not unplug by pulling on cord.

2. Open fuse cover by sliding open fuse access cover on

top of attachment plug towards blades. See Fig. 2

3. Remove fuse carefully. Use a small tool to pry the end

of the fuse from holder cavity. Be careful not to break

glass window.

4. Replace fuse.

WARNING: Risk of fire. Replace fuse only with identical

5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is

properly seated within its cavity.

5. Close fuse cover by sliding it back to its original closed

position.

Fig 1 Fig 2 Fig 3

Slide Cover to Open

- <-

Source page 4 (embedded text)

support@mrbrands.com

Source page 4 - OCR transcription (OCR)

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date

of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt,

to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to

Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place

of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone

other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful

operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited

in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an

implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of

either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of

incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all

‘such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may

also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty

is given in lieu of all other warranties.

CUSTOMER ASSISTANCE:

FOR IMMEDIATE CUSTOMER SERVICE, CALL:1-877-420-7555.

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

ANY QUESTIONS REGARDING YOUR FAN.

Made in China

Distributed by:

Mr. Brands LLG

support@mrbrands.com

Cancer and Reproductive Harm ~

www P65Warnings.ca.gov

Rev. 03/11/23