EZ Chill 12-inch Table Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01314

Original source file(s): 01314.pdf

Source SHA-256: a922e3c6151e6a82ff72195a4753164c873e7c9ca1d8c80b54da82cdb89f61dd

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

E2ZCHILL ote

sane

MEE.

Sou! “e

roo (224 -- +4

Ss. GH), “SF

al A,

. HT sy

e

" Table F

12" Table Fan

Features:

© Wide Area Oscillation

e Push Button ON/OFF Switches with

3 Speed Settings

© High Performance Fan Blade

e Adjustable Tilt

© Safety Grilles

© 120V A.C. / 60Hz.

FD-12 Intertek

Source page 2 - OCR transcription (OCR)

Te easet I intended for indoor residential and office use only, READ & SAVE THESE

not for industrial or other commercial applications. Use only with | INSTRUCTIONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

. . combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

¢ Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: TO PREVENT ELECTRIC SHOCK, '

* For proper operation, fan should be placed on a smooth, this product has a polarized two prong plug (one blade is wider

non-combustible, level surface. than the other) that must be fully inserted in to a matching

* Always unplug fan when not in use, when moving from place properly grounded outlet. This plug is designed to fit a polarized

to place, when assembling or disassembling parts, and before | Outlet only one way, If the plug does not fit fully into the outlet,

cleanin reverse the plug. If the plug still does not fit, contact a qualified

1g. i"

« The use of attachments, not recommended or sold by the electrician. Do not attempt to defeat this safety feature

manufacturer, may cause hazards.

D ot te y 2 WARNING: TO REDUCE THE RISK OF FIRE OR

10 not use outdoors. ELECTRIC SHOCK, do not use this product with any

. ft not use fan in we, Rain may cause electrical hazard solid-state speed control device.

jor non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with | DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the tke. Arrange cord away from traffic with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

USAGE: step 3 Step 4

Fan Operation: Always operate the fan in the upright position ‘Alignment Pine

following all instructions and recommendations listed in this een ie QE iM

manual. Ry eS a wey LZ

ah,

Fan Location: Place the fan in the area of the room that will _- ? . BZ

provide proper fan cooling. y a

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall 9, \ ‘9 « (a) =

outlet. Be sure plug fits tightly in outlet. A loose connection may . Sa =

cause overheating and damage to the plug or fan. - DF ~ SS

Note: To prevent overloading a circuit, do not plug the fan into AS SS

ircuit that is servicing other electrical needs. Remove the Blade Cap by twisting Z -_ WS

a circul - it CLOCKWISE while holding the VA, \W

metal shaft tightly. - =

CONTROL PANEL Note: Threads are reversed, Assemble Rear Grile onto Motor

Unscrew = Clockwise. Housing. Rear Grille should fit

5 into alignment pins on fan motor

Ws ZF housing as shown.

Te Note: Wire Handle should be on

8 top.

|

|) NY Sf Step 5 Step 6

Wi, Z| WW TE

On/Off Speed Control Oscillation Control Knob (Ly A

a i ee

Turning Fan On/Off: Place fan on stable level surface. Plug 4 i 1G Z| = LF)

fan into properly grounded outlet. To start the fan, press i | -_ 4

desired speed button: 1-LOW, 2-MED, 3-HIGH. Press 0-OFF 3 «SN =| =

to discontinue use. Unplug fan when not in use. | ~~ SS

aati “ati “hati > SS

: r SSS

Oscillation: To start fan osoliation, press Oscillation Control A\ ~~] Remove any protective covering

nob (located above motor housing) down.To stop oscillation P| over shat before fan bade

function pull Oscillation Control Knob up while the fan is in any f \\ 00 | installation, Place fan blade

oscillation position. _ yr \\ onto motor shaft. Notice the pin

Thread Locknut onto Motor ‘on motor shaft should fit into

. Housing to lock Rear Grille in slots of fan blade.

Fan Assem bly: place. Tighten=Clockwise.

Assembly is required to use this fan.

Step 1 Step 2 Step 7 Step 8

R&R Screw ire Goes: Rr hits

Ss hrough | (> <eth

"Screw | Ppening a) ~ $y i

ey 6 and Guide.’ ma) - a |

BH et)

- ‘an< PN °

x |

Remove two (2) screws from base -_Place power cord wire through Thread blade cap onto threaded With logo upright, attach Front

of fan and save them for Step #2. opening of plastic fan base. With end of the motor shaft. Note: Grille to Rear Grille by snapping

cord opening properly positioned, Threads are reversed at this them together. Be sure all 8 clips

snap plastic fan base onto fan connection. are secure. Do not operate fan

body. Re-assemble screws Tighten=Counter-clockwise without grille in place.

removed in Step #1.

Source page 4 (embedded text)

support@mrbrands.com

Source page 4 - OCR transcription (OCR)

Care and Maintenance: Warranty: iginal retai

This unit is guaranteed to the original retail purchaser

Cleaning: CAUTION-Before cleaning the fan be sure to against defects in quality or workmanship for a period of

disconnect power cord from the plug. Clean the grille surface one year from the date of original purchase. If this unit

with a clean damp cloth. Do not use harsh chemical or abrasive fails because of a manufacturing defect within 30 days of

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN purchase, return the unit, with your receipt, to the retailer.

WATER. Replace front grille before fan use. Allow fan to dry ; After 30 days, but within the warranty period, if the unit

completely before use. Periodic grille cleaning with a vacuum will was purchased within the continental United States,

prevent dust build up. The motor is sealed and does not require 4 3

any interior maintenance, cleaning or lubrication. return it, to Mr. Brands LLC for repair or replacement. if

the unit was purchased outside the continental United

Maintenance: The Internal motor bearings are permanently States, return the unit to the place of purchase. This

lubricated at the factory and do not require any additional warranty does not cover damage caused by misuse,

lubrication. abuse, overheating or alteration. Repairs made by anyone

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN other than Mr. Brands LLC are not covered in this

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR warranty. Mr. Brands LLC will not be held liable for any

BECOME DAMAGED IN ANY WAY. losses due to neglectful operation. All implied warranties,

Storage: Keep original carton for storage of the fan. Coil and tie including the warranties of merchantability and of fitness

the power cord to avoid damage during storage. of purpose, if applicable, are hereby limited in duration to

the period of one year from the date of original retail

MM). MM-w--- purchase. Some states do not allow limitations on how

Note: Some models come with a plug where you can replace a long an implied warranty lasts, so the above limitations

fuse. If your model has this, please read and follow the below may not apply to you. Incidental or consequential

instructions to replace the fuse. damages arising from a breach of either express or

This product employs overload protection (fuse). A blown fuse implied warranties are hereby disclaimed and excluded.

indicates an overload or short-circuit situation. If the fuse blows, Some states do not allow the exclusion of limitation of

unplug the product from the outlet. Replace the fuse as per incidental or consequential damages, so this limitation or

the user servicing instructions (follow product marking for proper exclusion may not apply to you. Upon the expiration of

fuse rating) and check the product. If the replacement fuse this warranty all such liability will terminate. No other

blows, a short-circuit may be present and the product should warranties are expressed or implied. This warranty gives

be discarded or returned to an authorized service facility for you specific legal rights, and you may also have other

examination and/or repair. rights which vary from state to state. No informal dispute

Fuse Replacement: settlement mechanisms are available. This limited

warranty is given in lieu of all other warranties.

1. Grasp plug and remove from the receptacle or other outlet

device. Do not unplug by pulling on cord.

2. Open fuse cover by sliding open fuse access cover on top of CUSTOMER ASSISTANCE:

attachment plug towards blades. See Fig. 2. FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

3. Remove fuse carefully. Use a small tool to pry the end of the A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

fuse from holder cavity. Be careful not to break glass window. ANY QUESTIONS REGARDING YOUR FAN.

4, Replace fuse. WARNING: Risk of fire. Replace fuse only with Distributed by:

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse Mr. Brands LLC

is properly seated within its cavity. support@mrbrands.com

5. Close fuse cover by sliding it back to its original closed /\

position. WARNING:

Cancer and Reproductive Harm -

. . . www.P65Warnings.ca.gov

Fig 1 Fig 2 Fig 3

Rev. 03/11/23

DI ye | Se pe SS tes

Slide Cover to Open ss

TTT ED