EZ Chill 16-inch Table Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01315

Original source file(s): 01315.pdf

Source SHA-256: e1f28b02f4e7ed102afecb315d2c5044b81a492a2c368994f4dc1f6d53074719

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

EZCHILL ots

TT

C5 LH EAS .

eu Wy PLS

oe W/o

FSS. tt “St

15> cil) #

pa #

a WO

ON Yoo”

ena ll MSs

" Tabl

16” Table Fan

Features:

* Wide Area Oscillation

* Push Button

ON/OFF Switches

and 3 Speed Settings

* High Performance

Fan Blade

¢ Adjustable Tilt

* Safety Grilles

*** 120V A.C. / 6OHz. @**

FD-16 intertek

Source page 2 - OCR transcription (OCR)

Intended Use: Shock Hazard

This product is intended for indoor residential and office use only, Use your fan only in dry environments. This fan is not intended

not for industrial or other commercial applications. Use only with for use in a bathroom, laundry area, or similar locations, or near

electrical wiring that is in good working order and that meets sinks, washing machines, swimming pools or other sources of

applicable codes and ordinances. If you have any questions water. Never locate fan where it may fall into a bathtub or other

whether your wiring is adequate, consult a qualified electrician. water receptacle. Do not use in damp environments such as

flooded basements.

While using your fan, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we Hot Surfaces

have used the word "WARNING" to indicate the level of hazard: Do not touch fan motor when in use. This motor is hot when in

WARNING indicates a hazard which, if not avoided, could result use, to avoid burns, do not let bare skin touch hot surfaces.

in injury or death.

Fire Hazard

IMPORTANT INSTRUCTIONS Fans have arcing or sparking parts inside. Do not use near

As with all electrical appliances, basic safety precautions should combustible materials or flammable gases or sources of heat.

always be followed to reduce the risk of electric shock, fire, or DO NOT USE in areas where gasoline, paint or flammable

injury to persons, including the following precautions: materials are used or stored. To prevent a possible fire, do not

block air intakes or exhaust in any manner. Do not insert or allow

* Read all the instructions before using this fan. foreign objects to enter any ventilation or exhaust opening as this

Use this fan only as described in this manual. Any other use not may cause an electric shock, fire, or damage the fan.

recommended by the manufacturer may cause electrical shock,

fire or injury to persons. Electrical Shock Hazard

* Do not operate the fan with a damaged power cord or after the Do not use with damaged cord or plug. Use with adequate

fan malfunctions or has been dropped in any manner. electrical system that is up to code.

* Use of extreme caution is necessary when any fan is used by or

near children, disabled persons or pets and whenever the fan is to Prevent Electric Shock, this product

left operating unattended. has a polarized two prong plug (one blade is wider than the

* Do not place the fan on a small, unlevel, uneven or any surface | other) that must be fully inserted in to a matching properly

which might allow fan to tip or fall. grounded outlet. This plug is designed to fit a polarized outlet

* For proper operation, fan should be placed on a smooth, only one way. If the plug does not fit fully into the outlet,

non-combustible, level surface. reverse the plug. If the plug still does not fit, contact a qualified

+ Always unplug fan when not in use, when moving from place electrician. Do not attempt to defeat this safety feature.

pear when assembling or disassembling parts, and before to Reduce the Risk of Fire or Electric

© The use of attachments, not recommended or sold by the Shock, do not use this product with any solid-state speed

manufacturer, may cause hazards. control device.

* Do not use outdoors. DO NOT operate any fan with a damaged cord or plug or after

* Do not use fan in window. Rain may cause electrical hazard fan malfunctions, has been dropped or damaged in any manner.

(for non-window models). Do not operate fan with a broken blade, safety cage or any visual

* Do not operate the fan with blade guards or any safety device imperfections. Disconnect power before servicing.

removed.

* Avoid the use of extension cords due to risk of fire. If an DO NOT run power cord under carpeting. DO NOT cover cord

extension cord must be used, the cord must be minimum with throw rugs, runners or the like. Arrange cord away from

14 AWG and rated not less then 1875 watts. traffic area where it will not be tripped over. Avoid the use of

* Do not run power cord under carpeting. Do not cover cord with extension cords due to risk of fire. If an extension cord must

throw rugs, runners or the like. Arrange cord away from traffic be used, the cord must be minimum 14 AWG and rated not

area where it will not be tripped over. less then 1875 watts. Do not use an extension cord unless the

* Do not insert or allow any object to enter any openings on the plug can be completely inserted into its receptacle. Unplug

fan. Doing so may cause electric shock and/or fire hazard. the fan when not in use. Do not operate fan with its ventilation

Avoid contact with moving parts. obstructed.

* This appliance is not intended for use by persons (including

children) with reduced physical, sensory or mental capabilities

or lack of experience and knowledge, unless they have

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

READ & SAVE THESE

Source page 3 - OCR transcription (OCR)

Usage: . ; 7 Step 3 Step 4

Fan Operation: Always operate the fan in the upright position VI eed

following all instructions and recommendations listed in this , i

manual. ay, \ ot Ze 2)

La Y D > g aq

Fan Location: Place the fan in the area of the room that will - : |

provide proper fan cooling. y . : a ” 2

} & =

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz = | Sa =-|

wall outlet. Be sure plug fits tightly in outlet. A loose connection I aa SS

may cause overheating and damage to the plug or fan. -@\7i% SS

Note: To prevent overloading a circuit, do not plug the fan into Remove the Blade Cap by Z iS. WS

a circuit that is servicing other electrical needs. twisting it CLOCKWISE while W, / LS

holding the metal shaft tightly.

Note: Threads are reversed. Assemble Rear Grille onto

Control Panel Oscillation Control Unscrew = Clockwise. Motor Housing. Rear Grille

- should fit into alignment pins

Ww =f] on fan motor housing as

= shown. Note: Wire Handle

3 S should be on top.

| W)

/ Es 4 Step 5 Step 6

Wve Zi Wi TA

A 7

On/Off Speed Control Oscillation Control Knob SS S OK LZ

Turning Fan On/Off: Place fan on stable level surface. -= PCy = weed >)

Plug fan into properly grounded outlet. To start the fan, press - & = -

desired speed button: 1-LOW, 2-MED, 3-HIGH. Press 0-OFF to = 2 4 =

discontinue use. Unplug fan when not in use. <<" WSs

ee NSS

Oscillation: To start fan oscillation, press Oscillation Control | Remove any protective

Knob (located above motor housing) down. Pi \\ \ NY '| covering over shaft before fan

To stop oscillation function pull Oscillation Control Knob up while i y \ \\\\ _| blade installation. Place fan

the fan is in any oscillation position. blade onto motor shaft. Notice

Thread Locknut onto Motor the pin on motor shaft should

Housing to lock Rear Grille in fit into slots of fan blade.

place. Tighten=Clockwise

Fan Assembly: Assembly is required to use this fan.

Step 1 Step 2 Step 7 Step 8

Ss Wire Goes Fl /

SJ frou A2vl= pyle =

and Guide De l\ ~ y lo) , i+

Cee

. a aa

mm |

Remove two @ screws fom Place power cord wire through Thread blade cap onto With logo upright, attach

ase of fan and save them for opening of plastic fan base. threaded end of motor Front Grille to Rear Grille by

Step #2 with cord opening properly shaft. Note: Threads are snapping them together. Be

Positioned, snap plastic reversed at this connection. sure all 8 clips are secure.

fan base onto fan body. Tighten=Counter-clockwise. Do not operate fan without

Re-assemble screws removed grille in place.

in Step #1.

Source page 4 (embedded text)

support@mrbrands.com

Source page 4 - OCR transcription (OCR)

Care and Maintenance Warranty:

Cleaning: CAUTION-Before cleaning the fan be sure to This unit is guaranteed to the original retail purchaser

disconnect power cord from the plug. Clean the grille surface against defects in quality or workmanship for a period of

with a clean damp cloth. Do not use harsh chemical or abrasive one year from the date of original purchase. If this unit

cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN fails because of a manufacturing defect within 30 days of

WATER. Replace front grille before fan use. Allow fan to dry purchase, return the unit, with your receipt, to the retailer.

completely before use. Periodic grille cleaning with a vacuum will After 30 days, but within the warranty period, if the unit

Prevent dust build up. The motor 's sealed and does not require was purchased within the continental United States,

any interior maintenance, cleaning or lubrication. return it, to Mr. Brands LLC for repair or replacement. If

Maintenance: The Internal motor bearings are permanently the unit was purchased outside the continental United

lubricated at the factory and do not require any additional States, return the unit to the place of purchase. This

lubrication. warranty does not cover damage caused by misuse,

abuse, overheating or alteration. Repairs made by anyone

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN | ther than Mr. Brands LLC are not covered in this

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR warranty. Mr. Brands LLC will not be held liable for any

BECOME DAMAGED IN ANY WAY. losses due to neglectful operation. All implied warranties,

including the warranties of merchantability and of fitness

Storage: Keep original carton for storage of the fan. Coil and tie of purpose, if applicable, are hereby limited in duration to

the power cord to avoid damage during storage. the period of one year from the date of original retail

purchase. Some states do not allow limitations on how

long an implied warranty lasts, so the above limitations

may not apply to you. Incidental or consequential

damages arising from a breach of either express or

This product employs overload protection (fuse). A blown fuse implied warranties are hereby disclaimed and excluded.

indicates an overload or short-circuit situation. If the fuse blows, Some states do not allow the exclusion of limitation of

unplug the product from the outlet. Replace the fuse as per the incidental or consequential damages, so this limitation or

user servicing instructions (follow product marking for proper exclusion may not apply to you. Upon the expiration of

fuse rating) and check the product. If the replacement fuse this warranty all such liability will terminate. No other

blows, a short-circuit may be present and the product should warranties are expressed or implied. This warranty gives

be discarded or returned to an authorized service facility for you specific legal rights, and you may also have other

examination and/or repair. rights which vary from state to state. No informal dispute

Fi . settlement mechanisms are available. This limited

‘use Replacement: an a .

1. Grasp plug and remove from the receptacle or other outlet warranty is given in lieu of all other warranties.

device. Do not unplug by pulling on cord.

2. n fl ver sliding nf ver on te f

attachment plug onards Hades. SeeFig. 2 | CUSTOMER ASSISTANCE:

FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

3. Remove fuse carefully. Use a small tool to pry the end of the A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

fuse from holder cavity. Be careful not to break glass window. ANY QUESTIONS REGARDING YOUR FAN.

4, Replace fuse. WARNING: Risk of fie. Replace fuse only with | hemneaine

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure Mr. Brands LLC

fuse is properly seated within its cavity. ‘support@mrbrands.com

5. Close fuse cover by sliding it back to its original closed

Position. L\ onsnc

Cancer and Reproductive Harm -

‘www.P65Warnings.ca.gov

Rev. 03/11/23

Fig 1 Fig 2 Fig 3

~- rrr i lass er he, |

- i | |< ie