EZ Chill 16-inch Oscillating Stand Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01316

Original source file(s): 01316.pdf

Source SHA-256: 1d1c5273a2da8451801a6e42f4a3e237015578390f5915082792871ba3512e01

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

EZCHILL ora16

|

ll 7 7

16" Oscillating Stand Fan

Features:

e Patented Fast Assembly Quad-Pod® Folding Base

(US Pat. No D643230 and D646501)

e Wide Area Oscillation

© ON/OFF Switch with 3 Speed Settings

© High Performance Blades

e Adjustable Height and Vertical Tilt

© Steel Safety Grilles

© 120V A.C. / 60Hz. @

FS-16B intertek

Source page 2 - OCR transcription (OCR)

INTENDED USE: seria ana ot READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with | INSTRUCTIONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING*" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

* Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, | block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

© Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is | Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: TO PREVENT ELECTRIC SHOCK,

+ For proper operation, fan should be placed on a smooth, this product has a polarized two prong plug (one blade is wider

non-combustible, level surface. than the other) that must be fully inserted in to a matching

* Always unplug fan when not in use, when moving from place properly grounded outlet. This plug is designed to fit a polarized

to place, when assembling or disassembling parts, and before outlet only one way. If the plug does not fit fully into the outlet,

cleaning. reverse the plug. If the plug still does not fit, contact a qualified

« The use of attachments, not recommended or sold by the electrician. Do not attempt to defeat this safety feature.

. manuactures ee hazards. WARNING: TO REDUCE THE RISK OF FIRE OR

oe . . ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing.

14 AWG and rated not less then 1875 watts.

* Do not run power cord under carpeting. Do not cover cord with DO NOT run power cord under carpeting. DO NOT cover cord

throw rugs, runners or the like. Arrange cord away from traffic with throw rugs, runners or the like. Arrange cord away from

area where it will not be tripped over. traffic area where it will not be tripped over. Avoid the use of

* Do not insert or allow any object to enter any openings on the extension cords due to risk of fire. If an extension cord must

fan. Doing so may cause electric shock and/or fire hazard. be used, the cord must be minimum 14 AWG and rated not

Avoid contact with moving parts. less then 1875 watts. Do not use an extension cord unless the

* This appliance is not intended for use by persons (including plug can be completely inserted into its receptacle. Unplug

children) with reduced physical, sensory or mental capabilities the fan when not in use. Do not operate fan with its ventilation

or lack of experience and knowledge, unless they have obstructed.

been given supervision or instruction concerning use of the

appliance by a person responsible for their safety.

* Children should be supervised to ensure they do not play with

the appliance.

Source page 3 - OCR transcription (OCR)

U S AG E: Step 4 Step 5

Fan Operation: Always operate the fan in the upright position] 3 oot va, JA

following all instructions and recommendations listed in this -- & hy .

manual.

Fan Location: Place the fan in the area of the room that will Thumb

provide proper fan cooling. Screw oa

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall

outlet. Be sure plug fits tightly in outlet. A loose connection may -= a

cause overheating and damage to the plug or fan. Remove the Blade Cap by

Note: To prevent overloading a circuit, do not plug the fan into a Assemble fan Control twisting it CLOCKWISE while

Circuit that is servicing other electrical needs. Panel/Motor assembly holding the metal shaft tightly.

co NTR OL P, AN EL: onto Chrome Extension Note: Threads are reversed

- and tighten thumb screw. Unscrew = Clockwise.

his |’ Oscillation - |

on/Speed al! | Control = Sten 6 sise 7 . 5 - TM

**Controls <== Ny » Wa qo 7, ps] **

Pe Le VAR "Ny

oft | QING SO

Controls | wt) = =") z

Ds. 22 | |Z! a

r FEO A, -

WW, Ziv G7) aes ock Nat}.

On/Off Speed Controls Oscillation Control Knob \Pin Z Pin, KS

Turning Fan On/Off: Place fan on stable level surface. Assemble Rear Grile es eet ote

Plug fan into properly grounded outlet. To start the fan, Rear Grille should a Rear Grille in sce

press desired speed button: 1-LOW, 2-MED, 3-HIGH. into pins on fan motor P °

Press 0-OFF to discontinue use. Unplug fan when not in use housing sa shown

Oscillation: To start fan oscillation, press Oscillation Control

Knob (located above motor housing) down. To stop oscillation Step 8 Step 9

function, pull Oscillation Control Knob up while the fan is in any a

oscillation position. " Pin Siot J Ry

| yj PS

Fan Assembly: i, | if \ ‘a

Simple assembly is required to use this fan. ke De | < \

Step 1 Step 2 J i 1

Ti +=) a A

y, Remove any protective Thread Blade Cap onto

WS 9 covering over shaft before threaded end of Motor Shaft.

A Fan Blade Installation. Place Note: Threads are reversed.

! “a y Pole Fan Blade onto Motor Shaft. Tighten = Counter-clockwise.

. | Notice the pin on Motor Shaft

me . = should fit into slots of Fan

Unfold patented Quad-Pod® Place decorative Plastic Flange Blade.

base legs. over Extension Pole to cover

the base. Slide pedestal pole 1

Step 3 into base receptacle. Tighten Step 10 7

nut to secure in place. Slide

flange over base connection.

Pull ‘il tothe

Chrome |’ beeen

Extension ITH AN

Out Ly y

| Wy |

With logo upright, attach

) With coll it | d, i 1

7 pul Chrome Extension Front Grille to Rear Grille by

out of Fan Pedestal. snapping them together. Be

sure all 8 clips are secure.

Source page 4 (embedded text)

support@mrbrands.com

Source page 4 - OCR transcription (OCR)

Care and Maintenance Warranty:

This unit is guaranteed to the original retail purchaser

Cleaning: CAUTION-Before cleaning the fan be sure to against defects in quality or workmanship for a period of

disconnect power cord from the plus. Clean ihe rile ‘cal one year from the date of original purchase. If this unit

Surface with a clean damp cloth. Do not use harsh chemical fails because of a manufacturing defect within 30 days of

or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY purchase, return the unit, with your receipt, to the retailer.

WIRES IN WATER. Replace front grille before fan use. Allow After 30 d: but within th " iod, if th it

fan to dry completely before use. Periodic grille cleaning with er 30 days, but within the warranty period, If the unt

a vacuum will prevent dust build up. The motor is sealed and was purchased within the continental United States,

does not require any interior maintenance, cleaning or return it, to Mr. Brands LLC for repair or replacement. If

lubrication. the unit was purchased outside the continental United

States, return the unit to the place of purchase. This

Maintenance: The Internal motor bearings are permanently warranty does not cover damage caused by misuse,

lubricated at the factory and do not require any additional abuse, overheating or alteration. Repairs made by anyone

lubrication. other than Mr. Brands LLC are not covered in this

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN | Warranty. Mr. Brands LLC will not be held liable for any

PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR | !osses due to neglectful operation. All implied warranties,

BECOME DAMAGED IN ANY WAY. including the warranties of merchantability and of fitness

- | ; of purpose, if applicable, are hereby limited in duration to

Storage: Keep original carton for storage of the fan. Coil and tie the period of one year from the date of original retail

the power cord to avoid damage during storage. purchase. Some states do not allow limitations on how

| Jong an implied warranty lasts, so the above limitations

may not apply to you. Incidental or consequential

Note: Some models come with a plug where you can replace a damages arising from a breach of either express or

fuse. IF your mode! has this, please read and follow the below implied warranties are hereby disclaimed and excluded.

Instructions fo replace the Tuse. Some states do not allow the exclusion of limitation of

This product employs overload protection (fuse). A blown fuse _|_incidental or consequential damages, so this limitation or

indicates an overload or short-circuit situation. If the fuse blows, | exclusion may not apply to you. Upon the expiration of

unplug the product from the outlet. Replace the fuse as per this warranty all such liability will terminate. No other

the user servicing instructions (follow product marking for warranties are expressed or implied. This warranty gives

proper fuse rating) and check the product. If the replacement you specific legal rights, and you may also have other

fuse blows, a short-circuit may be present and the product rights which vary from state to state. No informal dispute

should be discarded or returned to an authorized service facility settlement mechanisms are available. This limited

for examination and/or repair. warranty is given in lieu of all other warranties.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet CUSTOMER ASSISTANCE:

device. Do not unplug by pulling on cord. FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

2. Open fuse cover by sliding open fuse access cover on top of A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

attachment plug towards blades. See Fig. 2. ANY QUESTIONS REGARDING YOUR FAN.

Made in China

3. Remove fuse carefully. Use a small tool to pry the end of the Distributed by

fuse from holder cavity. Be careful not to break glass window. Mr. Brands LLC

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with Supponi@mrbrands.com

identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure

fuse is properly seated within its cavity. A

sinc j te or WARNING:

5. Close fuse cover by sliding it back to its original closed Cancer and Reproductive Harm -

position. www.P6sWarnings.ca.gov

7 a 7 Rev. 03/11/23

Fig 1 Fig 2 Fig3

- errr iy - |r ip 4

= ii | | <-

Slide Cover to Open