EZ Heat Digital Oil-Filled Radiator Heater with Remote

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32551

Original source file(s): 32551.Instruction Manual.01.pdf

Source SHA-256: b11ae00cd5502227d3b2d9adaddfbf0e1cd8cd3e8dc0e738c76d3e6a5f3462ef

Original PDF pages: 8 | Recovered reading units: 9

Source page 1 (embedded text)

190.00 mm

130.00 mm

2023-04-07

MG-MTOH907LC

SKU: 32551

Source page 2 - OCR transcription (OCR)

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, follow basic safety precautions to reduce the risk of fire, electrical shock, personal injury and property damage. Read all safety precautions and familiarize yourself with this manual prior to use.

WARNING: Use your heater only as described in this manual. Any other use is not recommended by the manufacturer, and can cause fire, electrical shock, personal injury and property damage.

- DONOT use your heater outdoors, or for industrial or commercial purposes. Your heater is for INDOOR HOUSEHOLD USE ONLY!

- DO NOT depend on the Power Control Switch as the sole means of disconnecting power from your heater. Disconnect the power cord from the electrical outlet when your heater is not in use, when changing locations, or prior to cleaning.

- DONOT - Use your heater on Carpeting, Vinyl Flooring, Place your heater on a stable, level surface, and route the power cord away from traffic areas.

- Connect the power cord to an easily-accessible electrical outlet so that your heater can be disconnected immediately in the event of an emergency.

- Ensure that twelve inches of clearance exists around your heater to avoid obstructing intake and exhaust flow.

- For optimal operation and to avoid overloading a circuit, connect your heater to

circuit that is not supplying power to other electrical appliances.

- DONOT operate your heater near curtains, plants, window covers, or other loose objects; such objects can become lodged in your heater’s components and cause a fire.

- NEVER cover your heater or place your heater or its power cord under rugs, carpeting or similar objects, as fire can occur.

- Your heater is not intended for use in bathrooms, laundry areas or similar damp locations.

- NEVER place your heater where it may come in contact with water or other liquids.

- DO NOT use devices that would turn your heater on and off automatically, as the use of such devices can cause a fire.

- DONOT immerse or expose your heater to any form of liquid.

- NEVER operate your heater near an open flame or in the presence of explosive or combustible gases or fumes, such as: gasoline, paint or other flammable liquids. Your heater has hot internal components.

- DO NOT expose your heater to excessive heat or humidity, as electrical component damage can occur.

- DONOT pull on the power cord. Always grasp the plug when connecting and disconnecting the power cord from the electrical outlet.

- DO NOT use extension cords with your heater. Extension cords can overheat and cause a fire.

- DONOT remove, replace, repair or tamper with the originally-supplied plug.

- NEVER attempt to open or service your heater. Doing so may cause personal injury or property damage. Should your heater or its power cord malfunction or become damaged, discontinue operation immediately and consult a qualified repair technician.

- Extreme Caution is necessary when your heater is used near children, pets and invalids. Keep your heater out of the reach of children, pets and invalids to reduce the risk of personal injury and electrical shock.

2

Source page 3 - OCR transcription (OCR)

PARTS OF THE HEATER

1

2

3

4

Bolt &Wing Nut

U-Shape

Bracket with C==f 2

Castor

5 "

P 6

PARTS OF THE HEATER

1. Oil fins (x7) DO NOT OPEN OR REFILL/CHANGE

2. Carry handle OIL FINS OIL FINS ARE PERMANTLY

3. Display SEALED AND DO NOT REQUIRE

4. Control panel REFILLING OR OIL CHANGING.

5. Power cord housing ATTEMPTING TO OPEN FINS WILL

. , DAMAGE THE UNIT. THIS UNIT IS FILLED

6. Rolling casters WITHA NON TOXIC MINERAL OIL.

CAUTION:

DO NOT OPERATE THIS HEATER WITHOUT

CASTERS ATTACHED

(okemae scl send sah

a} TW Wine” Micon fer,

Mnial CM | | |

m @ COMET

Assembly Instructions:

* Unpack the heater and remove all parts from the packaging.

1.For ease of assembly, place the heater upside down or on its side on

a soft surface which will not scratch the unit. Use one hand to hold it

in place. (1)

2.Unscrew nut and put U-shape bolt in one hole of bracket. (2)

3.Attach the bracket onto the heater with the U bolts and wing

nuts supplied as shown in 3, 4, 5.

4.Assemble another castor with bracket same with 2, 3, 4, 5.

3

Source page 4 - OCR transcription (OCR)

Instructions

Placement of the heater

1.Turn the heater upright. Ensure legs are correctly installed and level.

2.Place heater on a flat and stable surface. Setting the heater on an incline or

decline may cause damage to the unit and create a hazardous situation.

3.Proceed to OPERATING INSTRUCTIONS.

Pre-operation instructions

1. Carefully remove your heater from its shipping box. (The shipping box can be

reused for off-season storage).

2. Place your heater on a firm, level surface.

3. Completely uncoil the power cord, and connect your heater directly into a 120 Volt, grounded AC electrical outlet.

Note: The power cord has a polarized plug (with one blade wider than the other) that will only fit in a polarized outlet one way. If it does not insert easily try reversing the plug. If it still does not fit contact your electrician to replace your outlet. DO NOT defeat the safety purpose of the polarized plug.

CAUTION: TO PREVENT ELECTRIC SHOCK MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

The control panel

symbols

3 ®oc®

-Q- Low Power Level (600W) B00

0: Medium Power Level (900W) U

:O: High Power Level (1500W)

‘F Heating Mode a +

© Timer Mode = Oe

()) Power on

Controls on product

¢ (: press this button after plug in to power on the heater and start operation, or press it repeatedly to stop operation and set the heater into standby mode.

¢ Mode: use this button to set the power level.

° Timer: use this button to set the timer.

¢ [+] and [-]: use these buttons when setting the desired temperature, or for setting the timer.

4

Source page 5 - OCR transcription (OCR)

Controls on remote control «

e OWER

¢ POWER: press this button after plug in to power on the e.. heater and start operation, or press it repeatedly to stop e **operation and set the heater into standby mode. e. |**

¢ MODE: use this button to set the power level. N

¢ TIMER: use this button to set the timer.

¢ [A]and[V]: use these buttons when setting the ; : desired temperature, or for setting the timer. CHEAT)

Setting the temperature

The heater has a thermostat which enables you to set the temperature from 59°F to 95°F. Once a temperature has been set, the heater will remain on until the

room temperature has reached the temperature on the digital display. The thermostat will then cycle on and off to maintain the set room temperature.

¢ Power on the heater, the display will show 88 and keep flashing. Press Power button to set the desired power level. The desired temperature 75°F and power level will be shown and flash on the screen.

¢ Use the[+or A] and[-or V] buttons to set the desired temperature, from 56° F to 95° F.

¢ While the heater is warming up the room, the heat level symbol will keep flashing on the display until the set temperature has been reached. The symbol will stop flashing then. The heater comes on again when the room temperature drops below the desired temperature.

¢ Use the[+or A] and[-or V] buttons to change the desired room temperature at any time.

Setting the timer

When the heater is powered on. You can set the timer to switch off the

appliance automatically after a certain period of time (1 to 12 hours from the

time the function is set).

1. Power on the heater, the display will show 88 and keep flashing. Pregs, Timer button to set the desired power off time. The display will show 00 and start flashing on the screen.

2. Use the [A] and[V] buttons to set the heater operation time (between 1 and 12 hours). The function will activate once the timer icon stops flashing.

3. The heater will cycle on and off as per the set temperature setting and discontinue operation when the set time has run out.

5

Source page 6 - OCR transcription (OCR)

Example: It is now 4pm. The heater is on and you want it to shut off at 11pm automatically. Set the timer-off function to 7 hours: the heater will cycle on and off to maintain the set temperature. It will stop operating at 11pm and go into standby mode. It is recommended to unplug the heater from the wall outlet when the heater is not in use.

Clean and maintenance

1. Press Power Button to turn off the heater.

2. Disconnect the power cord from the electrical outlet, and wait until the unit cool down.

WARNING: Do not expose the heating elements or switches to water, cleaning liquids or other chemicals, as fire, electrical shock, personal injury and property

damage can occur.

CAUTION: Do not use gasoline, benzene or thinner to clean your heater, as these chemicals can cause surface damage.

1. Use a vacuum cleaner with a crevice tool to remove dust from the interior or your heater.
2. Use a clean, soft and lightly damp cloth to gently wipe the surface of the enclosure.
3. Allow the enclosure to dry completely prior to operating your heater.

Off-season storage instructions

1. Secure the power cord, and place your heater in its original shipping container, or a similar container.
2. Store the container in a cool, dry location.
3. Take out the remote batteries (to prevent corrosion) as shown below. Store the remote in a safe place.

CT SSS

\ } | i Ny

)> = ;}) -! }) ob]

/ I | GLY) }

Safety features

Your heater is equipped with a Tip-Over Safety Switch. When your heater tips over, it will turn off automatically.

Your heater is equipped with an Overheat Protection System. When the threshold temperature has been reached, your heater will turn off automatically.

6

Source page 7 - OCR transcription (OCR)

To reset your heater when the Overheat Protection System has been activated, perform the following:

1. Turn the Power Control Switch to the ‘OFF’ position, and turn the Temperature Control Switch to the lowest setting.
2. Disconnect the power cord from the electrical outlet.
3. Allow your heater to cool down for approximately ten minutes.
4. Connect the power cord to the electrical outlet.
5. Turn the Power Control Switch to the ‘HIGH’ position, and turn the Temperature Control Switch to the highest setting.
6. If your heater does not operate normally, turn the Power Control Switch to the ‘OFF’ position, disconnect the power cord from the electrical outlet, and consult an authorized repair technician.

7

Source page 8 - OCR transcription (OCR)

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental United States,** return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

LA waanne:

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov