EZ Heat Ceramic Heater Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 32555

Original source file(s): 32555.Instruction Manual.01.pdf

Source SHA-256: fc9851440b5dc4c55fc2d3a498d0c84facc687d2957f43e42d9f23a472936e21

Original PDF pages: 4 | Recovered reading units: 4

Source page 1 - OCR transcription (OCR)

OWNER'S MANUAL

CERAMIC HEATER FAN

Model NO.: FP442-15

SKU#:32555

> =

ne

Features:

eAdjustable Thermostat

Three Settings:

High (1500W)

Low (750W)

Fan Only

¢Top Mounted Control Panel

ePower Indicator Light

*Safety Overheat Protection @)

*Safety Tip-Over Switch TS

eConvenient Carry Handle Intertek

°120V A.C., 60Hz., 12.5A, 5120 BTUs Save These Instructions

Source page 2 - OCR transcription (OCR)

INTENDED USE: WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not Use your heater only in dry environments. This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes Igcations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult @ Gutdoors, Do not use in damp environments such a8 flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements.

damage, injury or even death may result if not adhered to. ”

Use your heater-fan only with a working smoke detector located inthe WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

IMPORTANT INSTRUCTIONS heat. DO NOT USE in areas where gasoline, paint or

flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

* Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

* This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not place the heater near a bed because

heater. Keep combustible materials, such as furniture, pillows, objects such as pillows or blankets can fall off the bed and be

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) _ ignited by the heater. Do not insert or allow foreign objects to

from the front of the heater-fan and keep them away from the sides -_ enter any ventilation or exhaust opening as this may cause an

and rear. electric shock, fire, or damage the heater.

© Do not use heater unattended. Use of extreme caution is necessary

when any heater is used by or near children, invalids, disabled .

persons or pets. WARNING:

© Do not operate the heater with a damaged power cord or after the ELECTRICAL SHOCK HAZARD

heater malfunctions, has been dropped or damaged in any manner. Do not use with damaged cord or plug. Use with adequate

* Do not use heater outdoors. electrical system that is up to code.

« Use your heater only in dry environments. This heater is not intended

for use in a bathroom, laundry area, or similar locations, or near The supply cord has a polarized plug. As a safety feature this

sinks, washing machines, swimming pools or other sources of water. plug will fit in a polarized outlet only one way. To prevent

Never locate heater where it may fall into a bathtub or other water electric shock, match wide blade of plug to wide slot, fully

container. Do not use in damp environments such as flooded insert plug. If the plug does not fit contact a qualified

basements. electrician.

* Do not place the heater on a small, unlevel, uneven or any surface

which might allow heater to tip or fall Do not operate any heater with a damaged cord or plug or after

* For proper operation, heater should be placed on a smooth, heater malfunctions, has been dropped or damaged in any

non-combustible surface. Do not place on rugs, carpet, vinyl flooring manner. Do not operate heater with a broken heating element

or other plastic surfaces. Not for use outdoors or in wet areas. or ceramic cone or any visual imperfections.

* This heater is not designed as a primary heat source.

« Always plug heaters directly into a wall outlet/receptacle. Never use

with an extension cord or relocatable power tap (outlet/power strip).

Always unplug heater when not in use.

* Do not run power cord under carpeting. Do not cover cord with '.

throw rugs, runners or similar coverings. Arrange cord away from PET OWNERS NOTE: Il pet tl . ti

traffic area where it will not be tripped over. rds and some small pets are extremely sensitive

* To disconnect heater, turn controls off then remove plug from outlet. ni ihe fumes given, off during the initial alu of many appliances

* Do not insert or allow foreign objects to enter any ventilation or though these fumes are not harmful to humans, it is

exhaust opening as this may cause an electric shock or fire or ‘Commended that this heater not be used around birds and

damage the heater small pets during its initial use until the manufacturing corrosion

burn off.

* To prevent a possible fire, do not block air intakes or exhaust in any Coatings

manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

* Aheater has hot and arcing or sparking parts inside. Do not use it in

areas where gasoline, paint or flammable liquids are used or stored

« Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock or

injury to persons or property.

Source page 3 - OCR transcription (OCR)

USAGE: TO OPERATE FAN ONLY: Turn the On/Off Power

HEATER OPERATION: Always operate the heater in Level Control dial to the Fan setting. Turn thermostat

the upright position following all instructions and fully clockwise so the fan will run continuously.

recommendations listed in this manual HEATER

LOCATION: Place the heater in the area of the room that IMPORTANT SAFETY FEATURES

is coldest. HEATER CONNECTION: Plug heater directly The power indicator light, located near the control

into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits panel, lights whenever the heater or fan is turned on.

tightly in outlet. A loose connection may cause The heater is equipped with an automatic overheat

overheating and damage to the plug or heater. NOTE: protection device located inside the body of the heater.

To prevent overloading a circuit, do not plug the heater If the heater grille is obstructed, or if the heater gets

into a circuit that is servicing other electrical needs. too hot for any reason, the automatic overheat

protection device will turn the heater off. To reset the

POWER INDICATOR: When the unit is turned on, the heater, simply turn power off and unplug the heater for power indicator light will illuminate to tell you the 10 minutes until it cools down and then you may plug heater is functioning. the heater in and restart. Be sure that the heater is on a smooth level surface with no obstructions. The heater

TURNING HEATER ON: To start the heater, turn the is also equipped with a safety tip-over switch to turn On/Off Power Level Control from the OFF position to the power off to the heater when the heater tips over. To LOW or HIGH setting. Then rotate the Thermostat resume heater functions simply stand heater upright. Control clockwise to the HIGH THERMOSTAT position as described below. (During the heaters initial use, you may CARE AND MAINTENANCE experience a slight odor or smoking. This is the result of WARNING: ALWAYS UNPLUG THE CORD BEFORE the heating element lubrication “burning off". This is MOVING OR SERVING. DO NOT IMMERSE normal and will go away after a few minutes of use.) HEATER/FAN IN WATER!

CONTROL PANEL CLEANING: IMPORTANT! DO NOT IMMERSE

cy Power HEATERIFAN IN WATER! Clean the Heater/fan grille

pe may |cicator with the vacuum brush attachment on your vacuum

oe cleaner. This will remove lint and dirt from inside the

» =) On/Off heater/fan. DO NOT ATTEMPT TO TAKE APART THE

Trermos:at A and HEATER/FAN. DO NOT REMOVE THE HEATERIFAN

: 5 Control GRILLE. Clean the body of the Heater/fan with a soft cloth.

POWER LEVEL SWITCH: This heater has two heat settings: High and Low. Use the higher setting (1500 watt) to raise the room temperature quickly. When the desired temperature is reached use the Low setting. It is usually sufficient to maintain a comfortable temperature. REPAIR:

DO NOT OPERATE THE HEATER WITHOUT THE

SETTING THERMOSTAT: After heater has been turned on and the room has reached the desired temperature, slowly rotate the thermostat knob counter-clockwise until the heater shuts off (you should hear a faint “click”). By leaving the thermostat at this setting it will automatically maintain this temperature. To lower the temperature, rotate the knob further counter-clockwise (towards the LOW position). To raise the temperature, rotate the thermostat knob clockwise (towards the HIGH position). small pets are extremely sensitive to the fumes given off during the initial use of many appliances. Although these fumes are not harmful to humans, it is recommended that this heater not be used around birds and small pets during its initial use until the manufacturing corrosion coatings burn off.

GRILLE IN PLACE. DO NOT USE THE HEATER IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

STORAGE: Keep original carton for storage of the heater. Coil and tie the power cord to avoid damage during storage.

PET OWNERS NOTE: The health of birds and some

TURNING OFF: Turn the center dial to the OFF position before unplugging or plugging in the heater. Heater should be unplugged when not in use.

Source page 4 - OCR transcription (OCR)

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

CUSTOMER ASSISTANCE

FOR IMMEDIATE CUSTOMER SERVICE, CALL: 1-877-420-7555

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH

ANY QUESTIONS REGARDING YOUR HEATER.

Distributed By:

Mr. Brands, LLC.

Made in China

Cancer and Reproductive Harm -~

winuP6SWarnings.cagov

Rev. 012017