Comfort Zone Window Air Conditioner

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12754

Original source file(s): CZ12754.Instruction Manual.01.pdf

Source SHA-256: 519918af88312095d1a77eadb694603d6044054bfe21e38e46c46530659fcea8

Original PDF pages: 21 | Recovered reading units: 27

Source page 1 - OCR transcription (OCR)

7898 10-LOL18

FLA EEK

1. ki; CRISS BA. ARE, REA RHHSNESSRIE;

2. Redo WASH, RR A70g/m’ , RIED HAGB/T1804-cH;

3 SV BRHA, AB. HR;

4. GBB: BE ABLACK; _

5. AH RAT AMER SSMS a CAS) FA AArial, FBA2. 3mm(9SF) WA

ores FEY ay $24 HO EY we HE ES BS, BI : RE FE TR UM-XXXXXXXXXXXX. HI BB PLIM-XXXXXXXXXXXX CA) ,

SB - RB BIM-XXXXXXXXXXXX (BD... AER.

-- FDR Fat 81101-018582

<7 vz oo A

SRSA ELAR

etlacepoorz el | | wom

re tfeen| [mex| | _ 78 ‘alaB2 (AL) BRAS

fe alm, [ee] em || eie | em | ERS Ae

Source page 2 (embedded text)

Model No: CZ12754

Source page 4 (embedded text)

INTRODUCTION

IMPORTANT SAFETY INSTRUCTION .....

ELECTRICAL REQUIREMENTS .....

PACKING LIST .....

INSTALLATION & ASSEMBLY INSTRUCTIONS .....

USING YOUR AIR CONDITIONER .....

CARE AND CLEANING .....

TROUBLESHOOTING .....

1

3

4

5

9
12
13
WARNING 14

Source page 5 (embedded text)

1
below:

Source page 5 - OCR transcription (OCR)

IMPORTANT SAFETY INSTRUCTIONS

Before installing and using your air conditioner, please read this owner’s manual carefully. Store this manual in a safe place for future reference. Your safety and the safety of others is very important to us. Please pay attention to all safety messages outlined in this owner’s manual.

WARNING: To reduce the risk of fire, electrical shock or injury when using your air conditioner, follow

the basic precautions below:

e Plug into a grounded 3 prong outlet. e Do not use an extension cord.

e Donot remove the ground prong. e Unplug the air conditioner before servicing.

e Do not use a plug adapter. e Use two or more people to move and install the air conditioner.

This is a safety alert symbol.

This symbol alerts you to potential hazards that can harm you or others or even cause death.

All safety messages will directly follow the safety alert symbol and/or the words **“DANGER’ or “WARNING”.**

A DAN G ER Failure to immediately follow these instructions may cause serious injury

AWARNING oreven ea

All Safety messages alert you of potential hazards, how to reduce the chance of injury, and what can happen if instructions are not followed correctly.

1

Source page 6 (embedded text)

2

INTRODUCTION TO REFRIGERANTS R32

9K
12K
18K
24K

The refrigerants used for air conditioners are environmentally friendly hydrocarbons R32. This kind of erant is combustible and odorless. Moreover, it can burn and explode under certain condition. However, there will be no risk of burning and explosion if you comply with the following table to install your air conditioner in a room with

an appropriate area and use it correctly.

Compared with ordinary refrigerants, Refrigerant R32 is environmentally friendly and do not destroy the ozone sphere and that its value of greenhouse effect is also very low.

Room area requests for air conditioner with Refrigerant R32

Warnings

Please read the manual before installation, using, maintenance.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

Do not pierce or burn the appliance.

The appliance shall be stored in a room without continuously operating sources (for example: open flames, an operating ignition gas appliance or an operating electric heater.)

Please contact the nearest after-sale service center when maintenance is necessary. At the time of **maintenance, the maintenance personnel must strictly comply with the Operation Manual provided by the** corresponding manufacturer and any non-professional is prohibited to maintain the air conditioner.

The handling, installation, storage, servicing and disposal must comply with the provisions of gas-related national laws and regulations, and also national wiring regulation.

It is necessary to clear away the refrigerant in the system when maintaining or scrapping an air conditioner.

Be aware that refrigerants may not contain an odour.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Unit operation limits: Outdoor side 61~110

, 80%RH; indoor side 61~90

, 80%RH.

R32

Refrigerant

Capacity(Btu)

Room Area

2

Above 4m

2

Above 4m

2

Above 15m

2

Above 25m

A2L

Source page 7 (embedded text)

3

7

8

If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Source page 8 (embedded text)

4

battery

Source page 9 (embedded text)

5

23" to 34"

584 mm to 863 mm

14 1/2" min

(368mm)

OFFSET

STOOL

SILL

INTERIOR

WALL

EXTERIOR

WALL

FIG. 1

4

584

863

Head

Source page 9 - OCR transcription (OCR)

INSTALLATION & ASSEMBLY INSTRUCTIONS

Some assembly is required for your new air conditioner. Please read and follow these instructions carefully.

1. This air conditioner is designed to be installed in a ZZ
standard double-hung window with a window width x PrN LA
between 23” and 34” (584 mm - 863 mm). --F

2. The air conditioner can be installed without the | £ ta |
accordion panels to fit in a narrow window opening. ele o 584 min to 863 mm
See the window dimensions. k i” J

3. The Lower Sash (the lower part of the window that EXTERIOR 14 1/2" min
moves up and down) must allow for 14.5” of vertical SLL OFFSET WALL ween win
clearance when open. (See FIG. 1).

when open. (ee wee cae

4. All supporting parts must be secured to firm wood, A

masonry, or metal. LZ

5. The electrical outlet must be within reach of the power Y
cord.

NOTE: Save the product packaging and installation instruc-

tions for future reference. Store the air conditioner in the

product box when not in use for an extended period of time.
a

Top Rail Assembly

The top rail must be assembled prior to installing the air conditioner in the window FIG.A Top Rail

Tools Needed: Phillips Head Screw Driver : J

Top Rail Hardware 4 4
é } 3/8” | |
B
”
=
= , 1 TL
: Rail BSS
=< LLL
Attaching the Top Rail to the Air Conditioner ie - ZZ
1. Remove the air conditioner from the box Aa
SA ilk
and place on a hard and flat surface. =S 7 |
SSS g

2. Remove top rail from the top of the SS | | g
packaging material as shown in FIG. A.

3. Align the hole in the top rail with those in] aes FIG. C
the top of the unit as shown in FIG. B. <>

4. Secure the top rail to the unit with the 3/8" Sse Sez
screws as shown in FIG. C. A Ss 5

SSS) //
lal fl
CAUTION - ite
av

When handling the unit, be careful to avoid cuts from we
the sharp metal edges and aluminum fins on the front
and rear coils. NOTE: For safety reasons, all 4

screws must be used to attach

the top rail.

5

Source page 10 (embedded text)

6

(It is suggested to keep a downward

angle to let accumulated rain water drain out from

the back side of the unit bottom.

(

8

5

7

6

Source page 10 - OCR transcription (OCR)

ASSEMBLY & INSTALLATION (CONT.)

Accordion Panel Installation Storm Window Requirements

Now that you have installed the top rail, you can now install | A storm window frame will not allow the air conditioner to

the accordion panels on each side. tilt properly which in turn will keep it from draining properly.

To adjust for this, attach a board or piece of wood to the

: a sill. The board or wood piece should have a depth of at

1. Place the air conditioner on a hard flat surface. least 1 1/2”. Make sure the board or piece of wood is ap-

2. Locate the accordion panels in the box. proximately 1/2” higher than the storm window frame. This

3. Gently pull the free end of the accordion panel (See will allow the air conditioner to tilt enough for proper drain-

FIG. 2). Do this for both panels. age. (See FIG. 5).

FIG. 5

|| SASH

AW \ \ \!

\

\} STORM » Board or wood

~ WINDOW 1 1/2" MIN piece must be

(38 mm) :

od FRAME approximately

vA vA >| 1/2” higher

than the storm

window frame

4. Slide the free end of the accordion panel into the side for proper

panel of the air conditioner (See FIG. 3). Do this for drainage

each side.

FIG.3 Placing the Unit Inside a Window

3 7 Tht | 1. Place the air conditioner on the sill with the bottom

} ah! \\ mounting rail against its back edge. Center the air con-

oe Ny ditioner and close the window securely behind the top

-- ; Val mounting rail. The air conditioner should be slightly

4) tilted to the outside area. Use a level; about a 1/3 bub-

' aa ble will be the correct case slant to the outside. (See

. a . FIG. 6 & FIG. 7) (It is suggested to keep a downward

5. Once the accordion panels are slid into place adjust angle to let accumulated rain water drain out from

the top and bottom rails of the accordion panels into the back side of the unit bottom.)

the top and bottom rails of the air conditioner (See FIG. . - - =

. jj y s =

4). ie Fic.7 | ==

aT mn |) es

7 ~ } | t 30TTOM RAIL -_--<_-

= ; \ toi | | \at --_-

= | i | | | = _a\ 3-

> \| 2. Once the air conditioner is placed, extend both the left

and right accordion panels to the width of the window.

Jain

blll 1

6

Source page 11 (embedded text)

7

Head

unplug

FIG. 9

9

10

FIG. 10

FIG. 11

FIG. 12

FIG. 13

FIG. 14

4

Source page 11 - OCR transcription (OCR)

ASSEMBLY & INSTALLATION (CONT.)

Frame Lock, Sash Lock, and Foam Seal 3. To secure the lower sash into place, use the sash lock

Installation and a 3/4” screw as shown below. (See FIG. 13)

MOUNTING HARDWARE lf if} Hi] |

3 iF ;

Qty yon | :

3/4” Screws 4 |

1/2” Screws 3 |

}

Pie Frame Lock 2

. Sash Lock 1 =.

Be

Tools Needed:

Phillips Head Screw Driver 4. For added insulation, cut the supplied insulation foam to

Drill (if plot holes are needed) the width of the window. Insert the foam between the

window sashes to prevent air and objects from getting

into the room. (See FIG. 14)

1. Place the frame lock between the extended accordion

panels and the window sill as show in FIG. 9. Screw a

3/4” (19 mm) locking screw through the frame lock and

into the window sill. (FIG. 10) = a

FIG. 9 :

\\ J

rez

2. Drive 1/2” screws into the top of the accordion panel

frame and the top rail to securely attach the window air | Removing the Air Conditioner from the

conditioner to the lower sash. (See FIG. 11/12) Window

1. Turn the air conditioner off and unplug the power

cord.

Fr IG. 2. Remove the sash seal from between windows, and

| q - unscrew sash lock.

-_ -- 3. Remove the screws installed through the frame and

a -- frame lock.

4. Close (slide) the side panels into frame.

5. Keeping a firm grip on air conditioner, raise the sash

and carefully “rock” air conditioner backward to drain

any condensate water in base of unit. Be careful not to

spill any remaining water while lifting unit from window.

6. Store parts WITH the air conditioner in the box.

7

Source page 12 (embedded text)

8

INSTALLATION & ASSEMBLY INSTRUCTIONS

Introduction to Refrigerants R32

Before installing the appliance, you must read the manual carefully to get the safety

information and notes.

When filling the combustible refrigerant, any of your rude operations may cause serious

injury or injuries to human body or bodies and object or objects.
A leak test must be done after the installation is completed.
It is a must to do the safety inspection before maintaining or repairing an air conditioner using combustible refrigerant in order to ensure that the fire risk is reduced to minimum.
It is necessary to operate the machine under a controlled procedure in order to ensure that any risk arising from the combustible gas or vapor during the operation is reduced to minimum.
Requirements for the total weight of filled refrigerant and the area of a room to be equipped with an air conditioner.
1. Site Safety
2. Operation Safety
Open Flames Prohibited
Ventilation Necessary
Open Flames Prohibited
Mind Static Electricity
Must Wear Protective Clothing and anti-static gloves
Don't use mobile phone
3. Installation Safety
Refrigerant Leak Detector
Appropriate Installation Location
The left picture is the schematic diagram of a refrigerant leak detector.
Please note that:
1. The installation site should be in a well-ventilated condition.
2. The sites for installing and maintaining an air conditioner using Refrigerant R32 should be free from open fire or welding, smoking, drying oven or any other heat source higher than 548 which easily produces open fire.
3. When installing an air conditioner, it is necessary to take appropriate anti-static measures such as wear anti-static clothing and/or gloves.
4. It is necessary to choose the site convenient for installation or maintenance wherein the air inlets and outlets of the indoor and outdoor units should be not surrounded by obstacles or close to any heat source or combustible and/or explosive environment.
5. If the indoor unit suffers refrigerant leak during the installation, all the personnel should go out till the refrigerant leaks completely for 15 minutes. If the product is damaged, it is a must to carry such damaged product back to the maintenance station and it is prohibited to weld the refrigerant pipe or conduct other operations on the user's site.
6. It is necessary to choose the place where the inlet and outlet air of the indoor unit is even.
7. It is necessary to avoid the places where there are other electrical products, power switch plugs and sockets, kitchen cabinet, bed, sofa and other valuables right under the lines on two sides of the indoor unit, and also prevent mechanical damage from occurring.
A2L

Source page 13 (embedded text)

9

and Button:
3. Use these buttons on the
control panel and remote to increase or decrease
the Set Temperature or Timer.
Temperature range: 61 ~88 or 16 ~31 .
Press the mode button to cycle
through the various modes: Cool, Dry, Fan and
Auto.
Cool Mode: The cooling function allows the air
conditioner to cool the room and at the same time
reduces humidity. Press the MODE button to
activate the cooling function. To optimize this
function adjust the temperature by pressing the up
and down arrows and the speed by pressing the
Fan Speed button.
Dry Mode: This function reduces the humidity of
the air to make the room more comfortable. Press
the MODE button to set the DRY mode. An
automatic function of alternating cooling cycles
and air fan is activated.
Fan Mode:
Auto Mode: In AUTO mode the unit automatically
chooses the mode of operation (COOL, DRY, or
FAN). In this mode the temperature is set
automatically according to the room temperature
(Room temperature is determined by the
conditioner is vented. Press the MODE button to

set the FAN mode. With pressing the FAN SPEED
button, the speed changes in the following

sequence: Hi, Med and Lo in FAN mode.
temperature sensor located in the indoor unit).
7
This function only works when the air

Press the SLEEP button, all of the
display lights will turn off after a while, but the
Sleep light is always on. In SLEEP mode, the air
conditioner will automatically adjust the
temperature and fan speed to make the room
more comfortable during the night. The set
temperature will automatically raise every 30-60
minutes, and at most change six times until the

set temperature is 81 or 82 .

1.

When the timer is not in use,

the operation mode and the set temperature will be displayed. Time will be displayed under the timer setting.

Digital Display:

2. Mode Button:

4. Sleep Button:

3

6

1

2

4

5

9

8

Source page 14 (embedded text)

10

6. Turn the air conditioner on and off.

Power Button:

Press the FAN SPEED button

to select the fan speed. In COOL MODE you can choose the following settings: HI, MED, LO, or AUTO. In FAN MODE you can choose from HI, MED, and LO.

9. Fan Speed Button:

When the unit is in ECO mode, the

light will turn on. In ECO mode, the unit will turn off once the room is cooled to the user-set temperature.

The unit will turn back on when the room temperature rises above the user-set temperature. Before the compressor starts, the fan motor will run for a while, then it will stop for a while, and will repeat to provide a much more comfortable feeling and save energy.

5. Eco Button:

10. Use the horizontal wheels

to control horizontal airflow and the air deflectors

to control vertical airflow.
Directional Louvers:
horizontal wheel
air deflector
air deflector
When the Filter Check light is off,
it is not necessary to press the Filter Check button.
When the Filter Check light is on, you can turn off the light by pressing the Filter Check button. After the fan motor works for 500 total hours, the Filter Check light will turn on to remind the user to clean the filter.
Filter Button:
7.
Use these buttons on the control panel and remote to set the Timer.
Timer Off: The timed stop is programmed by pressing TIMER button. Set the rest time by pressing the button
or
until the rest time displayed is to your demand then press TIMER button again.
Timer On: When the unit is off, press TIMER button at the first time, set the temperature with pressing the button
or
. Press TIMER button at the second time, set the rest time with pressing the button
or
. Press TIMER button at the third time, confirm the setting,
Note: It can be set to automatically turn off or on in 0.5-24 hours. Each press of the

buttons will increase or decrease the timer. The Timer can be set in 0.5 hours increment below 10 hours and 1 hour increment for 10 hours or above.
The SET light will turn on while setting.
To cancel the set function, press the TIMER button again.
then it

will show on the display.

8. Timer Button:

Source page 15 (embedded text)

11

Fan Only:

Press the FAN SPEED button to
choose the fan speed options. You can choose
Hi, Med, Lo or auto speed in COOL mode and
choose Hi, Med, Lo in FAN mode.

7.

Fan Speed:

To press the DISPLAY button, it can
switch off/on all lights or LED display.

8.

Display:

Use these buttons on the control panel
and remote to set the Timer.

Timer Off: The timed stop is programmed by
pressing TIMER button. Set the rest time by
pressing the button or until the rest
time displayed is to your demand then press
TIMER button again.

Timer On: When the unit is off, press TIMER
button at the first time, set the temperature with
pressing the button or . Press TIMER
button at the second time, set the rest time with
pressing the button or . Press TIMER
button at the third time, confirm the setting, then
the rest time to next automatical switching-on
could be read on the display of the machine.

Note: It can be set to automatically turn off or on
in 0.5-24 hours. Each press of the
buttons will increase or decrease the timer. The
Timer can be set in 0.5 hours increment below
10 hours and 1 hour increment for 10 hours or
above. The SET light will turn on while setting.
To cancel the set function, press the TIMER
button again.

5.

Timer:

In AUTO mode the unit automatically
chooses the mode of operation(COOL,DRY or

FAN). In this mode the temperature will be set automatically according to the room temperature (tested by the temperature sensor which is incorporated in the indoor unit.).

6.

Auto Mode:

1.

Turn the air conditioner on and off.

Power:

2. Press the COOL button to COOL mode.

Cool:

and :

3.

Use these buttons on the control panel and remote to increase or decrease the Set Temperature or Timer. Temperature range: 61 ~88 or 16 ~31 .

1

4

5

6

3

3

7

8

10

9

2

When the unit is in ECO mode, the light will turn on. In ECO mode, the unit will turn off once the room is cooled to the user set temperature. The unit will turn back on when the room temperature rises above the user set temperature. Before the compressor starts, the fan motor will run for a while, then it will stop for a while, and will repeat to provide a much more comfortable feeling and save energy.

Press the Fan Only button to FAN ONLY mode.

9.

10.

Eco:

Press the SLEEP button, all of the
display lights will turn off after a while, but the
Sleep light is always on. In SLEEP mode, the air-
conditioner will automatically adjust the tempera-
ture and fan speed to make the room more comfor-
table during the night. The set temperature will
automatically raise every 30-60 minutes
and at most change six times until the set
temperature is 81 or 82 .
4.
Sleep:

Source page 16 (embedded text)

12
15
FIG. 15

Source page 16 - OCR transcription (OCR)

CARE AND CLEANING Cabinet Cleaning 7 ;

Clean your air conditioner to keep it looking new | To clean the air conditioner cabinet:

and to minimize dust build up. e Unplug the air conditioner to prevent shock or

a fire hazard. The cabinet and front panel of

Air Filter Cleaning the air conditioner may be dusted with an oil-

The air filter should be checked at least once free cloth or washed with a cloth dampened in

every month to see if it needs cleaning. Trapped a solution of warm water and mild liquid soap.

particles and dust can build up in the filter and Rinse thoroughly with a damp cloth and wipe
may decrease airflow as well as cause the dry.

cooling coils to accumulate frost. To clean the air .

or e Never use harsh cleaners, wax or polish on

filter: :

the cabinet front.

1. Remove the filter by sliding it out from the e Be sure to wring excess water from the cloth
front right side of the air conditioner. (See before wiping around the controls. Excess
FIG. 15) water in or around the controls may cause

2. Wash the filter using liquid dish soap and damage to the air conditioner.
warm water. Rinse the filter thoroughly. Gen-
tly shake the filter to remove excess water. Winter Storage

3. Let the filter dry completely before placing it | To store the air conditioner when it is not in use
into the air conditioner. for an extended period of time, remove it care-

4. If you do not wish to wash the filter, you may | fully from the window according to the installation
vacuum the filter to remove the dust and instructions and cover it with plastic or place it in
other particles. the original box.

FIG. 15
ie | _---- e
re |
12

Source page 17 (embedded text)

13

Source page 17 - OCR transcription (OCR)

TROUBLESHOOTING

PROBLEM POSSIBLE CAUSES SOLUTIONS

The Air Conditioner will not start The air conditioner is unplugged e Make sure the air conditioner plug
is pushed completely into the
outlet
The fuse is blown/circuit breaker is e Check the house fuse/circuit
tripped breaker box and replace the fuse
or reset the breaker
Power failure e = The unit will automatically re-start
when power is restored
e There is a protective time delay
(approx. 3 minutes) to prevent
tripping of the compressor
overload. For this reason, the unit
may not start normal cooling for 3
minutes after it is turned back on.
The current interrupter device is ¢ Press the RESET button located
tripped on the power cord plug
e If the RESET button will not stay
engaged, discontinue use of the
air conditioner and contact a
qualified service technician
The Air Conditioner does not cool Airflow is restricted e Make sure there are no curtains,
as it should blinds, or furniture blocking the
front of the air conditioner
The temperature control may not be e Lower the set thermostat tempera-
set correctly ture
The air filter is dirty e Clean the filter. See the Cleaning

and Care Section of the manual

The room may be too warm e Please allow time for the room to

cool down after turning on the air

conditioner

Cold air is escaping e Check for open furnace registers

and cold air returns

The cooling coils are frozen e See “Air Conditioner Freezing Up”

below

The Air Conditioner is freezing up Ice blocks the air flow and stops the air|e Set the MODE dial to HIGH FAN

conditioner from cooling the room or HIGH COOL and set the ther-

mostat to a higher temperature

The Remote Control is not working | The batteries are inserted incorrectly |e Check the position of the batteries

The batteries may be dead e Replace the batteries

13

Source page 18 (embedded text)

14

WARNING

-Do not use means to accelerate the defrosting process or to clean, other than those

recommended by the manufacturer;

-The appliance shall be stored in a room without continuously operating ignition sources

(for example: open flames, an operating gas appliance or an operating electric heater.

-Do not pierce or burn.

-Be aware that refrigerants may not contain an odour.

Information:

1), information for handling, installation, cleaning please prefer page 5~12, servicing and

disposal of refrigerant please contact the manufacturer to advise.

2), a warning: keep 300mm ventilation openings clear of obstruction.

3), a notice: servicing shall be performed only as recommended by the manufacturer.

4), Information for qualification of workers

5), Information on servicing

6), Repairs to sealed components

7), Repairs to Intrinsically safe components

8), Cabling

9), Detection of flammable refrigerants

10), Removal and evacuation

11), Charging procedures

12), Decommissioning, labelling and recovery

Source page 21 - OCR transcription (OCR)

O) Comfort Zone.

www.Comfortzoneproducts.com

Distributed by: For warranty information visit:

Mr. Brands LLC www.mrbrands.com

Bristol, PA 19007

1-855-463-3518 WARNING:

www.mrbrands.com CANCER AND REPRODUCTIVE HARM

Made in Indonesia www.P65Warnings.ca.gov

OCR review notes

No OCR text recovered from source page 3

No OCR text recovered from source page 19

No OCR text recovered from source page 20