Comfort Zone 12,000 BTU Window Air Conditioner

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ12761

Original source file(s): CZ12761.Instruction Manual.01.pdf

Source SHA-256: 8b3c0eeef1dc76a0486ce4da5b87bb78a078c7e0dc9b0bf02347368e89d06b6e

Original PDF pages: 20 | Recovered reading units: 30

Source page 1 (embedded text)

12,000 BTU

Model No: CZ12761

Source page 3 (embedded text)

INTRODUCTION

IMPORTANT SAFETY INSTRUCTION .....

.....

PACKING LIST .....

INSTALLATION&ASSEMBLY INSTRUCTIONS .....

USING YOUR AIR CONDITIONER .....

.....

CARE AND CLEANING .....

TROUBLESHOOTING .....

ELECTRICAL REQUIREMENTS

OPERATING YOUR AIR CONDITIONER

1

3

4

5

11

13

14

15

Source page 4 (embedded text)

1

Source page 4 - OCR transcription (OCR)

IMPORTANT SAFETY INSTRUCTIONS

Before installing and using your air conditioner, please read this owner’s manual carefully. Store this manual in a safe place for future reference. Your safety and the safety of others is very important to

us. Please pay attention to all safety messages outlined in this owner’s manual.

WARNING: To reduce the risk of fire, electrical shock or injury when using your air conditioner, follow

the following basic precautions:

e Plug into a grounded 3 prong outlet. e Do not use an extension cord.

e Do not remove the ground prong. e Unplug the air conditioner before servicing

e Do not use a plug adapter. e Use two or more people to move and install the air conditioner

This is a safety alert symbol.

This symbol alerts you to potential hazards that can harm you or others or even cause death.

All safety messages will directly follow the safety alert symbol and/or the words **“DANGER’ or “WARNING”.**

rs DANG ER Failure to immediately follow these instructions may cause serious injury

AWARNING oreven goa

All Safety messages alert you of potential hazards, how to reduce the chance of injury, and what can happen if instructions are not followed correctly.

1

Source page 5 (embedded text)

2

INTRODUCTION TO REFRIGERANTS R32

9K

12K

18K

24K

The refrigerants used for air conditioners are environmentally friendly hydrocarbons R32. This kind of erant is combustible and odorless. Moreover, it can burn and explode under certain condition. However, there will be no risk of burning and explosion if you comply with the following table to install your air conditioner in a room with an appropriate area and use it correctly.

Compared with ordinary refrigerants, Refrigerant R32 is environmentally friendly and do not destroy the ozone sphere and that its value of greenhouse effect is also very low.

Room area requests for air conditioner with Refrigerant R32

Warnings

Please read the manual before installation, using, maintenance.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer.

Do not pierce or burn the appliance.

The appliance shall be stored in a room without continuously operating sources (for example: open flames, an operating ignition gas appliance or an operating electric heater.)

Please contact the nearest after-sale service center when maintenance is necessary. At the time of

maintenance, the maintenance personnel must strictly comply with the Operation Manual provided by the

corresponding manufacturer and any non-professional is prohibited to maintain the air conditioner.

The handling, installation, storage, servicing and disposal must comply with the provisions of gas-related national laws and regulations, and also national wiring regulation.

It is necessary to clear away the refrigerant in the system when maintaining or scrapping an air conditioner.

Be aware that refrigerants may not contain an odour.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

Unit operation limits: Outdoor side 61~110

, 80%RH; indoor side 61~90

, 80%RH.

R32

Refrigerant

Capacity(Btu)

Room Area

2

Above 4m

2

Above 4m

2

Above 15m

2

Above 25m

A2L

Source page 6 (embedded text)

3

(6K-8K) 0-8 amps

(10K-12K) 0-12 amps

(6K-8K) 10-amp

(10K-12K) 15-amp

If the SUPPLY CORD is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

Source page 7 (embedded text)

4

battery

Source page 8 (embedded text)

5

FIG. 1

FIG. 2

0

8

OFFSET

STOOL

SILL

INTERIOR

WALL

EXTERIOR

WALL

OFFSET

STOOL

SILL

INTERIOR

WALL

EXTERIOR

WALL

8K/10K

Source page 8 - OCR transcription (OCR)

DISCLAIMER

ALL INFORMATION AND THE TECHNICAL SPECIFICATIONS PRESENTED IN THIS USER'S MANUAL ARE THE

PRESENTATION OF THE MANUFACTURER.

a

INSTALLATION & ASSEMBLY INSTRUCTIONS [(S)S0u de). 8:1,¢h00.@)

Some assembly is required for your new air conditioner. Please read and follow these instructions carefully.

1. This air conditioner is designed to be installed in a ZZ
standard double-hung window with a window width © aS
between 23" and 36" (584 mm - 914 mm). SN

2. The air conditioner can be installed without the x -- ve we |
accordion panels to fit in a narrow window opening. | s > se4mm to 914mm
See the window dimensions. Ce J

3. The Lower Sash (the lower part of the window that a EXTERIOR asonny ZA
moves up and down) must allow for 14.5" of vertical SILL OFFSET WALL AB Z
clearance when open. (See FIG. 1). INTERIOR TAS

4. All supporting parts must be secured to firm wood, wat ZZ oa
masonry, or metal.

5. The electrical outlet must be within reach of the power u
cord.

NOTE: Save the product packaging and installation instruc-
tions for future reference. Store the air conditioner in the
product box when not in use for an extended period of time.

eee

INSTALLATION & ASSEMBLY INSTRUCTIONS (USED FOR 12K)

Some assembly is required for your new air conditioner. Please read and follow these instructions carefully.

1. This air conditioner is designed to be installed in a LZ
standard double-hung window with a window width = LA
between 26” and 36” (660 mm - 914 mm). a eS
2. The air conditioner can be installed without the | --- te , a“
accordion panels to fit in a narrow window opening. | rs tf -_S= 60 O 3o4mm
See the window dimensions. C ee 4
3. The Lower Sash (the lower part of the window that k EXTERIOR 16" C3
” . STOOL WALL (406mm)
moves up and down) must allow for 16” of vertical SILL OFFSET A -
clearance when open. (See FIG. 2). INTERIOR ZF
4. All supporting parts must be secured to firm wood, wat eA AST
masonry, or metal. CZ
5. The electrical outlet must be within reach of the power U
cord.

NOTE: Save the product packaging and installation instruc-
tions for future reference. Store the air conditioner in the
product box when not in use for an extended period of time.

5

Source page 9 (embedded text)

6

(Only used for 8K/10K)

Source page 9 - OCR transcription (OCR)

Top Rail Assembly (Only used for 8K/10K)

The top rail must be assembled prior to installing the air conditioner in the window Bottom Box

Tools Needed: Phillips Screw Driver a

Top Rail Hardware // fz

‘ 3/8” é LT) (otf

i ke. Screw 4 _

FIG.A l

¥ FIG.B;

Attaching the Top Rail to the Air Conditioner -

le

1. Remove the air conditioner from the box _ ees
and place on a hard flat surface. -SS-
; a= =e =
2. Remove top rail from the bottom of the Ea | |!
; . : |
packaging material as shown in FIG. A -----

3. Align the hole in the top rail with those in FIG.C

the top of the unit as shown in FIG. B oo, , ,

4. Secure the top rail to the unit with the 3/8" EE Sass =-___77

Screws as shown in FIG. C LSE | 34\

=== el

ad \|z3!

NOTE: For safety reasons, all 4

screws must be used to attach

the top rail.

When handling the unit, be careful to avoid cuts from

the sharp metal edges and aluminum fins on the front

and rear coils.

6

Source page 10 (embedded text)

7

FIG. 3

3

FIG. 4

FIG. 5

Source page 10 - OCR transcription (OCR)

OO -CSsSCSC‘C‘és

How to Install

MOUNTING HARDWARE

NOTE: Top Rail and Sliding Panels at each side are

Qty offset to provide the proper pitch to the rear of (5/16").

” This is necessary for proper condensed water utilization

3/4” Screws 4 and drainage. If you are not using the Side Panels for

4/2” Screws 3 any reason, this pitch to the rear must be maintained!

Place unit on floor, a bench or a table. There is a

Left and Right Window Filler Panel - be sure to

j € Lock Frame 2 use the proper panel for each side.When installed

the flange for securing the panel in place to the window sill

will be facing into the room.

| A. Hold the Accordion Panel in one hand and gently pull back

Sash Lock 1 the center to free the open end. See Figure 3.

% é (ae |

s = WE

\ \ Vit)

A\\\ \\\\ be

TOOLS NEEDED: Wh

* Phillips Screw Driver Wait

e Drill (If pilot holes are needed) “

fa a a G

When handling unit, be careful to avoid cuts

from sharp metal edges and aluminum fins on B. Slide the free end of the panel into the cabinet as shown in

front and rear coils. Figures 4. Slide the panel down. Be sure to leave enough

space to slip the top and bottom of the frame into the rails

on the cabinet.

-- -S i

C. Once the panel has been installed on the side of the cabinet,

make sure it sits securely inside the frame channel by

making slight adjustments. Slide the top and bottom ends

of the frame into the top and bottom rails of the cabinet.

Figure 5.

-S -_ FIG. 5

SS

-.

D. Slide the panel all the way in and repeat on the other side.

7

Source page 11 (embedded text)

8

(Suggest to keep a downward

oblique, to let accumulated rain water to drain out,

from back side of the unit bottom.)

FIG. 6

FIG. 7

FIG. 8

FIG. 9

FIG. 10

FIG. 11

FIG. 12

FIG. 13

Source page 12 (embedded text)

9

99FIG. 14

Source page 12 - OCR transcription (OCR)

OO --SSSCSC‘CSSCSCSCS

If AC is Blocked by Storm AIR CONDITIONER USE

Window ae

Operating your air conditioner properly helps you

Add wood as shown in FIG. 14, or remove storm to obtain the best possible results.

window before air conditioner is installed. This section explains proper air conditioner

operation.

99FIG. 14 IMPORTANT:

a lf you turn off the air conditioner, wait at least 3

SASH minutes before turning it back on. This prevents

BOARD the air conditioner from blowing a fuse or tripping

STORM WINDOW THICKNESS a circuit breaker.

FRAME AS REQUIRED,

OR OTHER FOR PROPER . ge .

OBSTRUCTION 4 PITCH TO = Do not try to operate your air conditioner in the

NN, ! IK cane sane cooling mode when outside temperature is below

t Nareon 65°F (18°C). The inside evaporator coil will freeze

SCREWS. up, and the air conditioner will not operate properly.

If Storm Window Frame must remain, be sure the pales In tne even oe eine failure, tine h

drain holes or slots are not caulked or painted condl loner wi operate at tne previous settings wnen

shut.Accumulated Rain Water or Condensation the power is restored.

must be allowed to drain out.

Removing AC From

Window

* Turn AC off, and disconnect power cord.

* Remove sash seal from between windows,

and unscrew safety lock.

* Remove screws installed through frame and

frame lock.

* Close (slide) side panels into frame.

* Keeping a firm grip on air conditioner, raise

sash and carefully “rock” air conditioner

backward to drain any condensate water in

base of unit. Be careful not to spill any

remaining water while lifting unit from

window. Store parts WITH air conditioner.

9

Source page 13 (embedded text)

10

INSTALLATION & ASSEMBLY INSTRUCTIONS

Introduction to Refrigerants R32

Before installing the appliance, you must read the manual carefully to get the safety

information and notes.

When filling the combustible refrigerant, any of your rude operations may cause serious

injury or injuries to human body or bodies and object or objects.

A leak test must be done after the installation is completed.

It is a must to do the safety inspection before maintaining or repairing an air conditioner

using combustible refrigerant in order to ensure that the fire risk is reduced to minimum.
It is necessary to operate the machine under a controlled procedure in order to ensure that any risk arising from the combustible gas or vapor during the operation is reduced to minimum.
Requirements for the total weight of filled refrigerant and the area of a room to be equipped with an air conditioner.
1. Site Safety
2. Operation Safety
Open Flames Prohibited
Ventilation Necessary
Open Flames Prohibited
Mind Static Electricity
Must Wear Protective Clothing and anti-static gloves
Don't use mobile phone
3. Installation Safety
Refrigerant Leak Detector
Appropriate Installation Location
The left picture is the schematic diagram of a refrigerant leak detector.
Please note that:
1. The installation site should be in a well-ventilated condition.
2. The sites for installing and maintaining an air conditioner using Refrigerant R32 should be free from open fire or welding, smoking, drying oven or any other heat source higher than 548
which easily produces open fire.
3. When installing an air conditioner, it is necessary to take appropriate anti-static measures such as wear anti-static clothing and/or gloves.
4. It is necessary to choose the site convenient for installation or maintenance wherein the air inlets and outlets of the indoor and outdoor units should be not surrounded by obstacles or close to any heat source or combustible and/or explosive environment.
5. If the indoor unit suffers refrigerant leak during the installation, all the personnel should go out till the refrigerant leaks completely for 15 minutes. If the product is damaged, it is a must to carry such damaged product back to the maintenance station and it is prohibited to weld the refrigerant pipe or conduct other operations on the user's site.
6. It is necessary to choose the place where the inlet and outlet air of the indoor unit is even.
7. It is necessary to avoid the places where there are other electrical products, power switch plugs and sockets, kitchen cabinet, bed, sofa and other valuables right under the lines on two sides of the indoor unit, and also prevent mechanical damage from occurring.
A2L

Source page 14 (embedded text)

11
1. Without timer setting,the
operation mode is Cooling,Dry, Fan and Auto,and
the set temperature will be displayed.

Time will be displayed under timer setting.
Digital Display:
and Button:
2. Use these buttons on the
control panel and remote to increase or decrease
the Set Temperature or Timer.
Temperature range: 61
~88
or 16
~31
.
3. Turn the air conditioner on and
off.
Power Button:
Press the mode button to cycle
through the various modes: Cool, Dry, Fan and
Auto.
4. Mode Button:
Use these buttons on the control
panel and remote to set the Timer.
Timer Off: The timed stop is programmed by
pressing TIMER button. Set the rest time by
pressing the button
or
until the rest
time displayed is to your demand then press
TIMER button again.
Timer On: When the unit is off, press TIMER
button at the first time, set the temperature with
pressing the button
or
. Press TIMER
button at the second time, set the rest time with
pressing the button
or
. Press TIMER
button at the third time, confirm the setting, then
the rest time to next automatical switching-on
could be read on the display of the machine.
Note: It can be set to automatically turn off or on in
0.5-24 hours. Each press of the

buttons will increase or decrease the timer. The

Timer can be set in 0.5 hours increment below 10 hours and 1 hour increment for 10 hours or above. The SET light will turn on while setting.
To cancel the setted function, press the TIMER button again.
5.
Timer Button:
Cool Mode: The cooling function allows the air conditioner to cool the room and at the same time reduces Air humidify. Press the MODE button to activate the cooling function. To optimize the function of the air conditioner, adjust the temperature and the speed by pressing the button indicated.
Dry Mode: This function reduces the humidity of the air to make the room more comfortable. Press MODE button to set the DRY mode. An automatic function of alternating cooling cycles and air fan is activated.
Fan Mode: The conditioner works in only ventilation. Press MODE button to set the FAN mode. With pressing FAN SPEED button the speed changes in the following sequence: Hi, Med and Lo in FAN mode. The remote control also stories the speed that was set in the previous mode of operation.
Auto Mode: In AUTO mode the unit automatically chooses the fan speed and the mode of operation (COOL,DRY or FAN).In this mode the fan speed and the temperature are set automatically according to the room temperature (tested by the temperature sensor which is incorporated in the indoor unit.).
1
2
3
4
5
6
7
8
9

AUTO
SPEED
AUTO
MODE

Source page 15 (embedded text)

12

When the unit is in ECO mode, the
light will turn on. In ECO mode, the unit will
turn off once the room is cooled to the user-set
temperature.
The unit will turn back on when the room
temperature rises above the user-set temperature.
Before the compressor starts, the fan motor will
run for a while, then it will stop for a while, and will
repeat to provide a much more comfortable feeling
and save energy.

6. Eco Button:

7. Sleep Button:

Press the FAN SPEED button
to choose the fan speed options. You can choose
Hi, Med, Lo or auto speed in COOL mode and
choose Hi, Med, Lo in FAN mode.

8. Fan Speed Button:

9. When the Filter Check light is off,
it is not necessary to press the Filter Check button.
When the Filter Check light is on, you can turn off
the light by pressing the Filter Check button. After
the fan motor works for 500 total hours, the Filter
Check light will turn on to remind the user to clean
the filter.
Filter Button:

10. To direct the airflow,
horizontal wheel to control the horizontal
direction,
control the
vertical direction.
use the
and use the air deflectors to
Directional Louvers:
horizontal wheel
air deflector
air deflector

Press the SLEEP button, all of the display lights will turn off after a while, but the Sleep light is always on. In SLEEP mode, the air conditioner will automatically adjust the temperature and fan speed to make the room more comfortable during the night. The set temperature will automatically raise every 30-60 minutes, and at most change six times until the set temperature is 81 or 82 .

Source page 16 (embedded text)

13
1
4
5
6
3
3
7
8
10
9
2
Fan Only:
Press the FAN SPEED button to choose the fan speed options. You can choose Hi, Med, Lo or auto speed in COOL mode and choose Hi, Med, Lo in FAN mode.
7.
Fan Speed:
To press the DISPLAY button, it can switch off/on all lights or LED display.
8.
Display:
Use these buttons on the control panel and remote to set the Timer.
Timer Off: The timed stop is programmed by pressing TIMER button. Set the rest time by pressing the button or until the rest time displayed is to your demand then press TIMER button again.
Timer On: When the unit is off, press TIMER

button at the first time, set the temperature with pressing the button or . Press TIMER button at the second time, set the rest time with pressing the button or . Press TIMER button at the third time, confirm the setting, then the rest time to next automatical switching-on could be read on the display of the machine.
Note: It can be set to automatically turn off or on in 0.5-24 hours. Each press of the buttons will increase or decrease the timer. The Timer can be set in 0.5 hours increment below 10 hours and 1 hour increment for 10 hours or above. The SET light will turn on while setting.
To cancel the set function, press the TIMER button again.
5.
Timer:
In AUTO mode the unit automatically chooses the mode of operation(COOL,DRY or FAN). In this mode the temperature will be set automatically according to the room temperature (tested by the temperature sensor which is incorporated in the indoor unit.).
6.
Auto Mode:
1.
Turn the air conditioner on and off.
Power:
2. Press the COOL button to COOL mode.
Cool:
and :
3.
Use these buttons on the control panel and remote to increase or decrease the Set Temperature or Timer. Temperature range: 61 ~88 or 16 ~31 .
When the unit is in ECO mode, the light will turn on. In ECO mode, the unit will turn off once the room is cooled to the user set temperature. The unit will turn back on when the room temperature rises above the user set temperature. Before the compressor starts, the fan motor will

run for a while, then it will stop for a while, and will repeat to provide a much more comfortable feeling and save energy.

Press the Fan Only button to FAN ONLY mode.

9.

10.

Eco:

Press the SLEEP button, all of the display lights will turn off after a while, but the Sleep light is always on. In SLEEP mode, the air-conditioner will automatically adjust the tempera-ture and fan speed to make the room more comfor-table during the night. The set temperature will automatically raise every 30-60 minutes and at most change six times until the set temperature is 81 or 82 .

4.

Sleep:

Source page 17 (embedded text)

14

FIG. 15

15

Source page 17 - OCR transcription (OCR)

CARE AND CLEANING Cabinet Cleaning 7

Clean your air conditioner to keep it looking new | To clean the air conditioner cabinet:

and to minimize dust build up. e Unplug the air conditioner to prevent shock or

a fire hazard. The cabinet and front panel of

Air Filter Cleaning the air conditioner may be dusted with an oil-

The air filter should be checked at least once free cloth or washed with a cloth dampened in

every month to see if it needs cleaning. Trapped a solution of warm water and mild liquid soap.

particles and dust can build up in the filter and Rinse thoroughly with a damp cloth and wipe

may decrease airflow as well as cause the dry.

cooling coils to accumulate frost. To clean the air .

or e Never use harsh cleaners, wax or polish on

filter: :

the cabinet front.

1. Remove the filter by pulling down on the in- |» Be sure to wring excess water from the cloth
dents of the filter door on the front of the unit. before wiping around the controls. Excess
(See FIG. 15) water in or around the controls may cause

2. Wash the filter using liquid dish soap and damage to the air conditioner.
warm water. Rinse the filter thoroughly. Gen-
tly shake the filter to remove excess water. Winter Storage

3. Let the filter dry completely before placing it | To store the air conditioner when it is not in use
into the air conditioner. for an extended period of time, remove it care-

4. If you do not wish to wash the filter, you may | fully from the window according to the installation
vacuum the filter to remove the dust and instructions and cover it with plastic or place it in
other particles. the original box.

re),
|
ee Lae
Se _
P FIG. 15
A. Indents

Wear and Tear

To minimize wear and tear on the air condi-

tioner, always wait at least 3 minutes before

changing modes. This will help prevent the

compressor from overheating and the circuit

breaker from tripping.

14

Source page 18 (embedded text)

15

Source page 18 - OCR transcription (OCR)

TROUBLESHOOTING

PROBLEM POSSIBLE CAUSES SOLUTIONS

The Air Conditioner will not start The air conditioner is unplugged e Make sure the air conditioner plug
is pushed completely into the
outlet
The fuse is blown/circuit breaker is e Check the house fuse/circuit
tripped. breaker box and replace the fuse
or reset the breaker.

Power failure e = The unit will automatically re-start
when power is restored.
e There is a protective time delay
(approx. 3 minutes) to prevent
tripping of the compressor
overload. For this reason, the unit
may not start normal cooling for 3
minutes after it is turned back on.
The current interrupter device is ¢ Press the RESET button located
tripped. on the power cord plug.
e If the RESET button will not stay
engaged, discontinue use of the
air conditioner and contact a
qualified service technician.
The Air Conditioner does not cool Airflow is restricted e Make sure there are no curtains,
as it should blinds, or furniture blocking the
front of the air conditioner
The temperature control may not be e Lower the set thermostat tempera-
set correctly. ture
The air filter is dirty e Clean the filter. See the Cleaning
and Care Section of the manual.
The room may be too warm e Please allow time for the room to
cool down after turning on the air
conditioner.
Cold air is escaping e Check for open furnace registers
and cold air returns
The cooling coils are frozen e See “Air Conditioner Freezing Up”
below.
The Air Conditioner is freezing up Ice blocks the air flow and stops the air|e Set the MODE dial to HIGH FAN
conditioner from cooling the room or HIGH COOL and set the ther-
mostat to a higher temperature
The Remote Control is not working | The batteries are inserted incorrectly e Check the position of the batteries.
The batteries may be dead e Replace the batteries
15

Source page 19 (embedded text)

16

WARNING

-Do not use means to accelerate the defrosting process or to clean, other than those
recommended by the manufacturer;
-The appliance shall be stored in a room without continuously operating ignition sources
(for example: open flames, an operating gas appliance or an operating electric heater.
-Do not pierce or burn.

-Be aware that refrigerants may not contain an odour.

Information:

1), information for handling, installation, cleaning please prefer page 5~14, servicing and disposal of refrigerant please contact the manufacturer to advise.

2), a warning: keep 300mm ventilation openings clear of obstruction.

3), a notice: servicing shall be performed only as recommended by the manufacturer.

4), Information for qualification of workers

5), Information on servicing

6), Repairs to sealed components

7), Repairs to Intrinsically safe components

8), Cabling

9), Detection of flammable refrigerants

10), Removal and evacuation

11), Charging procedures

12), Decommissioning, labelling and recovery

Source page 20 - OCR transcription (OCR)

O) Comfort Zone.

www.Comfortzoneproducts.com

Distributed by: For warranty information visit:

Mr. Brands LLC www.mrbrands.com

Bristol, PA 19007

1-855-463-3518 WARNING:

www.mrbrands.com CANCER AND REPRODUCTIVE HARM

Made in Indonesia www.P65Warnings.ca.gov

OCR review notes

No OCR text recovered from source page 2