Comfort Zone Electric Radiant Dish Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ998

Original source file(s): CZ2032.Instruction Manual.01.pdf; CZ998.Instruction Manual.01.pdf; 125039.Instruction Manual.01.pdf

Source SHA-256: 9972e19aeec7d54b4cad199e7052cba8e8b8fb72acd85290a8f0665dabd3c7f4

Original PDF pages: 1 | Recovered reading units: 4

Source page 1 - Panel 1 (top left) (OCR)

Model No. CZ998 Series

©) Comfort Zone.

America’s Heating and Cooling Choice

Electric Radiant = 4m

. Se 4 /| aw

Dish Heater 7,

a g {\

Features: Jy

¢ Dual Heat Settings:

1000 watts (3412 BTUs)

700 watts

¢70° Oscillation Feature

¢ Adjustable Tilt to Direct Heat

¢ Flocked Metal Safety Grille Stays Cool

to the Touch

¢ Safety Temperature Cutoff Switch

¢ Safety Tip-Over Cutoff Switch

¢ Convenient Carry Handle

¢120V A.C., 60HZ., 8.33A, 3412 BTUs

Save These Instructions

Page 1

Source page 1 - Panel 2 (top right) (OCR)

INTENDED USE: ; WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not | Use your heater only in dry environments, This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes | |gcations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a outdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property | basements

damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the | WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death: Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

heat. DO NOT USE in areas where gasoline, paint or

IMPORTANT INSTRUCTIONS flammable materials are used or stored. Keep combustible

, materials such as furniture, pillows, bedding, papers, clothes

When using electrical appliances, basic precautions should always be and curtains at least 3 feet (0.9 m) from the front of the heater

followed to reduce the risk of fire, electric shock and injury to persons, and keep them away from the sides and rear. To prevent a

including the following . possible fire, do not block air intakes or exhaust in any manner.

* Read all the instructions before using this heater/fan. Do not use on soft surfaces, like a bed, where openings may

* This heater/fan is hot when in use. To avoid burns, do not let bare become blocked. Do not place the heater near a bed because

skin touch hot surfaces. Use provided handle when moving this | objects such as pillows or blankets can fall off the bed and be

heater. Keep combustible materials, such as furniture, pillows, | ignited by the heater. Do not insert or allow foreign objects to

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) enter any ventilation or exhaust opening as this may cause an

from the front of the heater-fan and keep them away from the sides | glectric shock, fire, or damage the heater.

and rear.

* Do not use heater unattended. Use of extreme caution is necessary

when any heater is used by or near children, invalids, disabled | WARNING:

persons or pets ELECTRICAL SHOCK HAZARD

* Do not operate the heater with a damaged power cord or after the | D5 not use with damaged cord or plug. Use with adequate

heater malfunctions, has been dropped or damaged in any manner. electrical system that is up to code

Return heater to authorized service facility for examination, electrical

. or mechanical adjustment or repair. The supply cord has a polarized plug. As a safety feature this

plug will fit in a polarized outlet only one way. To prevent

Use your heater only in dry environments. This heater is not intended electric shock, match wide blade of plug to wide slot, fully

for use in a bathroom, laundry area, or similar locations, or near | ingert plug. if the plug does not fit contact a qualified

sinks, washing machines, swimming pools or other sources of water. electrician.

Never locate heater where it may fall into a bathtub or other water

eae Do not use in damp environments such as flooded | 9 not operate any heater with a damaged cord or plug or after

heater malfunctions, has been dropped or damaged in any

* Do not place the heater on a small, unlevel, uneven or any surface manner. Do not operate heater with a broken heating element

which might allow heater fo tip or fall. : or ceramic cone or any visual imperfections. For repairs

* For proper operation, heater should be placed on a smooth, covered under warranty, see warranty statement. For all other

non-combustible surface. Do not place on rugs, carpet, vinyl flooring repairs contact Comfort Zone® Customer Service by telephone

or other plastic surfaces. Not for use outdoors or in wet areas or mail for information and assistance

* This heater is not designed as a primary heat source

* Always plug heaters directly into a wall outlet/receptacle. Never use

with an extension cord or relocatable power tap (outlet/power strip). | PET OWNERS NOTE:

Always unplug heater when not in use. The health of birds and some small pets are extremely sensitive

Do not run power cord under carpeting. Do not cover cord with to the fumes given off during the initial use of many appliances.

throw rugs, runners or similar coverings. Arrange cord away from Although these fumes are not harmful to humans, it is

traffic area where it will not be tripped over. recommended that this heater not be used around birds and

© To disconnect heater, turn controls off then remove plug from outlet. small pets during its initial use until the manufacturing corrosion

* Do not insert or allow foreign objects to enter any ventilation or coatings burn off.

exhaust opening as this may cause an electric shock or fire or

damage the heater.

* To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

¢ Aheater has hot and arcing or sparking parts inside. Do not use it in

areas where gasoline, paint or flammable liquids are used or stored.

* Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock or

injury to persons or property.

Page 2

Source page 1 - Panel 3 (bottom left) (OCR)

USAGE: IMPORTANT SAFETY FEATURES

HEATER OPERATION: Always operate the heater in the upright The heater is equipped with an automatic overheat

position following all instructions and commendations listed in this protection device and an automatic tip-over sensor

manual. HEATER LOCATION: Place the heater in the area of the located under the base of the heater. If the heater grille

room that is coldest. HEATER CONNECTION: Plug heater directly is obstructed, the automatic overheat device will turn

into 120 Volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in the heater off. If the heater is tipped over, the automatic

outlet. A loose connection may cause overheating and damage tip-over switch will turn off the heater. If either safety

to the plug or heater. NOTE: The heater draws 8.33 amps sensor is activated, make sure the heater is on a level

during operation. To prevent overloading a circuit, do not plug surface and clear of all obstacles. Unplug the heater

the heater into a circuit that is servicing other electrical needs and allow it to cool down before restarting. After cooling

down and obstacles have been removed

TURNING HEATER ON: To start the heater, turn the POWER

SWITCH (left knob) from the off position to the LOW (700 Watt) CARE AND MAINTENANCE

or HIGH (1000 WATT) position. (During the heaters initial use, CLEANING: CAUTION-Before cleaning the heater be

you may experience a slight odor or smoking. This is the result

of the heating element lubrication “burning off”. This is normal sure to disconnect power cord and allow the heater to

and will go away after a few minutes of use.) cool completely. This heater should be cleaned at least

once a year to maintain proper performance. Clean the

outside surface with a clean damp cloth. Do not use

harsh chemical or abrasive cleaners. DO NOT

Power Sie IMMERSE THE HEATER IN WATER. Allow heater to dry

Switch Switch completely before use.

OPERATION SWITCH: This heater has two heat settings: REPAIR: DO NOT OPERATE THE HEATER WITHOUT

LOW (700 Watts) and HIGH (1000 Watts). Use the HIGH setting THE GRILLE IN PLACE. DO NOT USE THE HEATER IF

to raise the room temperature quickly. When the desired IT HAS MALFUNCTIONED OR BECOME DAMAGED IN

temperature is reached use the LOW setting to maintain ANY WAY.

temperature. It is usually sufficient to maintain a comfortable

temperature. STORAGE: Keep original carton for storage of the

heater. Coil and tie the power cord to avoid damage

TILT FEATURE: Your heater can tilt for adjusting the direction during storage.

of heat. To adjust the angle, loosen tilt adjustment knob and

move angle of the heater to desired position. Tighten tilt

adjustment knob to hold heater in position. Do not force the

heater in either direction beyond its guides.

TURNING OFF: Turn the selector switch to the OFF position

before unplugging or plugging in the heater. Heater should be

unplugged when not in use

OSCILLATION CONTROL: You can control the Oscillation

feature on the Heater by rotating the Oscillation Control (OSC)

switch located on the control panel of the heater.

. WA AZZ Zece0

USERS NOTE: \ SS

Ww sgegg?

The coils in the center of rr gg ri Ld

the dish are very hot. “a E] i

It is normal that not all coils 4

are glowing during use.

The non-glowing elements EONS 335

are functioning properly Mai SO SSSETES

and generating heat Non-glowing coils Glowing coils

Page 3

Source page 1 - Panel 4 (bottom right) (OCR)

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

L\ same

Cancer and Reproductive Harm

www.P65Warnings.ca.gov

Rev. 07/19/2023

Rev. 012017

Page 4