Comfort Zone Digital Baseboard Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ650B

Original source file(s): CZ650B.Instruction Manual.01.pdf; 125500.Instruction Manual.01.pdf

Source SHA-256: bb236178936c68e639729d1fd77d809e4210a3c5d613f347803e0afd7210ccec

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

290mm

210mm

Binding edge - dimensions:420X290

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

07/20/2023

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or

exclusion may not apply to you. Upon the expiration of this
warranty all such liability will terminate. No other warranties are
expressed or implied. This warranty gives you specific legal rights,
and you may also have other rights which vary from state to state.
No informal dispute settlement mechanisms are available. This
limited warranty is given in lieu of all other warranties.

Source page 1 - Panel 1 (top left) (OCR)

ver
IMPO
RTA
NT
neha, SAFETY FEA - = <
; ater is i
aan d valent | _ z
reat on levice loca’ "sinaide. |
heater gets heater sil | sobet hebes 4 Xs
overheat voter hot Or le is obstru © Body of te sa
thepeat the reotion device season te ut . sas S
ater, si e wi wth :
then vou e for ater Simply wa turn Tnomate nea i
that u may inutes rm powe eater off manufact original p as. co
= = = , 28 - | mar ufacturing re urenase nip fora sariod of one ye
ructi is on ater in s dow nplug warrant receipt, t within 3 is unit fal cas si
safety ti ions. Th asm and n and Uni y peri . o the retai O days cha mn
y tip- e he ere eat array perio’ tin ca ee =r
when over swi ater i level si “Bs cs = : : ;
: = 2 i. ed States, return it was pu 0 day: , return
simpl heater ti tot equi e with United nt. If th (OMe rst re a
ly stand r tips urn po pped wi no wa States e unit was p Brand tra =
heat over. T wer off itha rranty di , return sitio t dou
er . ores to th overheati oes n the uni hased ithe -
Cc upri um eh eat ot co rer eet =
& are AND M ie heater function Mr ses ae cone
ARN AINT ions | Al sorte nel lable te vere aa :
: 7 cca ven . This
M ING: EN Il impli eld liabl er iv "
‘= MouNG Oo Sea INL NCE: ane of jd waranes in sas i cs
rasi RVIC UG uratio of purpo neludin vara rt :
HEAT! ive cl ING THE pu nto th Mees he a :
ER eaner. .Do COR purchase e period , ifappli Ie are sir =
O before IN WATE s. DO NO not use h D BEFO implied We Some sta ofone ye tome = Eos
use. R. Allow T IMMER arsh che' RE you. Inci arranty la tes do vot ar from th iat a

¢)) CLEAN heater to d SE THE mical of M norgental or acts. so the alow imatons or |
CEATERINN IMPORT, ry completel arn encluded. Som real oe oe
N vacu N WAT ANT! y incidental o Some cu se :
um ER! !DO exclusi al or stale ta = :
This brush ! Clear NOT I usion m: conse al da ts 3 ee :
will attac nthe MME warra ay not quential alow ork -
DON remo hme! heat RSE e nty all it su =a :
OT ve lint nt on er grill xpress: such liabi te you nthe on :
DON ATTE and di your le with and ed or impli bility wi Upon th expiration caer
OT MPT irt fr vacuu the you m implied ill termi ne exp! ono ~
bod REM TO TA om insi m cle No inf wee a "s = =
: = = a he No ormal di 0 have arrant . No oth n of thi
|e he: HE HE. PART T e heat: . imited w ispute emer ne cc :
CAU ater wi ATER HE H er. arranty i settlem ghts whi vay om ms
TIO ithas GRIL EATE y is giveni vou of in a
thin N: Di oft cl LE. C R. This w: nin lieu hans rea
ner, h 0 not u: joth. lean th ha arranty gi _. = _ |
om st
heater. Neve cleaners gasoline, b © sigpute oat rights which vary - :
REPAIR RUSE ACO as they will paint wananty i olen i echan tom ose |
er en ate '
THE witnte NOTO OL OR oor damage th Manuf. n in lieu of vot are al se. =
IF IT HAS M IN FRCL oor THE LVENTS. e Mi Brands C 7 _ : ~
DAM A E H | me me | .

AGE LFUNCTIC NEN ET : ?

: = - mus we more S
tol
STO ANY W. EDOR cOMe a - =
E 16 Bee HEAT! vm =
hea E: Ke ~ ; Z =
7 z : mnwmrbran’s
ce a _ ‘comfortzonept
: _ . -_ neproducts.c
| .com
ory a the - WARNING:
te mn and Re :
z cer producti
.P65Warni seen
m=
Rev. 07/20/2 nen
023

Source page 1 - Panel 2 (top right) (OCR)

©) Comfort Zone. CZ650B Series

owerion

Features:

* Digital Thermostat and Timer ¢® Caution Indicator Light

¢ Two Heat Settings: ¢ Safety Overheat Protection

LOW Heat - 750 Watts ¢ Safety Tip-Over Protection

HIGH Heat - 1,500 Watts ¢ Silent Operation

(5,120 BTU) ¢ Stay Cool Body with

¢ Top Mounted Control Panel Dent-Resistant End Panels

¢ Power Indicator Light © 120V AC / 60Hz / 12.5A

&

x

3

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

©) Comfort Zone.

ED

USAG E Once the desired temperature is reached, press the MODE

button once to exit both options - this will return the display to

. the ambient temperature. Alternatively, the unit will automatically

HEATER OPERATION: . 7 . save and exit after 15 seconds of inactivity, returning the display

Always ° perate the heater in the upright position following all to the ambient temperature. After exiting, the Temperature

instructions and recommendations listed in this manual. Indicator Light will remain illuminated to show that the

HEATER LOCATION: Place the heater in the area of the room that thermostat option is active.

is coldest. Do not locate against walls or behind drapes or furniture.

NOTE: When the ambient air temperature is equal to or below

HEATER CONNECTION: Plug heater directly into 120 Volt the thermostat set point, the heater will automatically turn on.

AC, 60Hz wall outlet. Be sure plug fits tightly in outlet. A loose If the ambient air temperature is greater than the thermostat

connection may cause overheating and damage to the plug set point, the heater will turn

or heater. off - in this state, the Power ws \

and Temperature Indicator - oo

NOTE: To prevent overloading a circuit, do not plug the heater into Lights will remain illuminated i i(

a circuit that is servicing other electrical needs. and the ambient temperature ae | O comfort Zone.

OPERATING INSTRUCTIONS: willbe clisplayed. BE len =P

Plug the power cord into a wall outlet (120V AC, 60H2). Connect oe ee “ a re. @

heater to properly grounded outlets only. Power Indicator Light will heat setting (either Low or ‘ §@ 50 THer @

be illuminated and the unit will bein its standby State. In this state, High), press the MODE button | am

--"is shown on the display and indicates that the unit is on but two times to select the timer ; | @©0OO

not heating. option. This is indicated by GO MOP aa

TURN THE HEATER ON OR OFF BY PRESSING (()): tre tlanination ofthe Timer

Pressing the ON/OFF button once will select the Low Heat (750W) flashing “OOH on the display. ‘

setting, indicated by the illumination of the Low Heat Indicator Light. At this time, press the UP/DOWN buttons to set the length of

Pressing the ON/OFF button a second time will select the High time for the heater to run. The timer adjustment range is from

Heat (1,500W) setting, indicated by the illumination of the High Heat | 1 to 12 hours.

Indicator Light, Once the desired time is reached, press the MODE button once

Pressing the ON/OFF button a third time will return the heater to the | t0 exit this will return the display to the ambient temperature.

standby state. Make sure the heater is in the standby state before Alternatively, the unit will automatically save and exit after

unplugging. The heater should be unplugged when not in use. 15 seconds of inactivity, returning the display to the ambient

temperature. After exiting, the Timer Indicator Light will remain

NOTE: During the heater’s initial use, you may experience a slight illuminated to show that the timer option is active.

odor or smoking. This is the result of the heating element lubrication , ; ; :

“burning off”. This is normal and will go away after a few minutes To turn the timer off, select the timer option using the MODE button

of use. and adjust the time displayed to “OOH”.

NOTE: Heater will function in the Low or High heat setting NOTE: When the timer has reached its setting, the timer indicator

independently of the thermostat, when the thermostat is set to light will turn off and the heater will automatically turn off, returning

“00C” or “OOF”. to the standby state.

NOTE: The temperature value displayed in both heat settings is the USING THE THERMOSTAT AND TIMER AT THE SAME TIME:

current ambient temperature. It is possible to have both the thermostat and timer active at the

same time. To do so, follow the instructions under “Setting the

TEMPERATURE UNITS: Thermostat” and follow the instructions under “Setting the Timer”.

To switch between Celsius and Fahrenheit units, press the , : ,

MODE button once. The digital display will blink 3 times and then | NOTE: When both the thermostat and timer options are active, the

automatically switch. Temperature will reset to the default setting heater will remain on until the timer setting is reached. When the

when units are changed. timer has reached its setting, the heater will automatically turn off,

returning to the standby state.

SETTING THE THERMOSTAT:

When the heater is in the heat setting (either Low or High), press CAUTION INDICATOR LIGHT:

the UP/DOWN button once to select the thermostat option. This When overheating occurs, the Caution Indicator Light will illuminate

is indicated by the illumination of the Temperature Indicator Light and the heater will turn off immediately. Refer to the ‘Safety

and by a flashing “00C” on the display (or “OOF”, depending on Features’ section for heater reset instructions.

the selected units). At this time, press the UP/DOWN buttons to

raise or lower the temperature set point.

as °

-_-_- eee PFD

|

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

INTENDED USE READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial application. Use only with I N STR U CTl O N)

electrical wiring that is in good working order and that meets

applicable codes and ordinances. This heater must be plugged in WARNING: SHOCK HAZARD

to a 120V AC, 15 Amp (or larger) circuit. Do not plug anything Use your heater only in dry environments. This heater is

additional into the same circuit. If you have any questions whether not intended for use in a bathroom, laundry area, or similar

your wiring is adequate, consult a qualified electrician. Risk of fire, locations, or near sinks, washing machines, swimming pools

overheating, malfunction, property damage, injury or even death or other sources of water. Never locate heater where it may fall

may result if not adhered to. into a bathtub or other water receptacle. Do not use in damp

Use your heater only with a working smoke detector located in the environments such as flooded basements.

vicinity of your heater.

While using your heater, you should follow the IMPORTANT WARNING: Hor SURFACES . This heater is hot wh

INSTRUCTIONS listed below. As part of those instructions, we 70 Not toucn | 4 yo No er Mt tb in Ki is Nh er ls - ot w i

have used the word “WARNING? to indicate the level of hazard: in use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING indicates a hazard which, if not avoided, could result in provided, use handles when moving this heater.

injury or death.

WARNING: FIRE HAZARD

IMPORTANT INSTRUCTIONS Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

When using electrical appliances, basic safety precautions should always heat. DO NOT USE in areas where gasoline, paint or flammable

be followed to reduce the risk of fire, electric shock and injury to persons, materials are used or stored. Keep combustible materials such

including the following: as furniture, pillows, bedding, papers, clothes and curtains at

© Read all the instructions before using this heater. least 3 feet (0.9 m) from the front of the heater and keep them

* This heater is hot when in use. To avoid burns, do not let bare skin away from the sides and rear. To prevent a possible fire, do not

touch hot surfaces. Use provided handle when moving this heater. Keep block air intakes or exhaust in any manner. Do not use on soft

combustible materials, such as furniture, pillows, bedding, papers, surfaces, like a bed, where openings may become blocked. Do

clothes and curtains at least 3 feet (0.9 meters) from the front of the not place the heater near a bed because objects such as pillows

heater and keep them away from the sides and rear. or blankets can fall off the bed and be ignited by the heater.

* Do not use heater unattended. Use of extreme caution is necessary when | Do not insert or allow foreign objects to enter any ventilation or

any heater is used by or near children, invalids, disabled persons or pets. | exhaust opening as this may cause an electric shock, fire, or

* Do not operate the heater with a damaged power cord or after the damage the heater.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical or WARNING: ELECTRICAL SHOCK HAZARD

mechanical adjustment or repair. Do not use with damaged cord or plug. Use with adequate

* Do not use heater outdoors. electrical system that is up to code.

* Use your heater only in dry environments. This heater is not intended

for use in a bathroom, laundry area, or similar locations, or near sinks, CAUTION: TO PREVENT ELECTRIC SHOCK .

washing machines, swimming pools or other sources of water. Never This product has a polarized two prong plug (one blade is _

locate heater where it may fall into a bathtub or other water container. wider than the other) that must be fully inserted into a matching

Do not use in damp environments such as flooded basements. properly grounded outlet. This plug is designed to fit a polarized

© Do not place the heater on a small, unlevel, uneven or any surface which outlet only one way. If the plug does not fit fully into the outlet,

might allow heater to tip or fall. reverse the plug. If the plug still does not fit, contact a qualified

* For proper operation, heater should be placed on a smooth, electrician. Do not attempt to defeat this safety feature.

non-combustible, level surface. Do not place on rugs, carpet, vinyl Do not operate any heater with a damaged cord or plug

flooring or other plastic surfaces. Not for use outdoors or in wet areas. or after heater malfunctions, has been dropped or damaged

© This heater is not designed as a primary heat source. in any manner. Do not operate heater with a broken heating

Always plug heaters directly into a wall outlet/receptacle. Never use with element or ceramic cone or any visual imperfections. Disconnect

an extension cord or relocatable power tap (outlet/power strip). Always power before servicing. For repairs covered under warranty, see

unplug heater when not in use. warranty statement. For all other repairs contact Comfort Zone®

* Do not run power cord under carpeting. Do not cover cord with throw Customer Service by telephone or mail for information

rugs, runners or similar coverings. Arrange cord away from traffic area and assistance.

where it will not be tripped over.

* To disconnect heater, turn controls off then remove plug from outlet. PET OWNERS NOTE:

* Do not insert or allow foreign objects to enter any ventilation or exhaust The health of birds and some small pets are extremely

opening as this may cause an electric shock or fire or damage the heater. sensitive to the fumes given off during the initial use of many

* To prevent a possible fire, do not block air intakes or exhaust in any appliances. Although these fumes are not harmful to humans, it

manner. Do not use on soft surfaces like a bed, where openings may is recommended that this heater not be used around birds and

become blocked. small pets during its initial use until the manufacturing corrosion

* A heater has hot and arcing or sparking parts inside. Do not use it in coatings burn off.

areas where gasoline, paint or flammable liquids are used or stored.

Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock

or injury to persons or property.

o---"""ere*rereeeeeeeeeew-w-w-wrn"wwwwwmeoene

Tl

a SUOIONAJSU] BSOU] SACS WOd's}ONpoJdauOZHOJWOO' MMM

en