Comfort Zone Electric Utility Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ798

Original source file(s): CZ798, CZ798BK.Instruction Manual.01.pdf; CZ798GR3.Instruction Manual.01.pdf; 125037.Instruction Manual.01.pdf; 125038.Instruction Manual.01.pdf; 125048.Instruction Manual.02.pdf

Source SHA-256: d25952bb4e9c3ca820089d68bb5777c1f57fce297eb73655abc35c268148e884

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Page 1 (cover)

Page 2 (inside)

Page 3 (inside)

Page 4 (back)

Black border shows

page size and should

not print

Black border shows

page size and should

not print

11.0"

8.50"

Source page 1 - Panel 1 (top left) (OCR)

| Page 1 (cover) |

Model #CZ798 Seri

O Comfort Zone. “oe! #02798 Serres

America’s Heating and Cooling Choice

PY

if 7 - .

Electric Utility Heater

Features:

-Adjustable Thermostat with Anti-freeze Setting

‘Dual Heat Settings:

1500 watts (5120 BTUs)

1300 watts

‘Front Mounted Control Panel

*Power Indicator Light

‘Safety Overheat Protection

‘Safety Tip-Over Protection

-Convenient Carry Handle él)

-Sturdy Metal Frame us

1 20V A.C. / 60HZz. 1 2.5A Intertek

Save These Instructions

- | Black border shows /

Source page 1 - Panel 2 (top right) (OCR)

Page 2 (inside) |

INTENDED USE: .

This product is intended for indoor residential and office use only, not WARNING: SHOCK HAZARD .

for industrial or other commercial application. Use only with electrical Use your heater only in dry environments. This heater is not

wiring that is in good working order and that meets applicable codes intended for use in a athroom, laundry area, or similar |

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp. ocations, or near sinks, washing machines, swimming pools or

(or larger) circuit. Do not plug anything additional into the same circuit. other sources of water. Never locate heater where it may fall

If you have any questions whether your wiring is adequate, consult a into a bathtub or other water container. Do not use heater

qualified electrician. Risk of fire, overheating, malfunction, property outdoors. Do not use in damp environments such as flooded

damage, injury or even death may result if not adhered to. basements.

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT Srovi , ; ;

INSTRUCTIONS listed below. As part of those instructions, we have surfaces. If provided, use handles when moving this heater.

used the word “WARNING to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

| M PO RTANT | NSTR U CTIO NS heat. DO NOT USE in areas where gasoline, paint or

flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

¢ Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

¢ This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not insert or allow foreign objects to enter

heater. Keep combustible materials, such as furniture, pillows, any ventilation or exhaust opening as this may cause an

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) electric shock, fire, or damage the heater.

from the front of the heater-fan and keep them away from the sides

and rear.

* Do not use heater unattended. Use of extreme caution is necessary WARNING:

when any heater is used by or near children, invalids, disabled ELECTRICAL SHOCK HAZARD

persons or pets. Do not use with damaged cord or plug. Use with adequate

¢ Do not operate the heater with a damaged power cord or after the electrical system that is up to code.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical The supply cord has a polarized plug. As a safety feature this

or mechanical adjustment or repair. plug will fit in a polarized outlet only one way. To prevent

¢ Do not use heater outdoors. electric shock, match wide blade of plug to wide slot, fully

e Use your heater only in dry environments. This heater is not intended insert plug. If the plug does not fit contact a qualified

for use in a bathroom, laundry area, or similar locations, or near electrician.

sinks, washing machines, swimming pools or other sources of water.

Never locate heater where it may fall into a bathtub or other water Do not operate any heater with a damaged cord or plug or

container. Do not use in damp environments such as flooded after heater malfunctions, has been dropped or damaged in

basements. any manner. Do not operate heater with a broken heating

¢ Do not place the heater on a small, unlevel, uneven or any surface element or ceramic cone or any visual imperfections. For

which might allow heater to tip or fall. repairs covered under warranty, see warranty statement. For all

¢ For proper operation, heater should be placed on a smooth, other repairs contact Comfort Zone® Customer Service by

non-combustible surface. Do not place on rugs, carpet, vinyl flooring telephone or mail for information and assistance.

or other plastic surfaces. Not for use outdoors or in wet areas.

e This heater is not designed as a primary heat source.

e Always plug heaters directly into a wall outlet/receptacle. Never use PET OWNERS NOTE:

with an extension cord or relocatable power tap (outlet/power strip). The health of birds and some small pets are extremely

Always unplug heater when not in use. sensitive to the fumes given off during the initial use of many ;

© Do not run power cord under carpeting. Do not cover cord with appliances. Although these fumes are not harmful to humans, it

throw rugs, runners or similar coverings. Arrange cord away from is recommended that this heater not be used around birds and

traffic area where it will not be tripped over. small pets during its initial use until the manufacturing

e To disconnect heater, turn controls off then remove plug from outlet. corrosion coatings burn off.

¢ Do not insert or allow foreign objects to enter any ventilation or

exhaust opening as this may cause an electric shock or fire or

damage the heater.

¢ To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may become blocked.

e A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.

e Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

Black border shows /

Source page 1 - Panel 3 (bottom left) (OCR)

. . page size and should

Page 3 (inside) not pt \

USAGE: ASSEMBLY INSTRUCTIONS

HEATER OPERATION: Always operate the heater in the upright position following all instructions and recommendations listed in this manual

Before initial use some assembly is required. With a phillips screwdriver, attach handle to heater body HEATER using screws provided as shown in the photo.

LOCATION: Place the heater in the area of the room that ae is coldest.

HEATER CONNECTION: Plug heater directly as anal into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits lo | tightly in outlet. A loose connection may cause , overheating and damage to the plug or heater. NOTE: f | To prevent overloading a circuit, do not plug the f heater into a circuit that is servicing other electrical tf i needs. oi. ,

TURNING HEATER ON: To start the heater, turn the On/Off Power Level/Fan Dial from the OFF position to the 1300 or 1500 watt setting. Then rotate the Thermostat Control clockwise to the HIGH THERMOSTAT position as described below. (During the heaters initial use, you may experience a slight odor or smoking. This is the result of the heating element lubrication burning off’. This is normal and will go away after a few minutes of use.)

IMPORTANT SAFETY FEATURES

This heater includes a visual alarm to warn that parts of the heater are getting excessively hot. If the caution light comes on, immediately turn the heater off and inspect for any objects on or adjacent to the heater that may cause high temperatures. DO NOT OPERATE THE HEATER WITH THE CAUTION LIGHT ON. The power indicator light, located near the power Indicator control, lights whenever the heater is turned on. The Light F 7 2 e . heater is equipped with an automatic overheat rey a onTon Es Caution. protection device located inside the body of the ssc byt e Light heater. If the heater grille is obstructed, or if the = a ‘@) a heater gets too hot for any reason, the automatic POON ew " @ overheat protection device will turn the heater off. To Fan Dial a 5 reset the heater, simply turn power off and unplug the re) ie z Thermostat heater for 10 minutes until it cools down and then you : ay <5 Control may plug the heater in and restart. Be sure that the Anti freeze Oe heater is on a smooth level surface with no

9 O comfort Zone obstructions. The heater is also equipped with a
safety tip-over switch to turn power off to the heater
when the heater tips over. To resume heater functions
simply stand heater upright.
POWER LEVEL SWITCH: This heater has two heat
settings: 1300 and 1500 watts. Use the higher setting CARE AND MAINTENANCE .
(1500 watt) to raise the room temperature quickly. CLEANING: CAUTION-Before cleaning the heater be
When the desired temperature is reached use the sure to disconnect power cord and allow the heater to
lower 1300 watt setting. It is usually sufficient to cool completely. This heater should be cleaned at least
maintain a comfortable temperature. once a year to maintain proper performance. Clean
the outside surface with a clean damp cloth. Do not
ADJUSTABLE THERMOSTAT WITH ANTI-FREEZE use harsh chemical or abrasive cleaners. DO NOT
SETTING: After heater has been turned on and the IMMERSE THE HEATER IN WATER. Allow heater to
room has reached the desired temperature, slowly dry completely before use.
rotate the thermostat knob counter-clockwise until the
heater shuts off (you should hear a faint “click”). By REPAIR:
leaving the thermostat at this setting it will DO NOT OPERATE THE HEATER WITHOUT THE
automatically maintain this temperature. To lower GRILLE IN PLACE. DO NOT USE THE HEATER IF IT
temperature, rotate the knob further HAS MALFUNCTIONED OR BECOME DAMAGED IN
counter-clockwise (towards the LOW position). To ANY WAY. RETURN HEATER TO AUTHORIZED
raise the temperature, rotate the thermostat knob FACILITY FOR EXAMINATION, ELECTRICAL OR
clockwise (towards the HIGH position). MECHANICAL ADJUSTMENT OR REPAIR.
When set to the Anti-Freeze setting, the Heater will STORAGE: Keep original carton for storage of the
turn on whenever the temperature drops below 40°F, heater. Coil and tie the power cord to avoid damage
which is helpful to economically prevent ice formation
in garages and other unheated spaces.
TURNING OFF: Turn the On/Off Power Level/Fan Dial
to the OFF position before unplugging or plugging in
the heater. Heater should be unplugged when not in

Source page 1 - Panel 4 (bottom right) (OCR)

Page size and should
Page 4 (back) notin \

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable,

are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC
113 Fillmore St
Bristol, PA 19007 11.0"
1-877-420-7555 .
www.mrbrands.com
www.comfortzoneproducts.com
L\ saenne:
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov
Rev. 07/19/2023
Rev. 03/30/21
YI a> |