Comfort Zone Electric Oil-Filled Radiator

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ8008N

Original source file(s): CZ8008N.Instruction Manual.01.pdf; 120278.Instruction Manual.01.pdf

Source SHA-256: 548d162f1d8fb5989fad0ee7d637c5605de8dc1032b454919e849d0b7fce6e55

Original PDF pages: 4 | Recovered reading units: 6

Source page 1 (embedded text)

2023-07-20Single-black saddle-stitched coated paper

Source page 2 - OCR transcription (OCR)

©) Comfort Zone.

ES

INTENDED USE: READ & SAVE THESE

This product is intended for indoor residential and office use only, not

for industrial or other commercial application. Use only with electrical I NSTR U CTI (@) NS

wiring that is in good working order and that meets : WARNING: SHOCK HAZARD

applicable codes and ordinances. This heater must be plugged in to Use your heater only in dry environments. This heater is not intended

a 120V AC, 15 Amp (oF larger) circuit. Do not plug anything additional for use in a bathroom, laundry area, or similar locations, or near sinks,

into the same circuit. If you have any questions whether your wiring washing machines, swimming pools or other sources of water. Never

is adequate, consult a qualified electrician, Risk of fire, overheating, locate heater where it may fall into a bathtub or other water receptacle.

malfunction, Property damage, injury or even death may result if not Do not use in damp environments such as flooded basements.

adhered to.

Use your heater only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater. Do not touch body of heater when in use. This heater is hot when in use,

‘to avoid burns, do not let bare skin touch hot surfaces. If provided, use

While using your heater, you should follow the IMPORTANT handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard: WARNING | WARNING: FIRE HAZARD

indicates a hazard which, if not avoided, could result in injury or death. Heater has hot and arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat. DO NOT

IM PORTANT INSTR UCTIONS USE in areas where gasoline, paint or flammable materials are used or

stored. Keep combustible materials such as furniture, pillows, bedding,

When using electrical appliances, basic safety precautions should always papers, clothes and curtains at least 3 feet (0.9 m) from the front of the

be followed to reduce the risk of fire, electric shock and injury to persons, heater and keep them away from the sides and rear. To prevent a possible

including the following: fire, do not block air intakes or exhaust in any manner. Do not use on soft

«Read all the instructions before using this heater. surfaces, like a bed, where openings may become blocked. Do not place

© This heater is hot when in use. To avoid burns, do not let bare skin the heater near a bed because objects such as pillows or blankets can

touch hot surfaces, Use provided handle when moving this heater. Keep | ‘all off the bed and be ignited by the heater. Do not insert or allow foreign

combustible materials, such as furniture, pilows, bedding, papers, objects to enter any ventilation or exhaust opening as this may cause an

clothes and curtains at least 3 feet (0.9 meters) from the front of the electric shock, fire, or damage the heater.

heater and keep them away from the sides and rear. WARNING: ELECTRICAL SHOCK HAZARD

* Do not use heater unattended. Use of extreme caution is necessary Do not use with damaged cord or plug. Use with adequate electrical

when any heater is used by or near children, invalids, disabled persons system that is up to code.

or pets.

* Do not operate the heater with a damaged power cord or after the CAUTION: TO PREVENT ELECTRIC SHOCK

heater malfunctions, has been dropped or damaged in any manner. This product has a polarized two prong plug (one blade is wider

Return heater to authorized service facility for examination, electrical or than the other) that must be fully inserted into a matching properly

mechanical adjustment or repair. grounded outlet. This plug is designed to fit a polarized outlet only one

* Do not use heater outdoors way. If the plug does not fit fully into the outlet, reverse the plug. If the

Use your heater only in dry environments. This heater is not intended Plug still does not fit, contact a qualified electrician. Do not attempt to

for use in a bathroom, laundry area, or similar locations, or near sinks, defeat this safety feature.

washing machines, swimming pools or other sources of water. Never

locate heater where it may fall into a bathtub or other water container. Do not operate any heater with a damaged cor d or plug or after heater

Do not use in damp environments such as flooded basements. matfunctions, has been dropped or damaged in any manner. Do not

. operate heater with a broken heating element or ceramic cone or any

* Do not place the heater on a small, unlevel, uneven or any surface which | 41 imperfections. Disconnect power before servicing, For repairs

might allow heater to tip or fall covered under warranty, see warranty statement. For all other repairs

* For proper operation, heater should be placed ona smooth, contact Comfort Zone® Customer Service by telephone or mail for

non-combustible, level surface. Do not place on rugs, carpet, vinyl information and assistance.

flooring or other plastic surfaces. Not for use outdoors or in wet areas.

* This heater is not designed as a primary heat source. WARNING: HYPERTHERMIA HAZARD

Always plug heaters directly into a wall outlet/receptacle. Never use with Hyperthermia can result in death. Symptoms of hyperthermia include

an extension cord or relocatable power tap (outlet/power strip). Always high body temperature, headache, nausea, vomiting, tiredness,

unplug heater when not in use. dizziness, fainting, and rapid pulse. If you begin to experience

* Do not run power cord under carpeting. Do not cover cord with throw symptoms related to hyperthermia, turn off the heater and seek

rugs, runners or similar coverings. Arrange cord away from traffic area medical attention.

where it will not be tripped over. To avoid excessive room temperatures which can cause hyperthermia,

* To disconnect heater, turn controls off then remove plug from outlet. DO NOT leave product running unattended in a confined space around

* Do not insert or allow foreign objects to enter any ventilation or exhaust infants, or individuals with reduced physical, sensory, or mental

opening as this may cause an electric shock or fire or damage the heater. | capabilities,

* To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may PET OWNERS NOTE:

become blocked. The health of birds and some small pets are extremely sensitive to the

* Aheater has hot and arcing or sparking parts inside, Do not use it in fumes given off during the initial use of many appliances. Although

areas where gasoline, paint or flammable liquids are used or stored. these fumes are not harmful to humans, it is recommended that this

* Use this heater only as described in this manual. Any other use not heater not be used around birds and small pets during its initial use

recommended by the manufacturer may cause fire, electric shock Until the manufacturing corrosion coatings burn off.

or injury to persons or property.

2

Source page 3 - OCR transcription (OCR)

USAGE: WHEEL ASSEMBLY INSTRUCTIONS:

HEATER OPERATION: Always operate the heater in the upright CAUTION: The heater is packaged with the feet unattached.

position following all instructions and recommendations listed in You must attach them before operating the heater.

this manual. HEATER LOCATION: Place the heater in the area F

i WARNING: Do not operate without feet attached.

a ine into re ve bereaved co CTION: in neater Do operate the heater only in upright position (feet on the

directly into Olt AG, GOFz wall outlet. Be sure plug fits tightly | bottom, controls on the top), any other position could create

in outlet. A loose connection may cause overheating and damage a hazardous situation.

to the plug or heater. NOTE: To prevent overloading a circuit, do °

not plug the heater into a circuit that is servicing other electrical 1 a

needs. Make sure heater is at least three (3) feet away from walls, ee - oreweree

furniture, and other obstacles. aC 4 Se we

Ni 8 ap CO)

TURNING HEATER ON: aw 4 | | |

The Power Indicator Light will illuminate to show the heater is

plugged in and has electric power. The heater has three heat ; .

settings: 600, 900 and 1,500 watts. Use the 1,500 watt setting 1. Place the radiator body upside-down on a scratch-free

to raise the room temperature quickly while thermostat control location, make sure it is stable and will not fall.

is at its highest setting. (During the heaters initial use, you may 2. Screw off the wing nuts from the U-shaped bolt provided,

experience a slight odor or smoking. This is the result of residual attach the U-shaped bolt to the U-facing flange between first

lubrication on the steel “burning off”. This is normal and will and second fins (near the front cover).

go away after a few minutes of use.) When desired temperature . .

is reached, the 600 or 900 watt setting may be sufficient to 3. To attach the castor mounting plate to the radiator body, you

maintain a comfortable temperature. should insert the threaded ends of the U bolt in the holes on

the castor mounting plate.

POWER CONTROL DIAL: 4. Screw the wing nuts back to the U bolt and fasten the wing

* Position |: Low - provides 600 watts of heat output nut properly. Note: do not over tighten, which may cause

* Position II: Med - provides 900 watts of heat output the damage of radiator flange.

* Position III: High - provides 1500 watts of heat output 5. Screw off spherical nut from the castor, align the shaft to the

SETTING THERMOSTAT: hole of the castor mounting plate, insert in, and screw on the

After the unit has warmed up, slowly rotate the thermostat knob spherical nut.

counter-clockwise until the thermostat shuts off (you will hear 6. Repeat 2, 3, 4 and 5 on the rear of radiator for mounting of

a faint “click” sound). Leaving the thermostat at this setting will the rear castors. Note: the rear castors must be mounted

automatically maintain this temperature. For a lower temperature, between the end two fins.

rotate the knob further counter-clockwise.

TO TURN HEATER OFF:

Rotate Power Control Dial to OFF position. Unplug unit when

not in use.

-

=

ae

Thermostat a ~ \

Control 0

bts

Power Can

Control. > ¥

Dial

Power 7

Indicator. ---->

Light ae

TTT

Source page 4 (embedded text)

07/18/23

This unit is guaranteed to the original retail purchaser against

defects in quality or workmanship for a period of one year

from the date of original purchase. If this unit fails because

of a manufacturing defect within 30 days of purchase, return

the unit, with your receipt, to the retailer. After 30 days, but

within the warranty period, if the unit was purchased within the

continental United States, return it, to Mr. Brands LLC for repair

or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**

Mr. Brands LLC
113 Fillmore St
Bristol, PA 19007
1-877-420-7555
www.mrbrands.com
www.comfortzoneproducts.com