Comfort Zone Stove Style Electric Fireplace Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZFP4

Original source file(s): CZFP4.Instruction Manual.01.pdf; 125097.Instruction Manual.01.pdf

Source SHA-256: aff0466729fdd0fe2e47c302b5d6baaab8ba57cda1afeff1f9a2f538fb05e2ba

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Binding edge - dimensions:580X210

290mm

210mm

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

07/20/2023

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the **warranty period, if the unit was purchased within the continental** United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This **warranty does not cover damage caused by misuse, abuse,** overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed

and excluded. Some states do not allow the exclusion of limitation

of incidental or consequential damages, so this limitation or

exclusion may not apply to you. Upon the expiration of this

warranty all such liability will terminate. No other warranties are

expressed or implied. This warranty gives you specific legal rights,

and you may also have other rights which vary from state to state.

No informal dispute settlement mechanisms are available. This

limited warranty is given in lieu of all other warranties.

Source page 1 - Panel 1 (top left) (OCR)

©) Comfort Zone.

©) Comirort Zone

SD

CARE AND MAINTENANCE LIMITED WARRANTY

CLEANING: This unit is guaranteed to the original retail purchaser against

CAUTION - Before cleaning the heater be sure to disconnect defects in quality or workmanship for a period of one year from

power cord and allow the heater to cool completely. the date of original purchase. If this unit fails because of a

Clean the outside surface with a clean damp cloth. Do not use manufacturing defect within 30 days of purchase, return the unit,

harsh chemical or abrasive cleaners. DO NOT IMMERSE THE with your receipt, to the retailer. After 30 days, but within the

HEATER IN WATER. Allow heater to dry completely before use. warranty period, if the unit was purchased within the continental

Use a vacuum or duster to keep heat and vent area clean and United States, return it, to Mr. Brands LLC for repair or

free of dust and dirt. replacement. If the unit was purchased outside the continental

United States, return the unit to the place of purchase. This

REPAIR: warranty does not cover damage caused by misuse, abuse,

DO NOT OPERATE THE HEATER WITHOUT THE GRILLE overheating or alteration. Repairs made by anyone other than

IN PLACE. DO NOT USE THE HEATER IF IT HAS Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY. DO will not be held liable for any losses due to neglectful operation.

NOT REMOVE BACK COVER OF HEATER; NO SERVICEABLE All implied warranties, including the warranties of merchantability

PARTS and of fitness of purpose, if applicable, are hereby limited in

. duration to the period of one year from the date of original retail

STORAGE: aves

we . . purchase. Some states do not allow limitations on how long an

Keep original carton for storage of the heater. Coil and tie the implied warranty lasts, so the above limitations may not apply to

power cord to avoid damage during storage. you. Incidental or consequential damages arising from a breach

of either express or implied warranties are hereby disclaimed

= and excluded. Some states do not allow the exclusion of limitation

of incidental or consequential damages, so this limitation or

= exclusion may not apply to you. Upon the expiration of this

warranty all such liability will terminate. No other warranties are
([D) expressed or implied. This warranty gives you specific legal rights,
and you may also have other rights which vary from state to state.
OD) No informal dispute settlement mechanisms are available. This
N limited warranty is given in lieu of all other warranties.
This warranty gives you specific legal rights, and you may also
have other rights which vary from state to state. No informal
dispute settlement mechanisms are available. This limited
warranty is given in lieu of all other warranties.
Manufactured for:
Mr.Brands LLC
113 Fillmore St
Bristol, PA 19007
1-877-420-7555
www.mrbrands.com
www.comfortzoneproducts.com
L\ cusne:
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov
Rev. 07/20/2023

Source page 1 - Panel 2 (top right) (OCR)

O Comfort Zone. CZFP4 Series
Sam)
Stove Style
Electric Fireplace Heater
Features:
e Realistic 3-D Flame Effect
with or without heat
¢ 2 Heat Settings:
High - 1500 watts (5120 BTU)
Low - 750 watts
e Adjustable Thermostat
e Fan-forced for Wide Heat Dispersion
¢ Stay Cool Composite Body
¢ Safety Overheat Protection
e Safety Tip-over Cutoff Switch Protection
¢ 120V A.C., 60Hz, 12.5A =
3
Ke)

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

©) Comfort Zone.

Oo Comiort Zone

USAGE SETTING THE THERMOSTAT

HEATER OPERATION: Always operate the heater in the upright | After heater has been turned on and the room has reached

position following all instructions and recommendations listed in the desired temperature, slowly rotate the thermostat knob

this manual. counter-clockwise until the heater shuts off (you should

hear a faint "click"). By leaving the thermostat at this setting

HEATER LOCATION: Place the heater in the area of the room it will automatically maintain this temperature. To lower the

that is coldest. The heater should not be placed immediately temperature, rotate the knob further counter-clockwise towards

under a power outlet. the LOW (-) position. To raise the temperature, rotate the

thermostat knob clockwise towards the HIGH (+) position.

HEATER CONNECTION: Plug heater directly into 120 Volt A.C.,

60Hz wall outlet. Be sure plug fits tightly in outlet. A loose

connection may cause overheating and damage to the plug or TURNING HEATER OFF

heater. Slide the Main Power Switch © OFF «O» to discontinue use.

. rn Once the unit is turned off, both heat switches may remain in any

NOTE: To prevent overloading a circuit, do not plug the heater wae d will have no power. They will continue to have the

into a circuit that is servicing other electrical needs. position an wn av power. y wi nu v

same set functions when the heater is turned back on. Heater

should be unplugged when not in use.

TURNING HEATER ON

For Flame Effect Only,

Slide the Main Power ON/OFF Switch ©® to ON «-» position to IM PORTANT SAFETY FEATU R ES

have the 3-D flame effect without heat. The heater is equipped with an automatic overheat protection

device located inside the body of the heater. If the heater grille

For Low Heat - 750 watts, is obstructed, or if the heater gets too hot for any reason, the

Slide the Main Power ON/OFF Switch © to ON «-» position automatic overheat protection device will turn the heater off.

and slide switch I to ON «-» position. To reset the heater, simply turn power off and unplug the heater

. for 10 minutes until it cools down and you may plug the heater

For High Heat - 1500 watts, in and restart the heater. Be sure that the heater is on a smooth

Slide the Main Power ON/OFF Switch ©/¥ to ON «-» position level surface with no obstructions.

and slide both switch I and switch II to ON «-» positions.

Safety Tip-Over Switch is built-in to automatically turn off the

heater if it tips over. To resume heater functions, simply stand

CONTROL PANEL heater upright on a level surface and follow user operation

on the side panel of heater instructions.

© ON/OFF Switch:

I (e) + Main Power and Simulated flame

CoE ttt heat LEGASSEMBLY

I ae) Simple assembly is required if the legs Fig. 1 _

of your heater arrive unassembeled. -_--- \

I go Using a phillips screwdriver, thread SEXY

Two Switches for HEAT SETTINGS: three screws through the holes in each 3

. leg as illustrated in Fig. 1 and tighten TE

*Switch I = Low (750W) them down counter-clockwise onto the -~_

iN ¢Switch I + II Combined = High (1500W) A : L ty

rN underside of the heater. Please note: by Q\

extra screws are provided, you may

oa + have some left over after assembly. _-))

+ Adjustable Thermostat =

er ; |

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

©) www.comfortzoneproducts.com

-_-_-_-_-_-_-_--_-_-

INTENDED USE READ & SAVE THESE

This product is intended for indoor residential and office use only, not

for industrial or other commercial applications. Use only with electrical INSTRUCTIONS!

wiring that is in good working order and that meets applicable codes and

ordinances. This heater must be plugged into a 120 Volt A.C., 15 AMP WARNING: SHOCK HAZARD

(or larger) circuit. Do not plug anything additional into the same circuit. Use your heater only in dry environments. This heater is not intended

If you have any questions whether your wiring is adequate, consult a for use in a bathroom, laundry area, or similar locations, or near sinks,

qualified electrician. Risk of fire, overheating, malfunction, property washing machines, swimming pools or other sources of water. Never

damage, injury or even death may result if not adhered to. locate heater where it may fall into a bathtub or other water container.

Use your heater only with a working smoke detector located in the Do not use heater outdoors. Do not use in damp environments such as

vicinity of your heater. flooded basements.

While using your heater, you should follow the IMPORTANT

INSTRUCTIONS listed below. As part of those instructions, we have WARNING: HOT SURFACES

used the word "WARNING to indicate the level of hazard: WARNING Do not touch body of heater when in use. This heater is hot when in use,

indicates a hazard which, if not avoided, could result in injury or death. : y . . . ,

to avoid burns, do not let bare skin touch hot surfaces. If provided, use

IM PORTANT INSTRUCTIONS handles when moving this heater.

When using electrical appliances, basic safety precautions should always WARNING: FIRE HAZARD

be followed to reduce the risk of electric shock, fire, or injury to persons, . . a

. . . rane Heater has hot and arcing or sparking parts inside. Do not use near

including the following precautions:

combustible materials or flammable gases or sources of heat. Do not

* Read all the instructions before using this heater. use in areas where gasoline, paint or flammable materials are used or

¢ This heater is hot when in use. To avoid burns, do not let bare skin stored. Keep combustible materials such as furniture, pillows, bedding,

touch hot surfaces. Use provided handle when moving this heater. papers, clothes and curtains at least 3 feet (0.9 meters) from the front

Keep combustible materials, such as furniture, pillows, bedding, of the heater and keep them away from the sides and rear. To prevent a

papers, clothes and curtains at least 3 feet (0.9 meters) from the front possible fire, do not block air intakes or exhaust in any manner. Do not

of the heater and keep them away from the sides and rear. use on soft surfaces, like a bed, where openings may become blocked.

oo, Do not insert or allow foreign objects to enter any ventilation or exhaust

* Do not use heater unattended. Use of extreme caution is necessary opening as this may cause an electric shock, fire, or damage the heater.

when any heater is used by or near children, invalids, disabled persons

or pets.

¢ Do not operate the heater with a damaged power cord or after the WARNING: ELECTRICAL SHOCK HAZARD

heater malfunctions, has been dropped or damaged in any manner. Do not use with damaged cord or plug. Use with adequate electrical

Return heater to authorized service facility for examination, electrical or system that is up to code.

mechanical adjustment or repair. The supply cord has a polarized plug. As a safety feature this plug will fit

¢ Do not use heater outdoors. in a polarized outlet only one way. To prevent electric shock, match wide

¢ Use your heater only in dry environments. This heater is not intended blade of plug to wide slot, fully insert plug. If the plug does not fit contact

for use in a bathroom, laundry area, or similar locations, or near sinks, a qualified electrician.

washing machines, swimming pools or other sources of water. Never Do not operate any heater with a damaged cord or plug or after heater

locate heater where it may fall into a bathtub or other water container. malfunctions, has been dropped or damaged in any manner. Do not

Do not use in damp environments such as flooded basements. operate heater with a broken heating element or ceramic cone or any

* Do not place the heater on a small, unlevel, uneven or any surface visual imperfections. For repairs covered under warranty, see warranty

which might allow heater to tip or fall. statement. For all other repairs contact Comfort Zone® Customer Service

. by telephone or mail for information and assistance.

¢ For proper operation, heater should be placed on a smooth, non-

combustible surface. Do not place on rugs, carpet, vinyl flooring or

other plastic surfaces. Not for use outdoors or in wet areas. PET OWNERS NOTE:

* This heater is not designed as a primary heat source. The health of birds and some small pets are extremely sensitive to the

* Always plug heaters directly into a wall outlet/receptacle. Never use fumes given off during the initial use of many appliances. Although these

with an extension cord or relocatable power tap (outlet/power strip). fumes are not harmful to humans, it is recommended that this heater

Always unplug heater when not in use. not be used around birds and small pets during its initial use until the

. . manufacturing corrosion coatings burn off.

¢ Do not run power cord under carpeting. Do not cover cord with throw

rugs, runners or similar coverings. Arrange cord away from traffic area where it will not be tripped over.

¢ To disconnect heater, turn controls off then remove plug from outlet.

¢ Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire or damage the heater.

¢ To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces like a bed, where openings may become blocked.

¢ A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored.

¢ Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

DO

et

Tl

a SUOI}IMJSU] SS9U_L SAPS Wo9d'sjONpoJdeuoZOJWOo' MMM

aA