Comfort Zone Quartz Tower Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZQTV007BK

Original source file(s): CZQTV007BK.Instruction Manual.01.pdf; CZQTV007EBK.Instruction Manual.01.pdf; 125147.Instruction Manual.01.pdf

Source SHA-256: 1f3db6160aa8e295b34f3a20bf5e2b4d407f120032df77dfa4c73a2155b05cc2

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

10/20/23

Series

Source page 1 - Panel 1 (top left) (OCR)

i INTENDED USE: .

Model No. CZQTV007BK Series This product is intended for indoor residential and office use only, not WARNING: SHOCK HAZARD heat St

for industrial or other commercial application. Use only with electrical se ae peater only in bathroom. launde Is heater Is il

wiring that is in good working order and that meets applicable codes nen ed For use nk a Shine me fing ry area, oF sale ar

and ordinances. This heater must be plugged in to a 120V AC, 15 Amp whe lons, Of el was s, New a ate heat owherey poo all

om or one. (or larger) circuit. Do not plug anything additional into the same circuit. int er Soenub. wae ever ovate ales wi ere i may fa

on : . . : = If you have any questions whether your wiring is adequate, consulta | te ‘doe “a r other Mar er container. a vich oe tl od 4

America’s Heating and Cooling Choice > fe qualified electrician. Risk of fire, overheating, malfunction, property ba nent }0 not use In damp environments such as loode!

t : damage, injury or even death may result if not adhered to. asements.

= a Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

os a aie vicinity of your heaterffan. Do not touch body of heater when in use. This heater is hot

| ee. sessiaan ei . when in use, to avoid burns, do not let bare skin touch hot

f xen. seeeet Pe iy While using your heaterfan, you should follow the IMPORTANT - curfaces. If provided, use handles when moving this heater.

q *ecager 33 Pe a INSTRUCTIONS listed below. As part of those instructions, we have

. ee a esstasete used the word “WARNING” to indicate the level of hazard:

esse Beseaeeatan WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

Beseteecs sescteet ce injury or death. Heater has hot and arcing or sparking parts inside. Do not use

1 Besesess esctaeestas near combustible materials or flammable gases or sources of

reecseces! eeesteteatestas heat. DO NOT USE in areas where gasoline, paint or

rogsesoces saeoclegtoceases!

Weesescest saescteastent flammable materials are used or stored. Keep combustible

Meeeseecst setectestecte When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

‘eesessest seeestentartr followed to reduce the risk of fire, electric shock and injury to persons, -_and curtains at least 3 feet (0.9 m) from the front of the heater

Beeseocect sesaseetesserstee including the following and keep them away from the sides and rear. To prevent a

Yeeeese. sees sretegtestts. 4 Pp

Uu a r Z Wesesece: sesecitterse ¢ Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

iesees: i seseescistticss * This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

7s eect Seeeesereteeant skin touch hot surfaces. Use provided handle when moving this become blocked. Do not place the heater near a bed because

ower eater esseesst oi Seseeaie heater. Keep combustible materials, such as furniture, pillows, objects such as pillows or blankets can fall off the bed and be

Be 3 E Hi feat bedding, papers, clothes and curtains at least 3 feet (0.9 meters) ignited by the heater. Do not insert or allow foreign objects to

ieessa cts Hits from the front of the heater-fan and keep them away from the sides enter any ventilation or exhaust opening as this may cause an

<< ee 238: rate and rear. electric shock, fire, or damage the heater.

3 eet ‘Seeocuesene! * Do not use heater unattended. Use of extreme caution is necessary

deeesseest seetee when any heater is used by or near children, invalids, disabled .

seegeeeeere= persons or pets, WARNING:

Features . * Do not operate the heater with a damaged power cord or after the ELECTRICAL SHOCK HAZARD

. heater malfunctions, has been dropped or damaged in any manner. Do not use with damaged cord or plug. Use with adequate

. Return heater to authorized service facility for examination, electrical electrical system that is up to code.

«Adjustable Thermostat PS or mechanical adjustment or repair.

. . * Do not use heater outdoors. The supply cord has a polarized plug. As a safety feature this

*Two Settings: . Use your heater only in dry environments, This heater is not intended plug will fit in a polarized outlet only one way. To prevent

. for use in a bathroom, laundry area, or similar locations, or near electric shock, match wide blade of plug to wide slot, fully

High - 1500 watts (51 20 BTU) sinks, washing machines, swimming pools or other sources of water. insert plug. If the plug does not fit contact a qualified

Never locate heater where it may fall into a bathtub or other water electrician

Low - 750 watts container. Do not use in damp environments such as flooded

basements. 1 unlevel ' Do not operate any heater with a damaged cord or plug or

e * Do not place the heater on a small, unlevel, uneven or any surface after heater malfunctions, has been dropped or damaged in

Top Mounted Control Panel which might allow heater to tip or fall any manner. Do not operate heater with a broken heating

. H * For proper operation, heater should be placed on a smooth, element or ceramic cone or any visual imperfections. For

° Power Ind icator Lig ht non-combustible Surface Do ro place on rugs, carpet, vinyl flooring repairs covered under warranty, see warranty statement. For all

. or other plastic surfaces. Not for use outdoors or in wet areas. other repairs contact Comfort Zone® Customer Service by

“Safety Ove rheat P rotection * This heater is not designed as a primary heat source. telephone or mail for information and assistance.

‘ . * Always plug heaters directly into a wall outlet/receptacle. Never use

“Safety Tip-Over Protection with an extension cord or relocatable power tap (outlet/power strip) PET OWNERS NOTE:

C . t St C | Cc H dl Always unplug heater when not in use. The health of bird 4 . Il pet tl f

. * Do not run power cord under carpeting. Do not cover cord with le health of birds and some small pets are extremely

onvenien ay 00 arry anale throw rugs, runners or similar coverings. Arrange cord away from sence to ire fumes giver off during ine ina use of many

e 1 1 Tes] j traffic area where it will not be tripped over. appliances. Although these fumes are not harmful to humans, i

Qu iet H Ig h Efficiency Fan Assisted * To disconnect heater, turn controls off then remove plug from outlet. is recommenced that this healer not be use around bcs and

* Do not insert or allow foreign objects to enter any ventilation or small pets during its initial use until the manufacturing

“1 20V A.C., 60Hz, 1 2.5A exhaust opening as this may cause an electric shock or fire or Corrosion coatings burn off.

damage the heater.

a * To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

us become blocked

LISTED! ¢ A heater has hot and arcing or sparking parts inside. Do not use it in

areas where gasoline, paint or flammable liquids are used or stored.

Intertek * Use this heater only as described in this manual. Any other use not

. recommended by the manufacturer may cause fire, electric shock or

Save These Instructions injury to persons or property.

| pg. 1 pg. 2

Source page 1 - Panel 2 (top right) (OCR)

a

Source page 1 - Panel 3 (bottom left) (OCR)

| USAGE: TURNING OFF: Turn the center dial to the OFF position LIMITED WARRANTY

HEATER OPERATION: Always operate the heater in before unplugging or plugging in the heater. Heater This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a

the upright position following all instructions and should be unplugged when not in use. period of one year from the date of original purchase. If this unit fails because of a manufacturing

recommendations listed in this manual. a defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but

HEATER LOCATION: Place the heater in the area of © QUARTZ TUBES: Do not use with either quartz tube within the warranty period, if the unit was purchased within the continental United States, return it, to

tne foo thal is coldest, . . cracked or broken Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United

CONNECTION: Plug heater directly into 120V . .

AC., 60 Hz wall outlet. Be sure plug fits tightly in IMPORTANT SAFETY FEATURES States, return the unit to the place of purchase. This warranty does not cover damage caused by

outlet. A loose connection may cause overheating and The power indicator light, located near the control panel, misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not

damage to the plug or heater. NOTE: To prevent lights whenever the heater is plugged in. The heater is covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation.

overloading a circuit, do not plug the heater into. a - equipped with an automatic overheat protection device All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable,

circuit that is servicing other electrical needs. located inside the body of the heater. If the heater grill is are hereby limited in duration to the period of one year from the date of original retail purchase. Some

| . | obstructed, or if the heater gets too hot for any reason, states do not allow limitations on how long an implied warranty lasts, so the above limitations may not

Power Indicator: This heater is equipped with @ - the automatic overheat protection device will turn the apply to you. Incidental or consequential damages arising from a breach of either express or implied

Fower ight Indicator ye veal light wl Maminate heater off. To reset the heater, simply turn power off and warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation

nen ane nit is plugged in to alert you that the unit unplug the heater for 10 minutes until it cools down and of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the

power. you may plug in and restart the heater. Be sure that the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

TURNING HEATER ON: To start the heater, turn the heater is on a smooth level surface with no obstructions.

Power Control Dial from the OFF position to the Low _|f the heater is tipped over, the automatic tip-over switch This warranty gives you specific legal rights, and you may also have other rights which vary from state

or HIGH setting. Then rotate the Thermostat Control _Will turn off the heating elements until the heater is to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu

clockwise to the HIGH THERMOSTAT position as UP Fight. of all other warranties.

described below. (During the heaters initial use, you

may experience a slight odor or smoking. This is the | CARE AND MAINTENANCE

result ot the heating. element tabrication protective CLEANING: CAUTION-Before cleaning the heater be sure baiianered

coating “burning off’. This is normal and will go away to disconnect power cord and allow the heater to cool Bristol. PA 19007

after a few minutes of use.) completely. Clean the outside surface with a clean damp ristol,

cloth. 1-877-420-7555

CONTROL PANEL: www.mrbrands.com

Do not use harsh chemical or abrasive cleaners. DO www.comfortzoneproducts.com

power NOT IMMERSE THE HEATER IN WATER. Allow heater to

Light dry completely before use. A

WARNING:

REPAIR: DO NOT OPERATE THE HEATER WITHOUT Cancer and Reproductive Harm -

THE GRILLE IN PLACE. DO NOT USE THE HEATER IF www-P6sWarnings.ca.gov

Power IT HAS MALFUNCTIONED OR BECOME DAMAGED IN

Thermostat Control ANY WAY. Rev. 10/20/23

/ontrol ial

STORAGE: Keep original carton for storage of the

POWER CONTROL DIAL: This heater has two heat rein stoaoe tie the power cord to avoid damage

settings: High and Low. Use the higher setting

(1500W) to raise the room temperature quickly. When

the desired temperature is reached use the Low

setting. It is usually sufficient to maintain a

comfortable temperature.

SETTING THERMOSTAT: After heater has been turned on and the room has reached the desired temperature, slowly rotate the Thermostat Control dial counter-clockwise until the heater shuts off (you should hear a faint “click”). By leaving the thermostat at this setting it will automatically maintain this temperature. To lower temperature, rotate the knob further counter-clockwise (towards the LOW position) To raise the temperature, rotate the thermostat knob clockwise (towards the HIGH position).

pg. 3 pg. 4

| | i

Source page 1 - Panel 4 (bottom right) (OCR)

al