Comfort Zone 18-inch Pedestal Fan with Remote

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZST181RWT

Original source file(s): CZST181RWT, CZST181RBK.Instruction Manual.01.pdf

Source SHA-256: 4a65a103854971a7890762491b701d932c0db55e1885b7b3cb208ef6a658226b

Original PDF pages: 4 | Recovered reading units: 5

Source page 1 (embedded text)

www.comfortzoneproducts.com

Features:

• Wide Area Oscillation

• ON/OFF Switch with 3 Speed Settings

• User Selectable Countdown Timer

• High Performance Blades

• Adjustable Height and Vertical Tilt

• Large Heavy Stable Base

• Safety Grilles

• 120V A.C. / 60Hz

CZST181R Series

18" Pedestal Fan

with Remote Control

Save These Instructions

Source page 2 (embedded text)

22

www.comfortzoneproducts.com

INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial applications. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. If you have any questions whether your wiring is adequate, consult a qualified electrician. While using your fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word "WARNING" to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in injury or death.

IMPORTANT INSTRUCTIONS

As with all electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, fire, or

injury to persons, including the following precautions:

• Read all the instructions before using this fan.

• Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause electrical shock, fire or injury to persons.

• Do not operate the fan with a damaged power cord or after the fan malfunctions or has been dropped in any manner.

• Use of extreme caution is necessary when any fan is used by or near children, disabled persons or pets and whenever the fan is left operating unattended.

• Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.

• For proper operation, fan should be placed on a smooth, non-combustible, level surface.

• Always unplug fan when not in use, when moving from place to place, when assembling or disassembling parts, and before **cleaning.**

• The use of attachments, not recommended or sold by the manufacturer, may cause hazards.

• Do not use outdoors.

• Do not use fan in window. Rain may cause electrical hazard (for non-window models).

• Do not operate the fan with blade guards or any safety device removed.

• Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts.

• Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.

• Do not insert or allow any object to enter any openings on the fan. Doing so may cause electric shock and/or fire hazard. Avoid contact with moving parts.

• This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

• Children should be supervised to ensure they do not play with the appliance.

READ & SAVE THESE INSTRUCTIONS !

WARNING: SHOCK HAZARD

Use your fan only in dry environments. This fan is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. Do not use in damp environments such as flooded basements.

WARNING: HOT SURFACES

Do not touch fan motor when in use. This motor is hot when in use, to avoid burns, do not let bare skin touch hot surfaces.

WARNING: FIRE HAZARD

Fans have arcing or sparking parts inside. Do not use near combustible materials or flammable gases or sources of heat. Do not use in areas where gasoline, paint or flammable materials are used or stored. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the fan.

WARNING: ELECTRICAL SHOCK HAZARD

Do not use with damaged cord or plug. Use with adequate electrical system that is up to code.

CAUTION: TO PREVENT ELECTRIC SHOCK,

this product has a polarized two prong plug (one blade is wider than the other) that must be fully inserted in to a matching properly grounded outlet. This plug is designed to fit a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

CAUTION: TO REDUCE THE RISK OF FIRE OR

ELECTRIC SHOCK, do not use this product with any solid-state speed control device.

DO NOT operate any fan with a damaged cord or plug or after fan malfunctions, has been dropped or damaged in any manner. Do not operate fan with a broken blade, safety cage or any visual imperfections. Disconnect power before servicing. For repairs covered under warranty, see warranty statement. For all other repairs contact Comfort Zone® Customer Service by telephone or mail for information and assistance.

DO NOT run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over. Avoid the use of

extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts. Do not use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not in use. Do not operate fan with its ventilation obstructed.

Source page 3 (embedded text)

33

www.comfortzoneproducts.com

Turning Fan On/Off: Place fan on stable level surface. Plug fan into proper grounded outlet. To start the fan, press POWER button (

) repeatedly to desired fan speed: High, Med, Low

(

) Press POWER again and cycle through fan speeds to «OFF» position to discontinue use. Unplug fan when not in use.

Oscillation: To start fan oscillation, press Oscillation Control Knob (located above motor housing) down. To stop oscillation function pull Oscillation Control Knob up while the fan is in any oscillation position.

Remote Control: Place 2 «AAA» size batteries (not included) in the remote control. Use the buttons on the remote as you would with the control panel. Point the remote control towards the control panel for the sensor to receive a signal.

Timer Feature: The timer function is designed to work using oscillation or any fan speed. With a fan speed chosen press the TIME button on the control panel or remote control. Each time the TIME button is pressed additional time duration lights illuminate. Simply add the value of the lights and it is your set time. To turn the timer function off, press the TIME button continuously until all the lights are off.

Fan Assembly:

Simple assembly is required to use this fan.

USAGE

Fan Operation: Always operate the fan in the upright position following all instructions and recommendations listed in this manual.

Fan Location: Place the fan in the area of the room that will provide proper fan cooling.

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a circuit

that is servicing other electrical needs.
Remote
Control
Receiver
Power
Level
Indicator
On/Off
Speed
Control
Time
Value
Indicator
Oscillation
Control
Step 4
Step 6
Remove the Blade Cap by twisting it
CLOCKWISE while holding the metal
shaft tightly.
Note: Threads are reversed.
Unscrew = Clockwise.
With locknut
removed,
assemble
Rear Grille
onto Motor
Housing. Rear
Grille should
fit into pins
on fan motor
housing as
shown.
Step 9
Step 11
Step 10
Place Pedestal Pole into Socket of
the fan base as shown.
With Base upside down, thread
Base screw through Base into
Pedestal Pole. Tighten securely.
Attach Front Grille to Rear

Grille with Hook Clip centered on the bottom of the grille and logo upright.

Press remaining Grille Clips onto Rear Grille to securely attach Front Grille. Do not operate fan without Grille in place.

Thread Blade Cap onto threaded end of Motor Shaft.

Note: Threads are reversed.

Tighten = Counterclockwise.

Step 1

Step 2

Step 3

With thumbscrew loosened, pull Chrome Extension Pole out of Fan Pedestal.

Pull Chrome Extension Out

Set Screw Knob

Insert Chrome Extension Pole into the Fan Motor Housing and tighten Set Screw Knob.

Step 5

L

o

o

s

e

n

Step 7

Locknut

Thread Locknut onto Motor

Housing to lock Rear Grille

in place.

Step 8

Remove any protective covering over

shaft before Fan Blade installation.

Place Fan Blade onto Motor Shaft.

Notice the pin on Motor Shaft should

fit into slots of Fan Blade.

Slot

Pin

T

i

g

h

t

e

n

Hook Clip

CONTROL PANEL

Wire Handle

on Top

Pin

NOTE: The pedestal extension pole

may be recessed inside the larger

pole of pedestal body.

Note: Wire Handle

should be on top.

Source page 4 (embedded text)

44

www.comfortzoneproducts.com

LIMITED WARRANTY

Fig 1

Slide Cover to Open

Fig 2

Fig 3

CARE AND MAINTENANCE:

Cleaning: CAUTION-Before cleaning the fan be sure to unplug the power cord from the outlet. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Allow fan to dry completely before use. Periodic grille **cleaning with a vacuum will prevent dust build up. The motor is** sealed and does not require any interior maintenance, cleaning or lubrication.

Maintenance: The Internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

Note: Some models come with a plug where you can replace a fuse. If your model has this, please read and follow the below instructions to replace the fuse.

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades. See Fig. 2
3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.
4. Replace fuse.

WARNING: Risk of fire. Replace fuse only with identical 2.5 or 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure fuse is properly seated within its cavity.

5. Close fuse cover by sliding it back to its original closed position.