Comfort Zone 10,000W Digital Ceiling Mounted Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ260ER

Original source file(s): 520012.Instruction Manual.01.pdf; CZ260ER, CZ260ERBK.Instruction Manual.01.pdf; 120026.Instruction Manual.01.pdf

Source SHA-256: b97f3b3537ab2de028e0d63159d0702bdf55a73ffcefbe0bb3f71c97e4edd19b

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Binding edge - dimensions:420X290

290mm

210mm

Mr.Brands LLC

113 Fillmore St

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

07/20/2023

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from

the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit,

with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental

United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental

United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse,

overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability

and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail

purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to

you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed

and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or

exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are

expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr.Brands LLC 113 Fillmore St Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Source page 1 - Panel 1 (top left) (OCR)

O www.comfortzoneproducts.com f) (omfort Z O n e 6

-------- [TS

ERROR CODE TROUBLESHOOTING GUIDE €) TENDUSTRIAL | CZ260ER Series

G_ Gz

Error Code | Possible Cause Recommended Solution Clearing Error Codes

F1 (Fan Insufficient Clearance Around Ensure Heater is Installed with Sufficient Clearance All-Around, See Figure 1. To Clear E1 Code: |

Blade Not Heater *6 feet minimum mounting from floor

Spinning) *8 inches minimum from rear of heater 1. Power Off Heater

Overheat “13 inches minimum from side of heater 2. Switch Off Breaker (or

Safety Remove Fuse)

Cut-Out Obstructed Vent Remove any objects on heater or adjacent to heater vents. Do not block intake N

(Resettable) or exhaust by columns, machinery, etc. Ensure 24 inches minimum distance 3. Allow Heater to Cool

from heater exhaust (front) to any object (~15 minutes)

4. Switch on Breaker and

Fan Not Operational Disconnect power! wait 1 minute

(Fan Blade Not Spinning) Inspect Fan Blade (Rear of Heater) for foreign or dislodged object(s) preventing . .

rotation. Remove Rear Grille and clear interference, re-attach Rear Grille. 5. Power On Unit and follow == =

Instruction Manual for a

Disconnect power! Normal Operation

Open Hinged Bottom Cover by removing screws. Inspect Circuit Card .

Assembly (adjacent to Supply Connection Terminal Block) for loose or If E1 code persists please =

detached "plug-in" electrical connector. Re-attach securely, close Bottom contact manufacturer to

Cover and re-install screws. arrange product return.

Inadequate Copper Wire Gauge | Consult a licensed electrician. s

for Supply Connections Ensure Adequate Wire Gauge for Supply Connections -

(Fan Operates at Reduced Speed Ps

= Due to Insufficient Power Input)

Excessive Distance from Power Oot

Source

(Fan Operates at Reduced Speed

([D) Due to Current Loss)

oO) Inadequate Current (Amp) Rating | Consult a licensed electrician. . .

on Breaker Ensure adequately sized Current Breaker or Fuse per National & Local] | a

N Electrical Codes.

Improper Heater Shut Down Do not power off heater using circuit breaker. age

Fan motor is designed to operate for a short period of time after heating

element shuts off to prevent an overheat condition.

E2 Room Detached or Loose Connection at | Disconnect power! To Clear E2 & E3 Codes: SSS

Temp Sensor Room Temperature Sensor * Detach Fan Grille by removing screws. Locate Temp Sensor 4. Power Off Heater

Open Circuit Thermocouple on Housing (below Fan Motor Bracket). Ensure wire pair & .

thermocouple "tip" are free of damage. Re-attach Grille by re-installing screws. | 2, Switch Off Breaker HAR DWI R E D I NSTALLATI O N R EQ U l R E D

* Open Bottom Cover by removing screws. Inspect Circuit Card Assembly ‘or Remove Fuse) 1 1

(adjacent to Supply Connection Terminal Block) for loose or detached "plug-in" 3 s itch on Break) 7 Th IS heater m ust be g rou nded and hardwi red to a properly

electrical connector. Re-attach connectors securely. Close Bottom Cover and » Switch on Breaker an H H . . . H

reinstall screws, wait 1 minute sized current protection circuit breaker in accordance with

E3 Room Moisture Entrapment in Heater | Not intended for outdoor use. Not intended for use in bathrooms, shower 4. rower On alt and follow the (US) National Electric Code and local codes.

Temp Sensor rooms, laundry facilities or other similar indoor locations. Normal Operation

Short Circuit Disconnect power! Desc ri pti Oo n

Open Bottom Cover by removing screws. Allow unit to fully dry. Re-attach .

securely, close Bottom Cover and re-install screw(s). Wloose contact manufacturer to

e

Electical Shor-to Ground at | Disconnect power! arrange product return. Adjustable Heat Settings with Digital Thermostat

Room Temperature Sensor * Detach Fan Grille by removing screws. . . . .

Locate Temp Sensor Thermocouple on Housing (below Fan Motor Bracket). Ad Fan On ly Setti n g for Year- Rou n d Ai r C Ircu lati on

Ensure wire insulation is not damaged and internal conductor is not exposed. .

Re-attach Gre by re-instaling screws. e Fully Enclosed Motor for Extended Use in

No Power or | Supply Connections Improperly | Consulta licensed electrician. Re-Start Unit. D U sty E n vi ronme nts

Low Power Wired Ensure Supply Connections L1, L2, L3 & Ground are secure. Torque per NEC. . . . . .

to Heater (L3 provided on certain modes). Follow Instruction Manual for ¢ Horizontal and Vertical Air Flow with Tilt feature

Normal Operation.

Insufficient Service Loop on Consult a licensed electrician.

Supply Connections Ensure sufficient service loop in supply wires to maintain secure electrical ° Stu rdy H eavy Gau ge Steel Body

connections to swivel heater on bracket (particularly when using rigid or * j=)

seg cond. e Remote Control e

Electrical Short-to Ground Consult a licensed electrician. e High Limit Thermal Cut-Out Switch ZB

Ensure Supply Connections (L1, L2 & L3) are not contacting Housing (Ground) N

(L3 only provided on certain models). vt

Source page 1 - Panel 2 (top right) (OCR)

O www.comfortzoneproducts.com ° ©) www.comfortzoneproducts.com :

el rrr

13 CARE AND MAINTENANCE: SPECIFICATIONS:

Lem} HOT

ay - CLEANING THE HEATER:

_- =, 1. Do not disassemble the heater to clean it. CZ260ER SERIES DIGITAL HEAVY DUTY 10,000W ELECTRIC UTILITY HEATER

Bo 7>S rn

aEYy, = 2. The heater should be powered OFF and disconnected from WATTS SWITCH POSITION VOLTS (VAC) PHASE | amps | BTU/HOUR

ALR ey the power at the circuit breaker before attempting to clean

ae Z any portion of the heater. 10,000W HIGH (Defautt) 208-240V, 60Hz 34,120

GROUND .

= brush, vacuum and mild compressed puma favo Tw

= brush, vacuum and mild compressed air. N/A FAN ONLY N/A N/A N/A NA

WARNING: It is advised that at the start of each heater season, This Industrial Heater contains no user serviceable parts. RECOMMENDED CIRCUIT BREAKER 60 AMP or larger, in accordance with NEC and local codes.

the power should be turned off at the circuit breaker and the In the unlikely event that your heater should need service, please RECOMMENDED WIRE SIZE 6 AWG, COPPER ONLY | or larger, hardwired in accordance with NEC and

LI & L3 lug screws checked for tightness and proper torque. contact: Mr.Brands LLC 113 Fillmore St Bristol, PA 19007 RATED AT 167°F/75°C local codes.

The heater should be cleaned and checked for mechanical and 1-877-420-7555 - -

electrical integrity. See SPECIFICATIONS and NEC/local codes. www.mrbrands.com RECOMMENDED LUG TORQUES 45 IN-LBS or greater, in accordance with NEC and local codes

ADJUSTING AIR FLOW: www.comfortzoneproducts.com PRODUCT WEIGHT (APPROXIMATE) BETWEEN 45 TO 55 LBS ee

1. Tilt the unit- Loosen the top Small Knob-Screws and thread

into provided holes in heater until tight. See Figure 5.

2. Adjust the louvers in front of the heater as desired. See FOR CZ260ER SERIES

Figure 5. Note: Diagram is not drawn to scale, for information purposes only.

NOTE: DO NO OPERATE THE HEATER WITH THE FRONT Figure 1 CEILING SURFACE . CEILING SURFACE

LOUVERS CLOSED, DAMAGE TO THE HEATER COULD ‘olpin ; .|

RESULT. | - 17-2 in. A |

- 71m.

q 0 of -

SAFETY INSTRUCTIONS: a : oe] | Reeser

To start the heater, turn on the circuit breaker. The Power l | a nT ©) om

Indicator light will light up to indicate there is power available. 3 °

Press the POWER button to turn the heater on. The heater will be [seoose CY | . tp |

in HIGH setting by default. The heater indicator will illuminate, and = ~ i - : e-

the LED display will show the default setting temperature 80°F. vein i‘ a Wisin | |

1. The heater is HOT when in use. Do not let bare skin touch any “oval” ‘ewan Oitee

hot surfaces. 6ft.

2. Keep combustible materials (furniture, pillows, bedding, NOTE: Product dimensions are approximate and subject to change without notice. |

papers, clothes, curtains, and similar items) at least 3

feet (0.9m) from all sides and surfaces of the heater.

3. Do not use outdoors or in wet areas like bathrooms, laundry

areas or where it could fall into a swimming pool or other WARNING

container of water.

. Mw , . ' FOR INDOOR USE ONLY, IN A DRY LOCATION FREE OF GASOLINE, PAINT, FLAMMABLE LIQUIDS OR COMBUSTIBLE DUST OR

4. This heater is a 240V AC rated direct wired appliance. Never MATERIALS

use extension cords or relocatable power taps. .

DO NOT USE EXTENSION CORDS

MAXIMUM MOUNTING HEIGHT USING BRACKET FOR:

VERTICAL AIR FLOW: HORIZONTAL/ANGLED AIR FLOW:

The maximum recommended ceiling height The maximum recommended ceiling ae

for effective vertical air flow is 11 ft. i 7 height for effective vertical air flow is 8 ft. - ‘ihe

Ute

Source page 1 - Panel 3 (bottom left) (OCR)

Reading orientation normalized by 180 degrees.

©) Comfort Zone. O) Comfort Zone.

©) Comfort Zone Comiort Zone

SD ----------

TENDED USE designed th READ & SAVE LIMITED WARRANTY

lectric Utility heaters are designed to meet a variety of heating

requirements. This product is intended for indoor use only. Use only TH ESE | NSTRUCTI ONS This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from

with electrical wiring that is in good working order and that meets the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit,

applicable codes and ordinances. WARNING: SHOCK HAZARD with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental

If you have any questions whether your wiring is adequate, consult a Use your heater only in dry environments. This heater is not intended United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental

qualified electrician. Risk of fire, overheating, malfunction, property for use ina bathroom, laundry area, or similar locations, or near sinks, United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse,

damage, injury or even death may result if not adhered to. washing machines, swimming pools or other sources of water. Never overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC

; . . locate heater where it may fall into a bathtub or other water container. will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability

Use your heater-fan only with a working smoke detector located in the | Do not use heater outdoors. Do not use in damp environments such as and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail

Vicinity of your heater-fan. flooded basements. purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to

While using your heater-fan, you should follow the IMPORTANT you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed

INSTRUCTIONS listed below. As part of those instructions, we have WARNING: HOT SURFACES and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or

used the word "WARNING" to indicate the level of hazard: WARNING Do not touch body of heater when in use. This heater is hot when in use, exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are

indicates a hazard which, if not avoided, could result in injury or death. to avoid burns, do not let bare skin touch hot surfaces. If provided, use expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

handles when moving this heater. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

GENERAL SAFETY INFORMATION: WARNING: FIRE HAZARD

WARNING- Read and understand installation and operation Heater has hot and arcing or sparking parts inside. Do not use near This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal

instructions and observe all safety instructions combustible materials or flammable gases or sources of heat. DO NOT dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

SAVE THESE INSTRUCTIONS USE in areas where gasoline, paint or flammable materials are used or

1. For supply connections, use only copper wire, see stored. Keep combustible materials such as furniture, pillows, bedding, Manufactured for:

SPECIFICATIONS papers, clothes and curtains at least 3 feet (0.9 m) from the front of the Mr.Brands LLC

2. Heater air flow must be directed parallel to, or away from heater and keep them away from the sides and rear. Keep rear grille 113 Fillmore St

adjacent wall. away from walls or drapes so as to not block air intake. To prevent a Bristol, PA 19007

3. Observe wall, floor, and ceiling clearance requirements, see possible fire, do not block air intakes or exhaust in any manner. Do not 1-877-420-7555

Figure. 1. use on soft surfaces, like a bed, where openings may become blocked. www.mrbrands.com

4. All wiring must conform to national and local electrical codes in the Do not insert or allow foreign objects to enter any ventilation or exhaust www.comfortzoneproducts.com

United States and the heater must be grounded as a precaution opening as this may cause an electric shock, fire, or damage the heater.

against possible electrical shock. Heater circuit must be protected /\

with proper fuses or circuit breakers. WARNING: ELECTRICAL SHOCK HAZARD WARNING:

5. The mounting structure and the anchoring hardware must be Do not use with damaged wiring. Use with adequate electrical system Cancer and Reproductive Harm -

capable of reliably supporting the weight of the heater and, if used, that is up to code. wun P65Wamings.ca.gov

the mounting bracket. , ; ; Do not operate any heater with a damaged cord or plug or after heater Rev. 07/20/2023

6. All electrical power must be disconnected, and the main service box malfunctions, has been dropped or damaged in any manner. Do not

must be locked before inspection, cleaning or servicing the heater. operate heater with a broken heating element or ceramic cone or any

This sa precaution to prevent Serious shock. . . visual imperfections. For repairs covered under warranty, see warranty

7. This heater is not suitable for use in hazardous locations as defined statement. For all other repairs contact Comfort Zone® Customer

by the National Fire Protection Association (NFPA) in the United Service by telephone or mail for information and assistance.

States. This heater has hot and arcing (sparking) parts inside. Do

not use in areas where gasoline, paint, or flammable liquids are used PET OWNERS NOTE:

orstored, ; ; ; The health of birds and some small pets are extremely sensitive to the

8. This heater is not suitable for use in corrosive atmosphere such as fumes given off during the initial use of many appliances. Although these

marine, greenhouses or chemical storage areas. fumes are not harmful to humans, it is recommended that this heater

9. Do not install closer than 8 inches to a vertical surface. Do not not be used around birds and small pets during its initial use until the

install less than 6 feet from the floor. manufacturing corrosion coatings burn off.

10. Extreme caution is necessary when any heater is used by or near

children or invalids and whenever the heater is left operating and

unattended.

11. Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock, or

injury to persons.

WARNING- Improper installation or failure to follow the

procedures outlined in this instruction manual can result in

serious electrical shock.

DOT as |

3 _

0

a SUOH}ONYSU] BSEY | BABS woo'sjonpoidauozo}Woo'mmm en ¢ |

Source page 1 - Panel 4 (bottom right) (OCR)

Reading orientation normalized by 180 degrees.

©) www.comfortzoneproducts.com ° Oo www.comfortzoneproducts.com :

SD ee ee)

TIMER FUNCTION: CONNECTING THE POWER:

SERIES MODEL: CZ260ER The Timer function allows you to set the length of operation from 1. With the power off at the breaker, remove all screws from the

G 1 to 12 hours. Each time the TIMER button is pressed the length /..... bottom lid for access to the electrical section of the heater.

Oe OTR UTILITY HEAER of operation will increase 1 hour. The duration the timer is set for (-caneosr |) 2. Attach flexible cable through a knock-out in the side of the

will be displayed on the LED screen in hour increments. heater following NEC and local codes, (See Figure 6) and

TO TURN THE TIMER FUNCTION OFF: Press the TIMER WASHER -> = = SPECIFICATIONS for recommended wiring and circuit

Figure 2 Button continuously until the LED screen displays "O". breakers.

NOTE: The timer function is not an excuse to leave the heater NOTE: For certain applications, conduit may be required

Power Temperature Temperature unattended. af 2 (See Figure 6). Check local electrical codes. If you run the

- H IL 1 iring i i i

onto Controls +/ Display NOTE: Heater will cycle on and off to maintain room temperature. 6 BRACKET tops h conduit ae pe abet a rr neater be be

_ The first time you operate the unit, it may smoke slightly. This is : Lo to ed ase enougn Hexible conduit to allow tne neater to be

/\ due to residual cleaning agents used to clean the element when ured.

\ 1 \ v the heater is manufactured. This is normal and does not indicate o) 3/8 DIAMETER a

oc a problem with the unit. This condition will stop after the heater LAG BOLT CONDUIT

0.01. CONDUIT

Co) ® ®O@ has been in operation for a few minutes. If Heater is to \ ye aft.)

Control Panel Detail FAHRENHEIT OR CELSIUS DISPLAY: Figure 4: Multi-Screw Mounting, For Fixed Position be turned

(Enlarged for Clarity) To switch the display between Fahrenheit and Celsius, press : and wire Is

the °F/°C on either the unit or the remote. inside conduit. va

FLEXIBLE FLEXIBLE

CONDUIT CONDUIT

CONNECTOR

INSTALLING THE HEATER: -_-_

OPERATION Ne aseiaialaie sere LOCATING THE HEATER: HANGING THE HEATER IN THE BRACKET at 2

. is heater is designed to maintain a comfortable room ‘ ‘ : j i

i i Install the heater out of traffic areas, maintaining the clearances 1. Lift the heater into the mounting bracket and align the lower if Heater Is to ee

temp: e rature. Always operate the heater in the upright 7 Ei F bracket holes with the threaded holes nearest the heater’s be connected

position following all instructions and recommendations stated in Figure 1 above. The air flow from the heater must not center with NM Cable

listed in this manual. be restricted or obstructed by any items in the room. When . , .

more than one heater is used in an area, the heaters should be 2. Thread a large knob-screw through the hole on each side of FLEXIBLE FLEXIBLE NM CABLE

2. When the heater is turned on by pressing the POWER arranged so that the air discharge of each heater supports the the bracket. NM CABLE (use ONNECTOR

button, it will operate at 10,000W. The LED display panel air flow of the others to provide best circulation of warm air, as 3. Aim the heater horizontally or tilted by aligning the upper ----

will show the ambient temperature. The fan will start running indicated below in Figure 3. bracket holes with the top threaded holes on the heater 12

about 10 seconds after initial start to push the heat out. and secure with the small knob-screws and tighten all. == (Case

3. The temperature setting can be adjusted between 45°F (7°C) See Figure 5. Heater ee

to 95°F (35°C). To change the temperature, press the TEMP+ ii vith Flexible 3 4

or TEMP - buttons on either the unit or the remote. d a uit e

(See Figure 2) 5 ; ; onaurt. COCO

DS KS S055 Use top slots/hole in a

4. The temperature display will blink while it is being adjusted. fT i [} bracket and small eon

When the desired temperature is reached, it will take about es | knob-screws if heater (use per electircal codes)

5 seconds to accept the setting. Once the display stops LD _ is to be tilted down.

flashing, the room temperature will reappear on the LED Figure 6

screen to indicate the desired temperature is set. Figure 3 (}

5. In any temperature mode, the unit will stay in that mode, 3. Pull enough wire into the heater and connect to wire to

cycling on and off to maintain the set temperature. the Power Block located in the electrical area of the heater

See Figure 7).

6. The heater can be turned OFF by pressing the POWER BRACKET INSTALLATION FOR CZ260ER SERIES G) Adjust louvers up or ; 9) .

button. Once the unit is turned off, the fan will continue to Refer to Figure 4 down to control air flow 4. Be sure to torque all terminal screws and power block lugs

run to cool down the unit and there will be a 90 seconds 9 . 7] : tight, see SPECIFICATIONS and NEC/local codes, for

countdown on the digital display. 1. Locate a ceiling joist or other firm structural element or LSS required torque values, failure to do so can overheat the

support to mount the heater and point at desired direction Q power blocks.

of air flow. | 8 5. Turn on power at the main circuit breaker panel. Notice the

ill a v4” pi i iling joi YELLOW Power Indicator Light on the Control Panel will glow.

2. Drill a4” pilot hole in the ceiling joist for the Screws, Remove screws from the fe} g

3. Place the screws and washers as shown in the Figure 4. panel to access power

4. Tighten the screws to secure the heater. block, see Figure 7. Figure 5

QO as 5

ow -_-_- DPF

|