Comfort Zone Compact Heater

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ35E

Original source file(s): CZ35E.Instruction Manual.01.pdf; 120986.Instruction Manual.01.pdf; 120987.Instruction Manual.01.pdf

Source SHA-256: 8c928e7f7239003ec9fddefc63aab725a64e5e6caed936c009c0e87d6bb07d22

Original PDF pages: 1 | Recovered reading units: 4

Source page 1 - Panel 1 (top left) (OCR)

Reading orientation normalized by 180 degrees.

7 J SMOYS JOpsOg YIe|G |

| 6d

VG'clL “2ZHO9/'O'V AOC! e

SUOHONISU] SSEU| OAS g|pueH Aled JUSIUSAUOD e

JoH4OIUl Apog |0045 Abels e

sn (|) YOUMS 18AQ-di] Ajoyes «

- | UOID9}O1d4 JEAUJOAC Alayes e

}YHI7 JO}eOIPU] J}O/UO

[AUB |O1]UOD PS]UNO/]UOJ- e

Bullies AjuO ue e

SHEM 009 - MO7]

(SOLE OZES) sivem OOS} - YBIH

spoly| eves Afieuz

‘SHuINeS yeOH BOU] e

JeISOWJEU | ajqeisnipy e

:soinjyeo4

Ja]}e3}H JOeAWIOY

/aTM

e oS) Bulpudag juaye,

Wee= nem 008 L201 pareduos coeds

BESS= j.Aeye0y psepueys e ueY} ABJaU9 sso]

2ESSeS= ee pINOud Bunge ieety ong

222255 foot a ssa a

22S==F ABojouyos| aves AByeuy

i - ADOTONHOSL

- 30

BIVS

ADUYANA

aal0yy Buljooy pue buljeay s,eouewy

SOLAS ASEZO# [OPO QUOZ JAOJLUO") ©

- | (48A09) | a6eg |

Source page 1 - Panel 2 (top right) (OCR)

Page 2 (inside) |

INTENDED USE: - - . WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not Use your heater only in dry environments. This heater is not

for industrial or other commercial application. Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes locations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in toa 120V AC, 15 Amp. other sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a outdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements

damage, injury or even death may result if not adhered to. ,

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word “WARNING” to indicate the level of hazard:

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

heat. DO NOT USE in areas where gasoline, paint or

IMPORTANT INSTRUCTIONS flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

¢ Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

© This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not insert or allow foreign objects to enter

heater. Keep combustible materials, such as furniture, pillows, any ventilation or exhaust opening as this may cause an

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) electric shock, fire, or damage the heater.

from the front of the heater-fan and keep them away from the sides

and rear. .

¢ Do not use heater unattended. Use of extreme caution is necessary WARNING:

when any heater is used by or near children, invalids, disabled ELECTRICAL SHOCK HAZARD

persons or pets. Do not use with damaged cord or plug. Use with adequate

¢ Do not operate the heater with a damaged power cord or after the electrical system that is up to code.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical The supply cord has a polarized plug. As a safety feature this

or mechanical adjustment or repair. plug will fit in a polarized outlet only one way. To prevent

¢ Do not use heater outdoors. electric shock, match wide blade of plug to wide slot, fully

e Use your heater only in dry environments. This heater is not intended insert plug. If the plug does not fit contact a qualified

for use in a bathroom, laundry area, or similar locations, or near electrician.

sinks, washing machines, swimming pools or other sources of water.

Never locate heater where it may fall into a bathtub or other water Do not operate any heater with a damaged cord or plug or after

container. Do not use in damp environments such as flooded heater malfunctions, has been dropped or damaged in any

basements. manner. Do not operate heater with a broken heating element

¢ Do not place the heater on a small, unlevel, uneven or any surface or ceramic cone or any visual imperfections. For repairs

which might allow heater to tip or fall. covered under warranty, see warranty statement. For all other

e For proper operation, heater should be placed on a smooth, repairs contact Comfort Zone® Customer Service by telephone

non-combustible surface. Do not place on rugs, carpet, vinyl flooring or mail for information and assistance.

or other plastic surfaces. Not for use outdoors or in wet areas.

e This heater is not designed as a primary heat source. .

e Always plug heaters directly into a wall outlet/receptacle. Never use PET OWNERS NOTE: Il pet ‘ | it

with an extension cord or relocatable power tap (outlet/power strip). e Nealln OF Diras and some smal pets are extremely sensitive

Always unplug heater when not in use. to the fumes given off during the initial use of many appliances.

: F Although these fumes are not harmful to humans, it is

e Do not run power cord under carpeting. Do not cover cord with g . am

throw rugs, runners or similar coverings. Arrange cord away from recommended that this heater not be used around birds and

traffic area where it will not be tripped over. small pets during its initial use until the manufacturing corrosion

* To disconnect heater, turn controls off then remove plug from outlet. coatings burn off.

¢ Do not insert or allow foreign objects to enter any ventilation or

exhaust opening as this may cause an electric shock or fire or

damage the heater.

e To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

e A heater has hot and arcing or sparking parts inside. Do not use it in

areas where gasoline, paint or flammable liquids are used or stored.

e Use this heater only as described in this manual. Any other use not

recommended by the manufacturer may cause fire, electric shock or

injury to persons or property.

Pg. 2

Black border shows

Source page 1 - Panel 3 (bottom left) (OCR)

. . page size and should

| Page 3 (inside) not print \

USAGE: TURNING OFF: To discontinue use, turn the Power

HEATER OPERATION: Always operate the heater in Switch to the OFF position. Always turn the heater

the upright position following all instructions and OFF before unplugging or plugging in the heater.

recommendations listed in this manual HEATER Heater should be unplugged when not in use.

LOCATION: Place the heater in the area of the room that

is coldest. HEATER CONNECTION: Plug heater directly TO OPERATE FAN ONLY: Turn the On/Off Power

into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits Level Control dial to the Fan setting. Turn thermostat

tightly in outlet. A loose connection may cause fully clockwise so the fan will run continuously.

overheating and damage to the plug or heater. NOTE:

To prevent overloading a circuit, do not plug the IMPORTANT SAFETY FEATURES

heater into a circuit that is servicing other electrical The power indicator light, located above the control

needs. panel, lights whenever the heater/fan is plugged in to

TURNING HEATER ON: To start the heater, turn the tell you that the heater has power. The heater Is

: . ve , equipped with an automatic overheat protection

Power Control dial from OFF position to FAN, LOW, device located inside the body of the heater. If the

HIGH, or ENERGY SAVE setting. Then rotate the h ro .

; eater grille is obstructed, or if the heater gets too hot

Thermostat Control clockwise to the HIGH for any reason, the automatic overheat protection

THERMOSTAT position as described below. (During device will turn the heater off. To reset the heater,

the heaters initial use, you may experience a slight . ‘ ,
odor or smoking. This is the result of the heating simply turn Power off and unplug the heater for 10
element lubrication “burning off’. This is normal and minutes until it cools down and you may plug the
will go away after a few minutes of use.) heater in and restart the heater. Be sure that the
heater is on a smooth level surface with no
3 obstructions. The heater is also equipped with a
safety tip-over switch to turn power off to the heater
om" --- when the heater tips over. To resume heater functions
-- simply stand heater upright. With tip over protection,
- the heater will only operate when placed upright on a
sSSSE=
SSSSe= level surface.
ee
SS ==

SE227~ CARE AND MAINTENANCE

foe {3 CLEANING: CAUTION-Before cleaning the heater be
WY \ sure to disconnect power cord and allow the heater to
cool completely. Clean the outside surface with a
/ clean damp cloth. Do not use harsh chemical or
on/ott gn/Oft abrasive cleaners. DO NOT IMMERSE THE HEATER
Thermostat Indicator devel IN WATER. Allow heater to dry completely before use.

; REPAIR: DO NOT OPERATE THE HEATER WITHOUT

eetines CLEGY OAVE il Ona eae Select we THE GRILLE IN PLACE. DO NOT USE THE HEATER
heat setting that best meets your heating needs. The NAMAGED I ANY WAY ONE? OR BECOME
ENERGY SAVE heat setting provides comfortable :
crag ceste rooms, while saving you money on STORAGE: Keep original carton for storage of the
heater. Coil and tie the power cord to avoid damage
SETTING THERMOSTAT: After heater has been turned during storage.
on and the room has reached the desired temperature,
slowly rotate the Thermostat Control counter-clockwise
until the heater shuts off (you should hear a faint
“click”). By leaving the thermostat at this setting it will
automatically maintain this temperature. To lower
temperature, rotate the knob further counter-clockwise
(towards the LOW position). To raise the temperature,
rotate the Thermostat Control clockwise (towards the
HIGH position).
Pg. 3

Source page 1 - Panel 4 (bottom right) (OCR)

Page size and should
Page 4 (back) notin \

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC
113 Fillmore St
Bristol, PA 19007
1-877-420-7555 11.0"
www.mrbrands.com
www.comfortzoneproducts.com
L\ neon
Cancer and Reproductive Harm --
www.P65Warnings.ca.gov
Rev. 07/19/2023
Pg. 4
It eFSXSX_ |
| 850"