Comfort Zone Compact Heater Fan

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ40E

Original source file(s): CZ40E.Instruction Manual.01 (1).pdf; CZ40E.Instruction Manual.01.pdf; 120233.Instruction Manual.01.pdf; 120234.Instruction Manual.01.pdf

Source SHA-256: a129396cbc87bbd3e86ba391c61c1b7b49b51cdfcab48f8c5062b96de5420e6d

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Mr.Brands LLC

113 Fillmore St

Bristor,PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev.07/20/2023

Source page 1 - Panel 1 (left to right) (OCR)

Comfort Zone.

O America’s Heating and Cooling Choice CZ40 E Series

ENERGY ay

SAVE Sexe

TECHNOLOGY = Se *

ENERGY SAVE TECHNOLOGY SE n eZ = ‘

yourheating.costes NSZ a

provides comfotabi nesting SS SS

techest et SSZ27 Sa

“Seaman: ate watspace Se ee! i...

Patent Pending =,

KTM ee 8

we "]

Compact Heater/Fan

Features:

e Adjustable Thermostat

e Three Heat Settings:

Energy Save Mode

High - 1500W (6120 BTU)

Low - 600W

e Fan Only Setting

¢ Power Indicator Light

e Safety Overheat Protection

e Safety Tip-Over Switch

¢ Convenient Carry Handle

0120V A.C., 60Hz., 12.5A

www.comfortzoneproducts.com Save These Instructions

Source page 1 - Panel 2 (left to right) (OCR)

©) www.comfortzoneproducts.com -

-_-_-_

moving this heater. Keep combustible materials, such as and keep them away from the sides and rear.To prevent a

furniture, pillows, bedding, papers, clothes and curtains at reap y e

[east 3 feet (0.9 tneters) train the front of the heater-fan and possible fire, do not block air intakes or exhaust in any manner.

keep them away from the sides and rear. Do not use on soft surfaces, like a bed, where openings may

* Do not use heater unattended. Use of extreme caution is become blocked. Do not place the heater near a bed because

necessary when any heater is used by or near children, objects such as pillows or blankets can fall off the bed and be

invalids, disabled persons or pets. ignited by the heater. Do not insert or allow foreign objects to

. Do not. operate the heater with & ae cord eiged enter any ventilation or exhaust opening as this may cause an

in any manner. Return heater to authorized service facility for electric shock, fire, or damage the heater.

examination, electrical or mechanical adjustment or repair.

« Do not use heater outdoors , WARNING: ELECTRICAL SHOCK HAZARD

* Use your heater only in dry environments. This heater is Do not use with damaged cord or plug. Use with adequate

not intended for use in a bathroom, laundry area, or similar electrical system that is up to code.

locations, or near sinks, washing machines, swimming pools

or other sources of water. Never locate heater where it may The supply cord has a polarized plug, As a safety feature

ea other water container. Do not use in this plug will fit in a polarized outlet only one way. To prevent

+ Do not place the fan on a small, unlevel, uneven or any electric shock, match wide blade of plug to wide slot,

surface which might allow heater to tip or fall. fully insert plug. If the plug does not fit contact a qualified

* For proper operation, heater should be placed on a smooth, electrician.

non-combustible, level surface. Do not place on rugs, carpet,

vinyl flooring or other plastic surfaces. Not for use outdoors Do not operate any heater with a damaged cord or plug or after

or in wet areas. . ; heater malfunctions, has been dropped or damaged in any

* This heater is not designed as a primary heat source. manner. Do not operate heater with a broken heating element

* Always plug heaters directly into a wall outlet/receptacle. or ceramic cone or any visual imperfections. For repairs

Never use with an extension cord or relocatable power tap covered under warranty, see warranty statement. For all other

«* Do not run power cord under carpeting, Do not cover cord repairs contact Comfort Zone® Customer Service by telephone

with throw rugs, runners or similar coverings. Arrange cord or mail for information and assistance.

away from traffic area where it will not be tripped over.

* To disconnect heater, turn controls off then remove plug from PET OWNERS NOTE:

outlet. The health of birds and some small pets are extremely sensitive

* Do not insert or allow foreign objects to enter any ventilation to the fumes given off during the initial use of many appliances.

gr exhaust opening as {his may cause an electric shock or Although these fumes are not harmful to humans, it is

: recommended that this heater not be used around birds and

* To prevent a possible fire, do not block air intakes or exhaust il pets during tts initial til th fact .

in any manner. Do not use on soft surfaces like a bed, where small pets during Its initial use until the manufacturing corrosion

openings may become blocked. coatings burn off.

ow --_-_------

Source page 1 - Panel 3 (left to right) (OCR)

Comfort Zon

SS

USAGE: TO OPERATE FAN ONLY: Turn the On/Off Power Level Control

dial to the FAN setting. Turn thermostat fully clockwise so the fan

HEATER OPERATION: Always operate the heater in the upright | wit run continuously.

position following all instructions and recommendations listed in

this manual. TURNING OFF: To disconnect heater, turn controls to off, then

remove plug from outlet. Heater should be unplugged when not

HEATER LOCATION: Place the heater in the area of the room in use.

that is coldest.

HEATER CONNECTION: Plug heater directly into 120 volt IMPORTANT SAFETY FEATURES

A.C., 60Hz wall outlet, Be sure plug fits tightly in outlet. A loose The power indicator light, located near the control panel, lights

connection may cause overheating and damage to the plug or whenever the heater or fan is turned on. The heater is equipped

heater. NOTE: To prevent overloading a circuit, do not plug the with an automatic overheat protection device located inside

heater into a circuit that is servicing other electrical needs. the body of the heater, If the heater grille is obstructed, or if

the heater gets too hot for any reason, the automatic overheat

POWER INDICATOR LIGHT: This heater is equipped with a protection device will turn the heater off. To reset the heater,

Power Indicator Light. The power light will illuminate when the simply turn power off and unplug the heater for 10 minutes until

unit is turned on. it cools down and then you may plug the heater in and restart.

Be sure that the heater is on a smooth level surface with no

TURNING HEATER ON: To start the heater, turn the Power obstructions. The heater is also equipped with a safety tip-over

Control dial from OFF position to FAN, LOW, HIGH, or ENERGY switch to turn power off to the heater when the heater tips over.

SAVE setting. Then rotate the Thermostat Control clockwise to To resume heater functions simply stand heater upright.

the HIGH THERMOSTAT position as described below. During the

heaters initial use, you may experience a slight odor or smoking.

This is the result of the heating element lubrication “burning ott”. | CARE AND MAINTENANCE

This is normal and will go away after a few minutes of use. CLEANING:

CAUTION - Before cleaning the heater be sure to disconnect

ro) power cord and allow the heater to cool completely, Clean

- OFF the body of the heater/fan with a soft cloth. Do not use harsh

& - ran chemical or abrasive cleaners. DO NOT USE GASOLINE, BEN-

Ro - Low Hear ZENE, PAINT THINNER, HARSH CLEANERS, ETC. AS THEY

RO Hick Hear WILL DAMAGE THE HEATER/FAN. NEVER USE ALCOHOL OR

@ - enercy save SOLVENTS.

IMPORTANT! DO NOT IMMERSE HEATER/FAN IN WATER!

CONTROL PANEL Clean the Heater/fan grille with the vacuum brush attachment
wy ‘on your vacuum cleaner. This will remove lint and dirt from
“s Z| ros inside the heater/fan. DO NOT ATTEMPT TO TAKE APART THE
A> HEATER/FAN. DO NOT REMOVE THE HEATER/FAN GRILLE.
if . S REPAIR: DO NOT OPERATE THE HEATER WITHOUT THE
\ } GRILLE IN PLACE. DO NOT USE THE HEATER IF IT HAS.
t | | MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.
STORAGE: Keep original carton for storage of the heater. Coil
Thermostat Power owt, Fan and contro! and tie the power cord to avoid damage during storage.
POWER CONTROL DIAL: This heater has 3 heat settings:
ENERGY SAVE, HIGH and LOW. Select the heat setting that
best meets your needs. The ENERGY SAVE heat setting
provides comfortable heating in most rooms, while saving you
money on energy costs.
SETTING THERMOSTAT: After heater has been turned on and
the room has reached the desired temperature, slowly rotate
the thermostat knob counter-clockwise until the heater shuts
off (you should hear a faint "click"). By leaving the thermostat
at this setting it will automatically maintain this temperature. To
lower the temperature, rotate the knob further counter-clockwise
(towards the LOW position). To raise the temperature, rotate the
thermostat knob clockwise (towards the HIGH position).
-eke-_wewreere-eree---ere--------eo

Source page 1 - Panel 4 (left to right) (OCR)

O Comfort Zone.
www.comfortzoneproducts.com

-_-_-_----

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in

duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of

all other warranties.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr.Brands LLC

113 Fillmore St

Bristor,PA 19007

1-877-420-7555

www. mrbrands. com

www. comfortzoneproducts. com

LA cso

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Rev.07/20/2023

LY

(4]