Comfort Zone Compact Heater Fan

Comfort Zone - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): CZ45E

Original source file(s): CZ45E.Instruction Manual.01.pdf; 120107.Instruction Manual.01.pdf

Source SHA-256: 2aaec5ea6c1d8dcce2affce868d7be49607ae75594141cbf53c3ae7e667b3a17

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Mr.Brands LLC

113 Fillmore St

Bristor,PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

Rev.07/20/2023

Series

Source page 1 - Panel 1 (left to right) (OCR)

O Comfort Zone. Model #CZ45E Series

America’s Heating and Cooling Choice

ENERGY a=: =

SAV Fos

TECHNOLOGY x : yeaa 7

Energy Save Technology C®) s. Z ;

helps Save energy and reduces = = |

Gare sat Sang provides == -----oe

Sree pa a - Sew

Sees

Compact SF

Heater/Fan

Features:

+ Adjustable Thermostat

* Three Heat Settings:

Energy Save Mode

High - 1500 watts (5120 BTU)

Low - 600 watts

* Fan Only Setting

* Safety Tip-Over Switch

* Power Indicator Light

* Safety Overheat Protection él)

* Comfortable Carry Handle ONES

* Stay Cool Body Intertek

-120V A.C., 60Hz, 12.5A Save These Instructions

Pg.1

Source page 1 - Panel 2 (left to right) (OCR)

INTENDED USE: WARNING: SHOCK HAZARD

This product is intended for indoor residential and office use only, not Use your heater only in dry environments, This heater is not

for industrial or other commercial application, Use only with electrical intended for use in a bathroom, laundry area, or similar

wiring that is in good working order and that meets applicable codes -_igcations, or near sinks, washing machines, swimming pools or

and ordinances. This heater must be plugged in toa 120V AC, 15 Amp. ther sources of water. Never locate heater where it may fall

(or larger) circuit. Do not plug anything additional into the same circuit. into a bathtub or other water container. Do not use heater

If you have any questions whether your wiring is adequate, consult a cytdoors. Do not use in damp environments such as flooded

qualified electrician. Risk of fire, overheating, malfunction, property basements

damage, injury or even death may result if not adhered to.

Use your heater-fan only with a working smoke detector located in the WARNING: HOT SURFACES

vicinity of your heater/fan. Do not touch body of heater when in use. This heater is hot

when in use, to avoid burns, do not let bare skin touch hot

While using your heater/fan, you should follow the IMPORTANT surfaces. If provided, use handles when moving this heater.

INSTRUCTIONS listed below. As part of those instructions, we have

used the word "WARNING" to indicate the level of hazard

WARNING indicates a hazard which, if not avoided, could result in WARNING: FIRE HAZARD

injury or death. Heater has hot and arcing or sparking parts inside. Do not use

near combustible materials or flammable gases or sources of

heat. DO NOT USE in areas where gasoline, paint or

IMPORTANT INSTRUCTIONS flammable materials are used or stored. Keep combustible

When using electrical appliances, basic precautions should always be materials such as furniture, pillows, bedding, papers, clothes

followed to reduce the risk of fire, electric shock and injury to persons, and curtains at least 3 feet (0.9 m) from the front of the heater

including the following: and keep them away from the sides and rear. To prevent a

* Read all the instructions before using this heater/fan. possible fire, do not block air intakes or exhaust in any manner.

* This heater/fan is hot when in use. To avoid burns, do not let bare Do not use on soft surfaces, like a bed, where openings may

skin touch hot surfaces. Use provided handle when moving this become blocked. Do not insert or allow foreign objects to enter

heater. Keep combustible materials, such as furniture, pillows, any ventilation or exhaust opening as this may cause an

bedding, papers, clothes and curtains at least 3 feet (0.9 meters) electric shock, fire, or damage the heater.

from the front of the heater-fan and keep them away from the sides

and rear. .

* Do not use heater unattended. Use of extreme caution is necessary WARNING:

when any heater is used by or near children, invalids, disabled ELECTRICAL SHOCK HAZARD

persons or pets. Do not use with damaged cord or plug. Use with adequate

* Do not operate the heater with a damaged power cord or after the _ electrical system that is up to code.

heater malfunctions, has been dropped or damaged in any manner.

Return heater to authorized service facility for examination, electrical The supply cord has a polarized plug. As a safety feature this

or mechanical adjustment or repair. plug will fit in a polarized outlet only one way. To prevent

* Do not use heater outdoors electric shock, match wide blade of plug to wide slot, fully

* Use your heater only in dry environments. This heater is not intended insert plug. If the plug does not fit contact a qualified

for use in a bathroom, laundry area, or similar locations, or near _ electrician

sinks, washing machines, swimming pools or other sources of water.

Never locate heater where it may fall into a bathtub or other water -_Do not operate any heater with a damaged cord or plug or after

container. Do not use in damp environments such as flooded heater malfunctions, has been dropped or damaged in any

basements manner. Do not operate heater with a broken heating element

* Do not place the heater on a small, unlevel, uneven or any surface or ceramic cone or any visual imperfections. For repairs

which might allow heater to tip or fall covered under warranty, see warranty statement. For all other

* For proper operation, heater should be placed on a smooth, repairs contact Comfort Zone® Customer Service by telephone

non-combustible surface. Do not place on rugs, carpet, vinyl flooring _o mail for information and assistance

or other plastic surfaces. Not for use outdoors or in wet areas

* This heater is not designed as a primary heat source. :

* Always plug heaters directly into a wall outlet/receptacle. Never use PET OWNERS NOTE:

with an extension cord or relocatable power tap (outlet/power strip), _ ‘The health of birds and some small pets are extremely sensitive

Always unplug heater when not in use. to the fumes given off during the initial use of many appliances

* Do not run power cord under carpeting. Do not cover cord with Although these fumes are not harmful to humans, it is

throw rugs, runners or similar coverings. Arrange cord away from fecommended that this heater not be used around birds and

traffic area where it wil not be tripped over small pets during its initial use until the manufacturing corrosion

* To disconnect heater, turn controls off then remove plug from outlet. coatings burn off

* Do not insert or allow foreign objects to enter any ventilation or

exhaust opening as this may cause an electric shock or fire or

damage the heater.

* To prevent a possible fire, do not block air intakes or exhaust in any

manner. Do not use on soft surfaces like a bed, where openings may

become blocked.

* Aheater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint or flammable liquids are used or stored

* Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock or injury to persons or property.

Pg. 2

Source page 1 - Panel 3 (left to right) (OCR)

USAGE: TO OPERATE FAN ONLY: Turn the Power Control dial

HEATER OPERATION: Always operate the heater in to the Fan setting. Turn thermostat fully clockwise so the upright position following all instructions and the fan will run continuously.
recommendations listed in this manual HEATER
LOCATION: Place the heater in the area of the room that TURNING OFF: To disconnect heater, turn controls to is coldest. HEATER CONNECTION: Plug heater directly off, then remove plug from outlet.
into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits
tightly in outlet. A loose connection may cause IMPORTANT SAFETY FEATURES
overheating and damage to the plug or heater. NOTE: The power indicator light, located near the control
To prevent overloading a circuit, do not plug the heater panel, lights whenever the heater or fan is turned on.
into a circuit that is servicing other electrical needs. The heater is equipped with an automatic overheat
Power Indicator Lights: This heater is equipped with protection device located inside the body of the
a Power Indicator Light. The power light will illuminate heater. If the heater grill is obstructed, or if the heater
when the unit is turned on gets too hot for any reason, the automatic overheat
protection device will turn the heater off. To reset the
TURNING HEATER ON: To start the heater, turn the heater, simply turn power off and unplug the heater
Power Control dial from OFF position to FAN, LOW, for 10 minutes until it cools down and you may plug in
HIGH, or ENERGY SAVE setting. Then rotate the and restart the heater. Be sure that the heater is on a
Thermostat Control clockwise to the HIGH smooth level surface with no obstructions. The heater
THERMOSTAT position as described below. (During the is also equipped with a safety tip-over switch to turn
heaters initial use, you may experience a slight odor or power off to the heater when the heater tips over. To
smoking. This is the result of the heating element resume heater functions simply stand heater upright.
lubrication “burning off’. This is normal and will go
away after a few minutes of use.) CARE AND MAINTENANCE

CLEANING: CAUTION-Before cleaning the heater be

sure to disconnect power cord and allow the heater to
cool completely. Clean the outside surface with a
» ox" w clean damp cloth. Do not use harsh chemical or
YS - ue " abrasive cleaners. DO NOT IMMERSE THE HEATER
Cy) @ oN wo ‘ IN WATER. Allow heater to dry completely before use.
J, 4

A Las -_ REPAIR: DO NOT OPERATE THE HEATER WITHOUT
- _ . THE GRILL IN PLACE. DO NOT USE THE HEATER IF
{ IT HAS MALFUNCTIONED OR BECOME DAMAGED
IN ANY WAY.

Thermostat - Power Gower

Control neice Dial STORAGE: Keep original carton for storage of the heater. Coil and tie the power cord to avoid damage during storage.

POWER CONTROL DIAL: This heater has 3 heat settings: ENERGY SAVE, HIGH, and LOW. Select the heat setting that best meets your heating needs. The ENERGY SAVE heat setting provides comfortable heating in most rooms, while saving you money on SAVE THESE INSTRUCTIONS energy costs.

SETTING THERMOSTAT: After heater has been turned on and the room has reached the desired temperature, slowly rotate the thermostat knob counter-clockwise until the heater shuts off (you should hear a faint "click"). By leaving the thermostat at this setting it will automatically maintain this temperature. To lower temperature, rotate the knob further counter-clockwise (towards the LOW position). To raise the temperature, rotate the thermostat knob clockwise (towards the HIGH position).

Pg. 3

Source page 1 - Panel 4 (left to right) (OCR)

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase,

return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased

within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are

expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr.Brands LLC

113 Fillmore St

Bristor,PA 19007

1-877-420-7555

www. mrbrands. com

www. comfortzoneproducts. com

LA wnsoinc

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Rev.07/20/2023

Pg. 4