

Rico Net - Pandur OLT Field Installation Guide

1. Pre-deployment Node Details

Target Device:	Raspberry Pi 2 (Collector)
Tailscale IP:	100.93.120.87 (Auto-Reconnecting)
Backend Server IP:	100.96.243.32 (Pings configured in Watchdog)
WiFi Hotspot SSID:	Bagrudeen Ali's iPhone (Saved Profile)
Hotspot Password:	amd12345

2. On-Site Steps at Pandur OLT

☐ Step 1: Phone Hotspot Activation

Open settings on your iPhone -> Personal Hotspot. Turn Maximize Compatibility ON. Leave this screen open and active on your phone screen while booting the Pi.

☐ Step 2: Power up the Pi

Plug the Pi's USB power adapter into a UPS backup power socket on-site (crucial so that it survives power cuts and registers power alarms).

☐ Step 3: Laptop connection

Connect your laptop to your iPhone's hotspot. Open your terminal or Command Prompt on the laptop and log in using SSH:

```
ssh rico@100.93.120.87 (Password: ricoamd)
```

☐ Step 4: Configure Pandur Site WiFi

Type: `sudo raspi-config`

Go to: System Options -> Wireless LAN.

Enter the actual Pandur OLT site WiFi SSID (name) and Password.

Turn off your iPhone's hotspot. The Pi will connect to the site WiFi automatically within 60s.

☐ Step 5: Physical OLT Connection

Connect the Ethernet patch cable from the Pi's Ethernet port directly to the EMS / Management Port of the Pandur OLT.

☐ Step 6: Verify Communication

Log back into the Pi (over site WiFi or Tailscale) and test connection to the OLT:

```
ping 192.168.8.100 (or the actual Pandur OLT IP).
```

Important Notes / Troubleshooting:

- *Disabling Key Expiry:* Remember to open tailscale.com, find 'riconet-olt-2' in Machines, and select 'Disable Key Expiry' so you never get logged out after 6 months.

- *Auto-Healing Watchdog:* The Pi has a watchdog script running every 5 minutes. If it loses internet or Tailscale connection, it will automatically restart the services and reboot itself if needed. Do not manually power cycle unless absolutely necessary.

- *Ethernet Static Config:* The Pi's Ethernet port (eth0) is pre-configured to communicate with the OLT subnet (192.168.8.x). Ensure the OLT management port is on this subnet.