

DRMLogPlotter - rebuild

Update History

Update 20.July 2026

Version 1.00 has been released.

New improvements have been implemented in the code!

- Main GUI -> Main Plot Window
The display and analysis of the green Doppler line should now closely match the original DRMLogPlotter.
- Main GUI -> DRM Mode Used
The DRM mode analysis has been further refined.
- Set Event -> Dream Start & Schedule Dialog
The "midnight logic" has been completely overhauled. Timer events should now start correctly even after midnight.
- Main GUI -> Frame Color
Color settings for the frame and scale display in the main plot window have been optimized for the "Gray" theme.
- Setup -> Basic Setup Parameters -> Dream and Receiver Configuration
The "Hamlib NET rigctl" transceiver/RX selection should now work successfully with rigctl servers.

Once you have selected "Hamlib NET rigctl" from the Hamlib list, DRMLogPlotter continuously communicates with a rigctl server.

Successful connections via selection from the Hamlib list using USB or network connectivity have been confirmed:

- Icom IC-7300
- Icom IC-705
- Yaesu FT-891 (RX modified for DRM)
- Kenwood TS-2000 (RX modified for DRM)
- AirSpy with plugin (simulates Kenwood TS-2000)
- SDRPlay RSPDuo with SDR++ Software (rigctl server)

Hope it works for you, too

Update from 16.07.2026

- There are significant improvements once again: The "DReaM and RX Configuration" menu has been substantially expanded. RX parameters for HamLib/rigCTL can now be specifically configured.
- The processing of the dreamloglong.csv file has been revised. The "empty plot" issue should now be resolved.

Update from 07. July 2026

This update brings improvements, fixes, and new features!

The most significant new feature is as follows: When you launch the DReaM decoder software via `drmlogplotter_v.0.99c`, a new function comes into play. This function reads the DReaM label from the PC screen 30 seconds after startup and adds the missing audio code information to the DReaM log. In the process, a new file—`DreamAudio.json`—is written to the DReaM folder. `drmlogplotter_v.0.99c` then reads this new file and displays the information within the "Main Log" section of the main GUI.

- RX/TX Distance and AZ Calculation - Should now display the same result as the original drmlotplotter.
- Main GUI -> LED 3 - An additional LED has been added to the main GUI to provide a visual indicator for DReaM logs.
- Main GUI -> DReaM Stop Button - A new button has been added to the "Update Files" section, allowing the user to stop DReaM Remote quickly, easily, and correctly via drmlotplotter. This function ensures that various settings in Dream.ini are correctly reset.
- Main GUI -> Main Log Section - Result displays for Audio Code / Prot. Level and Audio Mode have been added.
- Main GUI -> DRM Mode Used Section - DReaM log glitches should no longer generate phantom modes.
- Main GUI -> Select Main Log - The tabular display of logs in DReaM is now better organized.
- Main GUI -> AutoPlot - The minimum interval time is now 5 seconds.
- Main GUI -> AutoPlot - If you run AutoPlot (manually or via a timer event) and Dream Log stops correctly via drmlotplotter, then AutoPlot checks for 15 seconds longer to see if a Dream Log is still running. This was exactly how it worked in the original version.
- Main GUI -> Line Plot - The "Delay" line is now finer and less bright, resulting in a more balanced visual appearance.
- Main GUI -> Line Plot - The "Doppler" line is now slightly brighter.
- Main GUI -> Line Plot The priority for the plotting process is now: 1) SNR, 2) Audio, 3) Doppler, 4) Delay.
- "Basic Setup Parameters" Dialog -> The window layout has been improved, and "Set" buttons have been added to make it more intuitive for the user.
- "Dream and Receiver Configuration" Dialog -> Input handling for the paths required to access Dream remotely via drmlotplotter has been optimized. This input method works equally well on Windows 11, Ubuntu, and Linux Mint. Also new "Set" button has been implemented.
- Help Text File -> The help text has been expanded and the sections reorganized for better clarity.
- drmltransmittersites.txt -> You can use your existing transmitter sites file from the original drmlotplotter with the new dlp-experimental version as well.
- Python -> A new third file has been created to support the program's workflow in Python. Therefore, all three files must be placed in the same directory.
- Linux binaries (startup issues) -> The compilation process has been optimized; consequently, DreamLogPlotter.bin and DreamAudio.bin should now be able to run from the same directory on Linux.
- Windows 11 -> There are now two .exe files that must be placed together in the same directory.
- Python/Linux/Windows 11 -> Additionally, place the files drmltransmittersites.txt and drmlotplotter_help.txt in this same directory.
- Applmage -> The Applmage contains all components. You can find the "Screenshot" and "Logs" folders, as well as drmlotplotter_cfg.json, at
 #####/home/pc/.local/share/drmlotplotter. In your file manager, go to View -> "Show Hidden Files" click yes to locate the .local folder within your "pc" directory.