DRMLogPlotter – rebuild

Update History

Version 1.28.2 released (September 2026)

- Click in Radio List does not transfer the RX-Frequency to FLRig -> Solved.
- Information: The AppImage files for Linux and Raspberry Pi will be removed at the end of December.

Version 1.28.1 released (27.August 2026)

- Station list: When opening the station list via the main interface (GUI),
  the list no longer jumps to the first row but to the last selected row (except after a complete program restart). This does not apply to the station list under "Set-Event".
- Clicking "Average" in the main interface generates a line in the chart.
  The positioning of the text or value at the end of the line has been optimized.
- Clock in the main interface: Settings can now be toggled.
  Clicking UTC switches to Local time.
  Clicking Time changes the color.
- Main interface -> Station list
  After restarting DRMLogPlotter and starting logging via the station list,
  the .csv file size was not displayed correctly. Fixed.

Version 1.28 released (21.August 2026)

- Dialog Radio List: Once Dream has been started, you can now select a desired station from the list with a mouse click,
  and Hamlib-rigctl will tune to it. Channel hopping is now possible.
  Naturally, this is not possible when using "Start Dream with Log".
- Timer Events Dialog: A bug has been fixed. Entries in the list should no longer conflict with other functions.
- Fixed a significant logic error affecting timer events:
  Timer events should now always start correctly.
- RX Frequency Status LED:
  A discrepancy between Hamlib/rigctl and analog operation without Hamlib has been resolved.
  The RX frequency LED no longer lights up red when Hamlib/rigctl is disabled.

  If Hamlib is enabled and setting the frequency fails, this LED continues to signal a problem by glowing red.
- Fixed an issue when starting "Dream with Log" from the Radio List dialog:
  The Autoplot LED now shows yellow ("Wait") after a manual start and subsequently switches correctly to green.
- Corrected minor program logic steps and informational text.
- Fixed minor but very annoying compilation errors for Linux and Raspberry Pi.

Version 1.27 - 19. August 2026

Update: RX-TX distance calculation corrected -

- Previously, the calculation was only valid for the Earth's Northern Hemisphere.

Version 1.26 - August 18, 2026

(Raspberry Pi - Version is still 1.22 at the moment)

- A UTC clock has been added to the main GUI.
- In the "Radio List" dialog (which includes a Dream startup option), the directory path for the .ini file is hidden after 6 seconds.

Version 1.25 - 16. August 2026

- The update improves operation with DReaM software!

Update: 16. August 2026

- Starting Dream with DRMLogPlotter

If a timer event is scheduled and the user manually starts Dream beforehand, a collision protection mechanism now intervenes:

1. The user is notified via a popup message.
2. One minute before the scheduled start time, the active manual session of Dream is terminated.
3. The timer event then starts correctly.
4. If the user deliberately starts Dream less than 60 seconds before the scheduled start time, the manual session is stopped one second prior to the timer event. Two seconds later, the timer event starts correctly.
5. Two new colors have been added to the radio list: Red = less than 15 minutes until the program starts. Blue = the frequency currently selected.
6. A time display in UTC format has been added.
7. Minor visual changes to the "Radio List" dialog. The display showing the directory path for radio_list.ini is no longer permanently visible.
8. The position and size of the "Dream-Start and Schedule" dialog window can now be freely adjusted. Upon restarting DRMLogPlotter, the window opens with the settings last selected by the user.

Update: 14. August 2026 Version 1.24 released

Update Information Version 1.24:

- All major dialog windows now save their size and last position on the PC screen. This ensures the overall layout is immediately organized upon restarting.
- Timer event now supports 4 events.
- Timer event logic revised; should now run stably.
- Station list: Added a warning for events spanning the 00:00–24:00 time range; the end time must be set to 23:59.
- Station list: Double-clicking an entry copies it to the timer event.
- Auto-Plot: Now saves the last used interval. (Does not apply to timer events or log starts via the "Station List" button on the main interface).
- RX + Ant Info: Corrected input and processing logic for "RX+Ant Info"; buttons repositioned.
- All LED functions verified.

- Bug fix: The "Stop Dream" button displayed red text (indicating active Dream operation) even after Dream had been closed.
- Dream: No more conflicts when restarting while Dream is already running; a notification ("Stop Dream first") now appears.
- Corrected checkbox labels in all dialog windows.
- Fixed the checkbox for the edit function in the station list.
- Screenshot files are now saved in the same format as the original LogPlotter (13750-260730-1702-1756_Nickname.png).
- Corrected time and coordinate input functions for "TX-Site" and "Station List" (in the main interface and the DRM timer event dialog). Clicking the button again no longer opens an unnecessary additional dialog window; ...instead, the dialog window closes upon the second click (toggle function).
- Plot window and main interface frame: The color of the gray frame in the main plot window has been optimized.
- Main interface plot window: The color of the audio line in the plot has been changed to a lighter shade. The line should now be clearly visible even in "Thin Mode."
- Editing the station list: The AutoTab function is now triggered during time entry as well.
- The "Compare-Log" function now uses the same colors as the original for the comparison (audio and SNR lines).
- The text display for the comparison ("Compare-Text") is now clearer and—as in the original version—is located at the bottom of the chart.
- Radio list and timer event: Clicking a row copies all necessary data into an available timer event row.
- Radio list and timer event: Collision check for start and stop times implemented. If the end time is 00, the new start time is automatically set to 01.
- Radio list and timer event: All timer event rows can be programmed independently. Clicking an event in the radio list automatically copies the data to an available row.
- Radio list dialog ("Main GUI"): Button layout rearranged.
- Radio list dialog ("Main GUI"): AutoPlot can now be started alongside a manual DReaM log start. Delay is approx. 30 seconds, as usual.

Update: 09. August 2026

The following improvements have been made:

1. The radio list display has been optimized; column widths can now be adjusted individually.
   The program saves these settings and restores them after a restart.
   The selection radio buttons have been optimized; the list selection no longer reverts to "Default" but retains the last setting.

2. The "DRM Radio List" button in the "Set-Event" dialog has been removed.
   The DRM radio list dialog window now features four buttons:
   Dream Start, Dream Stop, Start Dream with Log, and Close.

3. You can now start logging immediately without having to switch back to the "Set-Event" dialog to select a frequency.
   Rigctl control has been improved: clicking a frequency in the radio list immediately sets it as the "log frequency" for Dream.
   Once logging is underway, you can close the dialog.
   After about a minute, the log can be manually selected in the main interface (GUI), and AutoPlot can be started.
   To stop logging, simply click "Stop Dream" in the main interface. It couldn't be easier.

4. The visual appearance of the "TX-Site" and "Radio List" buttons in the main interface (on Windows 11) has been improved.

5. SNR analysis has been further optimized.
   The red curve in the main plot window now evaluates SNR only while DReaM registers a

sync pulse from the DRM radio signal. If decoding is interrupted—for example, due to signal fading—all curves drop to the zero line.

6. The key windows now save their positions. Upon restarting the program, the windows return to their last saved locations.
7. On Linux, the font has been changed from the Tkinter default to Arial. It now looks significantly better.
8. Many other minor internal changes and improvements have also been implemented.
9. The text and checkbox inputs have been optimized for "Zoom in" and "RX coordinates. " Unintentional, erroneous user input is now largely prevented.
10. The releases have been updated for Windows 11, Linux Mint/Ubuntu, and Raspberry Pi (ARM).

We are steadily approaching the final version...

Update: August 5, 2026

1. SDR-RX
   Frequency correction for rigctl and adjustment for the correct DRM logging frequency.
   If DRM reception must instead be performed using USB/LSB for instance, because the SDR software does not offer a DRM mode— a correction function is available.
   The offset (e.g., + or - 5 kHz) is detected, and the correct logging frequency for the DReaM log is simultaneously passed on.
2. DRM Radio List
   This feature has been added.
   The official DRMSchedule.ini file can now be loaded.
   Clicking an entry in the list causes DRMLogPlotter to switch to the desired frequency.
   If you use Hamlib-rigctl for your receiver, it will also automatically switch to the desired frequency.
   Even without remote RX control, the selected frequency is conveniently adopted as the log frequency.
   A display has been added to show the user the current DRM radio list.
3. The summary view has been optimized.
4. The help text has been expanded and optimized.
5. Minor optimizations have been made to the window hierarchy to improve clarity for the user.
6. The main GUI view has been further optimized for Linux/Raspberry Pi.

Update 28.July 2026

You will find very important information below in QUICK-START regarding operation with the DRMLogPlotter-rebuild.

1. You can now also find a DRMLogPltoter.bin and an AppImage for Raspberry Pi OS "Trixie" under "Releases"!
   Initial tests have been successful.
2. An attempt was made to optimize reading the audio code information from the PC screen, though this remains experimental.
3. The main GUI layout has been corrected for Linux (including AppImage and Raspberry Pi);
   it should now closely match the view in Windows 11.
4. "x11/xwayland" and "Wayland" radio buttons have been added to the Basic Settings, with "x11/xwayland" selected by default.
5. This is also strictly experimental—an attempt to better understand the issues involved.

Update 20.July 2026

Version 1.00 has been released.

New improvements have been implemented in the code!

- Main GUI -> Main Plot Window
  The display and analysis of the green Doppler line should now closely match the original DRMLogPlotter.
- Main GUI -> DRM Mode Used
  The DRM mode analysis has been further refined.
- Set Event -> Dream Start & Schedule Dialog
  The "midnight logic" has been completely overhauled. Timer events should now start correctly even after midnight.
- Main GUI -> Frame Color
  Color settings for the frame and scale display in the main plot window have been optimized for the "Gray" theme.
- Setup -> Basic Setup Parameters -> Dream and Receiver Configuration
  The "Hamlib NET rigctl" transceiver/RX selection should now work successfully with rigctl servers.

Once you have selected "Hamlib NET rigctl" from the Hamlib list, DRMLogPlotter continuously communicates with a rigctl server.

Successful connections via selection from the Hamlib list using USB or network connectivity have been confirmed:

- Icom IC-7300
- Icom IC-705
- Yaesu FT-891 (RX modified for DRM)
- Kenwood TS-2000 (RX modified for DRM)
- AirSpy with plugin (simulates Kenwood TS-2000)
- SDRPlay RSPDuo with SDR++ Software (rigctl server)

Hope it works for you, too

Update from 16.07.2026

- There are significant improvements once again: The "DReaM and RX Configuration" menu has been substantially expanded. RX parameters for HamLib/rigCTL can now be specifically configured.
- The processing of the dreamloglong.csv file has been revised. The "empty plot" issue should now be resolved.

Update from 07. July 2026

This update brings improvements, fixes, and new features!

The most significant new feature is as follows: When you launch the DReaM decoder software via drmlogplotter_v.0.99c, a new function comes into play. This function reads the DReaM label from the PC screen 30 seconds after startup and adds the missing audio code information to the DReaM log. In the process, a new file—DreamAudio.json—is written to the DReaM folder. drmlogplotter_v.0.99c then reads this new file and displays the information within the "Main Log" section of the main GUI.

- RX/TX Distance and AZ Calculation - Should now display the same result as the original drmlogplotter.
- Main GUI -> LED 3 - An additional LED has been added to the main GUI to provide a visual indicator for DReaM logs.

- Main GUI -> DReaM Stop Button - A new button has been added to the "Update Files" section, allowing the user to stop DReaM Remote quickly, easily, and correctly via drmlogplotter. This function ensures that various settings in Dream.ini are correctly reset.
- Main GUI -> Main Log Section - Result displays for Audio Code / Prot. Level and Audio Mode have been added.
- Main GUI -> DRM Mode Used Section - DReaM log glitches should no longer generate phantom modes.
- Main GUI -> Select Main Log - The tabular display of logs in DReaM is now better organized.
- Main GUI -> AutoPlot - The minimum interval time is now 5 seconds.
- Main GUI -> AutoPlot - If you run AutoPlot (manually or via a timer event) and Dream Log stops correctly via drmlogplotter, then AutoPlot checks for 15 seconds longer to see if a Dream Log is still running. This was exactly how it worked in the original version.
- Main GUI -> Line Plot - The "Delay" line is now finer and less bright, resulting in a more balanced visual appearance.
- Main GUI -> Line Plot - The "Doppler" line is now slightly brighter.
- Main GUI –> Line Plot The priority for the plotting process is now: 1) SNR, 2) Audio, 3) Doppler, 4) Delay.
- "Basic Setup Parameters" Dialog -> The window layout has been improved, and "Set" buttons have been added to make it more intuitive for the user.
- "Dream and Receiver Configuration" Dialog -> Input handling for the paths required to access Dream remotely via drmlogplotter has been optimized. This input method works equally well on Windows 11, Ubuntu, and Linux Mint. Also new "Set" button has been implemented.
- Help Text File -> The help text has been expanded and the sections reorganized for better clarity.
- drmtransmittersites.txt -> You can use your existing transmitter sites file from the original drmlogplotter with the new dlp-experimental version as well.
- Python -> A new third file has been created to support the program's workflow in Python. Therefore, all three files must be placed in the same directory.
- Linux binaries (startup issues) -> The compilation process has been optimized; consequently, DreamLogPlotter.bin and DreamAudio.bin should now be able to run from the same directory on Linux.
- Windows 11 -> There are now two .exe files that must be placed together in the same directory.
- Python/Linux/Windows 11 -> Additionally, place the files drmtransmittersites.txt and drmlogplotter_help.txt in this same directory.
- AppImage -> The AppImage contains all components. You can find the "Screenshot" and "Logs" folders, as well as drmplotter_cfg.json, at #####/home/pc/.local/share/drmlogplotter. In your file manager, go to View -> "Show Hidden Files" click yes to locate the .local folder within your "pc" directory.