

U1

40	PB0/XCK0/T0/PCINT8	PA0/ADC0/PCINT0	37
41	PB1/T1/CLKO/PCINT9	PA1/ADC1/PCINT1	36
42	PB2/AIN0/INT2/PCINT10	PA2/ADC2/PCINT2	35
43	PB3/AIN1/OC0A/PCINT11	PA3/ADC3/PCINT3	34
44	PB4/SS/OC0B/PCINT12	PA4/ADC4/PCINT4	33
1	PB5/MOSI/PCINT13	PA5/ADC5/PCINT5	32
2	PB6/MISO/PCINT14	PA6/ADC6/PCINT6	31
3	PB7/SCK/PCINT15	PA7/ADC7/PCINT7	30
9	PD0/RXD0/PCINT24	PC0/SCL/PCINT16	19
10	PD1/TXD0/PCINT25	PC1/SDA/PCINT17	20
11	PD2/INT0/RXD1/PCINT26	PC2/TCK/PCINT18	21
12	PD3/INT1/TXD1/PCINT27	PC3/TMS/PCINT19	22
13	PD4/OC1B/XCK1/PCINT28	PC4/TDO/PCINT20	23
14	PD5/OC1A/PCINT29	PC5/TDI/PCINT21	24
15	PD6/ICP/OC2B/PCINT30	PC6/TOSC1/PCINT22	25
16	PD7/OC2A/PCINT31	PC7/TOSC2/PCINT23	26
29	AREF	XTAL1	8
27	AVCC	XTAL2	7
4	RESET		

ATMEGA324P