

SOP – AFW Pump P-101A Operation and Verification

SOP-ID: SOP-AFW-001 | Authority: Mandatory

Cross References: CR-2026-00123, WO-2026-04567, ECA-2026-0007

1. Purpose

Describe the method to start AFW Pump P-101A and verify acceptable operating conditions.

2. Procedure

Step	Action
1	Verify MOV-204A is OPEN.
2	Start P-101A and monitor VB-101A vibration.
3	If vibration exceeds 5.0 mils, stop pump and initiate CR.

[FIGURE PLACEHOLDER]

Figure 1: AFW Pump P-101A Location and Monitoring Points